

特殊功能表

索引号	特殊功能名称	索引号	特殊功能名称
C000	Catalyst Replaced	C01A	Bosch ECM Replaced
C001	Check PCM Odometer	C01B	Cummins ECM Replaced
C002	Check VIN	C01C	Display TPM Sensors IDs
C003	Clear DTCs	C01D	Enable/Disable TPM
C004	Clear PCM Batt Disconnect	C01E	Erase All Current Ign Keys
C005	EGR SYSTEM TEST	C01F	Erase FOB Only Keys
C006	ETC SYSTEM TEST	C020	Manual SKIM Functions
C007	ETC THROTTLE FOLLOWER TEST	C021	Manual SKREEM Functions
C008	GENERATOR FULL FIELD TEST	C022	PCM Replaced
C009	GOV 3 & 4 SHIFT VALVE TEST	C023	Program Ignition Key(s)
C00A	IAC WIGGLE TEST	C024	Program New FOB
C00B	INJECTOR KILL TEST	C025	Program Tire Sensor ID
C00C	LDP MONITOR TEST	C026	SKIM Key Test
C00D	LEAK DETECTION PUMP TEST	C027	SKIM Replaced
C00E	LINEAR IAC TEST	C028	SKREEM Replaced
C00F	Learn ETC	C029	TPM Sensors Test
C010	MINIMUM AIRFLOW Test	C02A	TPM Tire Pressures
C011	MISFIRE MONITOR TEST	C02B	TPM Trigger Module Test
C012	NVLD Forced Monitor Test	C02C	Tire Pressure Placard Values
C013	O2 HEATER TEST	C02D	Battery Disconnect
C014	PURGE VAPORS TEST	C02E	Clutch Test
C015	ReLearn Cam Crank	C02F	EATX TCM Has Been Changed
C016	Reset Memory	C030	Quicklearn
C017	SET RPM SYSTEM TEST	C031	Shift Lever
C018	Set Sync Signal	C032	TCC Break-In
C019	TORQUE CONV CLUTCH TEST	C033	Trans Overhauled/Replaced

0081	Reset ECU	0099	Service Interval - Diesel
0039	Accessory Time Delay	0098	Service Interval - Gas
003C	Add Navigation Radio	007E	Enable FCM/IPM Diagnostics
003D	Change Country Code	007D	Program Tire Size:CS
0032	Disable Radio Clock Display	027B	1st Gear Clutch Test:62TE
003F	Enable DRL	025F	1st Gear Clutch Test:NonRFE
003E	Enable Front Fog Lamp Output	025E	1st Gear Clutch Test:RFE
0036	Flash Hazard Lamps On Lock	0260	2 Prime Gear Clutch Test:RFE
0037	Headlamps Delay Time	027C	2nd Gear Clutch Test:62TE
0035	Headlamps On With Wipers	0262	2nd Gear Clutch Test:NonRFE
0034	Horn Chirp Duration	0261	2nd Gear Clutch Test:RFE
0038	Illuminated Entry Time	027D	3rd Gear Clutch Test:62TE
003A	Program Network Configuration	0264	3rd Gear Clutch Test:NonRFE
0033	Sound Horn On Lock	0263	3rd Gear Clutch Test:RFE
0040	Trailer Tow Relay Outputs	02F8	4th Gear Clutch Test:62TE
00EA	Actuator Calibration Test	0140	ESIM Forced Monitor Test
00E8	Actuator DTC Detection	027E	Reverse Gear Clutch Test:62TE
0378	ATC Data Display	0266	Reverse Gear Clutch Test:NonRFE
00E9	Cool Down Test	0265	Reverse Gear Clutch Test:RFE
0324	Rear AC and Rear Wiper Wash Data Display	02FB	SRV Test
002F	Bleed Brakes ABS only	0281	Neutral Gate Test:NOT_RFE
002E	Program Tire Size	0280	Neutral Gate Test:RFE
0030	Bleed Brakes 2WD	0176	Overdrive Switch Test
0031	Bleed Brakes 4WD	024E	Overdrive Switch Test:RFE
0127	EGR System Test	016F	Quick Learn:RFE
0126	ETC Throttle Follower Test	0269	TCC BreakIn
0044	Injector Kill System Test	01FC	Thermistor Test
0129	NVLD Forced Monitor Test	802A	Software Reset Module
026C	O2 Heater System Test:1bank	802B	Hardware Reset Module
026D	O2 Heater System Test:2bank	01F6	Enable or Disable Mobile PTO
0128	Purge Vapors System Test	0291	3rd Gear Clutch Test:68RFE
012E	Set RPM Test - ETC Equipped	0290	Direct Gear Clutch Test:68RFE
012F	Set RPM Test - non - ETC Equipped	01FB	Quick Learn:Non-RFE
012C	Check PCM Odometer	033D	Aisin Trans Data
012D	Check PCM VIN	017B	Enable / Disable Vehicle Features:cc
0173	FCM Enable Emissions Rolls Test Mode	0292	Enable / Disable Vehicle Features:pu
012A	Learn ETC	0276	Mobile DeSoot - Minimum Required Soot Load
012B	Reset Memory	0277	Mobile DeSoot - No Minimum Required Soot Load
013B	TIPM Enable Emissions Rolls Test Mode	033B	Mobile DeSoot - No Minimum Required Soot Load_Var03
01D2	Erase All Ignition Keys	033C	Mobile DeSoot - No Minimum Required Soot Load_Var05
0228	PCM Replaced	017A	Reset Aftertreatment Trip Information
0226	Program Ignition Keys or Key FOBs:RKEONLY	0178	Reset NOx Adsorber Counts
0225	Program Ignition Keys or Key FOBs:SKIM	0179	Reset Pressure limiting Valve Accumulators
0227	WCM Replaced	0278	Reset Regenerative Filter Timers
008C	CCN Self Test	033A	VIEW/RESET DUTY CYCLE ACCUMULATORS:03
008F	Auto Door Lock	0303	AMP Tone Test with volume control
008E	Auto Door Unlock	00D5	HB and HG:Enable DRL
0091	Change Measurement Units	00D8	HB and HG:Program Tire Size
008D	Disable Seatbelt Minder Chime	00DB	ND:Enable Cruise Control

特殊功能表

索引号	特殊功能名称	索引号	特殊功能名称
0090	Unlock Driver Door On 1st Press	00D6	ND:Enable DRL
0167	1st Gear Clutch Test:FWD	00D9	ND:Program Tire Size
0166	1st Gear Clutch Test:RWD	00DA	WK and XK:Program Tire Size
01EE	2 Prime Gear Clutch Test	0272	WK:Enable DRL
016A	2nd Gear Clutch Test:FWD	0273	XK:Enable DRL
0169	2nd Gear Clutch Test:RWD	0323	IR Sensor Data
016C	3rd Gear Clutch Test:FWD	0317	Smart Bar Motor Self Test
016B	3rd Gear Clutch Test:RWD	0318	Sway Bar Telltale Fast Blink Actuator
016E	Reverse Gear Clutch Test:FWD	031A	Sway Bar Telltale Off Actuator
016D	Reverse Gear Clutch Test:RWD	031B	Sway Bar Telltale On Actuator
01F0	Shift Lever Position Test:NON_RFE	0319	Sway Bar Telltale Slow Blink Actuator
0172	Shift Lever Position Test:RFE	02BA	Diesel Particulate Filter Replacement
0177	Clear Variable Line Pressure (VLP) Counters	02B9	Differential Pressure Sensor Replacement
0170	Quick Learn:NOT_RFE	02BF	Display Diesel Particulate Filter Values
0175	TCC Break-In	02BD	ECU Replacement With Value Transfer
0289	AMP Channel Output Channel Test:6 Channel	02BE	ECU Replacement Without Value Transfer
028A	AMP Channel Output Channel Test:8 Channel	02BC	Emission-Relevant Component Replacement
006D	AMP Input Test	0144	Program Variant Code
006B	AMP Mute Channel:6 Channel	02C0	Reset Inhibiting Timer
006C	AMP Mute Channel:8 Channel	02BB	Reset Mass Airflow Values
0068	AMP Software Test	031D	Service Diesel Particulate Filter Regeneration
006A	AMP Tone Test	02C1	Set Oil Dilution Mass Value
011E	OCM System Verification Test	02C2	View Oil Dilution Mass Value
013C	Cam Crank Relearn	0219	Auto Wipers
01F1	Clear Variable Line Pressure (VLP)	021E	Program Tire Size:JK
01EF	Quick Learn	021F	Program Tire Size:KA
01F4	Initialize EGS-52	021D	Unlock All Doors 1st Press
01F3	Reset Learned Adaptives	0288	Actuator Calibration Front Only
01F2	Store Learned Adaptives	0287	Actuator Calibration w/Rear
005A	Cycle Stop Lamp Relay	00EC	HVAC Self Test
0058	Bleed Brakes:LX	02E7	Downstream O2 Response Monitor
0059	Bleed Brakes:WK	013E	ETC System Test
005E	Initialize ABS Module	0314	Adaptive Numerator Learn
005C	Initialize ESP Module:LX	0310	Cruise Control Data
005D	Initialize ESP Module:WK	0064	ACC Cutout Reasons Clear
005F	Initialize ESP Module:WK-Non ESP	0065	Align ACC Sensor
005B	Initialize Steering Angle Sensor	02CE	Change Cruise Control Mode
0094	Language Preference	0067	AHBM Self Test
00C4	Enable Cruise Control	01F5	CVT Initialization
0002	Bleed Brakes	0012	Learn Motor
0232	Program Left Front Tire Sensor ID	02D6	Modulator Solenoid Test
0230	Program Left Rear Tire Sensor ID	02D7	Shift Pressure Solenoid Test
0231	Program Right Front Tire Sensor ID	02D4	TCC Solenoid Test
022F	Program Right Rear Tire Sensor ID	02D5	Transmission Shift Solenoids Test
01DE	Program Spare Tire Sensor ID	0018	TCM Reset Learned Adaptives
022D	Update Pressure Thresholds	0014	ORC Initialize ECU
0274	WCM Replaced Non TPM	0013	Reset ORC
0373	Program Tire Size for EATX	02CF	Sensors:Bussed Inputs:and Bussed Outputs
0374	Program Tire Size for EGS 52	032D	Activate/Deactivate Cruise Control
0097	CCN Gauge Test	0001	Calibrate G-Sensor
0042	Compression Test	0003	Drive Test
0149	Cylinder Balance Test	029F	Calibrate AHLM
0142	Cylinder Fuel Quantity Correction Test	02D0	Verify Front TPM Antenna
0145	Set RPM System Test	02D1	Verify Rear TPM Antenna
014B	Exhaust Throttle Plate Adaptive Learn Position	001A	Left Front Tire Pressure Signal Transmission Test
014A	Fuel Mean Value Adaptation Initialization	001B	Left Rear Tire Pressure Signal Transmission Test
0148	IMA Rapid Calibration	001C	Right Front Tire Pressure Signal Transmission Test
0049	Injector Quantity Adjustment	001D	Right Rear Tire Pressure Signal Transmission Test
0146	NOx Catalyst(New) Initialization	0247	Tire Pressure ECU Replacement with Manual Initialization
0147	NOx Catalyst(Used) Learning	004E	View Electronic TPM ID
0066	Aim Test	0004	AEHM Actuate Heater Booster
0156	CYLINDER PERFORMANCE TEST - Automatic Transmission	002A	Replace Steering Column Lock
0157	CYLINDER PERFORMANCE TEST - Manual Transmission	0007	CCN Display Dimmer Test
0154	FUEL PRESSURE OVERRIDE - Automatic Transmission	0008	CCN LCD Display Test
0155	FUEL PRESSURE OVERRIDE - Manual Transmission	0005	Gauge Sweep Test
0141	GENERATOR FULL FIELD TEST	0334	Pushbutton Test
0150	Set RPM System Test - Automatic Transmission	0006	Speaker Test
0151	Set RPM System Test - Manual Transmission	032F	Customer Programmable- Clock
0153	TORQUE CONVERTER CLUTCH TEST	0330	Customer Programmable- Daytime Running Lamps
015A	TVA AUTO ZERO TEST	0331	Customer Programmable- Language
0159	TVA SPAN TEST	0332	Customer Programmable- Speedometer/Odometer Units
0158	IDLE UP FEATURE ENABLE	0333	Customer Programmable- Temperature
014F	VIEW/RESET DUTY CYCLE ACCUMULATORS	0009	Oil Change Reset
0152	VIEW/RESET TRIP INFORMATION ACCUMULATORS	000A	Personalize with Electronic Ignition Switch
0242	DR WCM Replaced SCI	032E	Update Service Interval

特殊功能表

索引号	特殊功能名称	索引号	特殊功能名称
023F	PCM Replaced SRT-10 Only	0337	Set High Idle Allowed Speeds
0233	TPM Trigger Module Test	001E	Check/Write VIN
0241	WCM Gateway Replaced	0023	Engine ECU Replaced (Drive Authorization)
023D	WCM Replaced 1	0043	Exhaust Throttle Plate Adaptive Learn
023E	WCM Replaced 2	026E	Mass Air Flow Sensor Initialization
0271	WCM Replaced Not Var 5 non TPM	026F	Rail Pressure Initialization
0270	WCM Replaced Var 5 non TPM	0336	Set Maximum Vehicle Speed
0285	Initialize ABS Non ESP	0025	O2 Sensor Monitor Test
0062	Initialize ESP Sensor	0024	Camshaft Reference Adaptation
028D	AMP Channel Output Channel Test:No Channel 7	0022	Fuel Pump Activation
027F	AMP Mute Channel:No Channel 7	0020	Reset Adaptive Memory
00EB	Actuator Calibration Test DR	0021	Throttle Valve Initialization
0214	Combined Rear Lighting	8001	TPM Train Tires
0210	DR Restore Customer Preference	8002	Stop Tire Training
020E	Program Tire Size:DR	8070	Oil Change
0213	Program Tire Size:JS	807D	RESET OIL CHANGE
0215	Program Tire Size:PM or MK	033F	TPM Trigger Module Test DH
028F	Program Tire Size:PM or MK No TCM	02DE	Update Heavy Load Pressure Thresholds
0211	PT Restore Customer Preference	02DF	Update Light Load Pressure Thresholds
00C6	Tip Start Override	02F1	View Last Successful Remote Start Event Data
0069	AMP Channel Output Channel Test	02F0	View Remote Start Abort Data
0079	AMP Multiple Mute Channel	02F3	View Remote Start Enable Data
02F6	AMP Tone Test without volume control	02EF	View Remote Start Inhibit Data
801A	Reset Module	02A6	Clear Last Successful Remote Start
8023	Original VIN Read	02A5	Clear Remote Start Abort Reasons
8024	Current VIN Read	02A4	Clear Remote Start Inhibit Reasons
8003	WCM Replaced - Gas	0293	Remote Start Override
8004	PCM Replaced - Gas	0313	DPF Replacement
8005	WCM Replaced - Diesel	0312	ECM Replacement
8006	PCM Replaced - Diesel	0311	Manual DPF Regeneration
8007	Erase Key FOBs Only	02E3	Program Tire Size:JC
800D	Program Ignition Keys	0122	Rollover Detection
8008	Program Key FOBs	0245	WIN Replaced
8009	View SKREEM VIN	02E2	Program Tire Size:KK
800A	View SKREEM Country Code	02F7	TPM Sensor Test
800B	Reset SKREEM	0321	ACC Exit In-Plant Mode
800C	Enable Disable TPM	02AD	OCM Rezero Procedure
800E	WCM Trigger Module Test	0325	LDP Forced Monitor Test
01DA	WCM TPM Sensor Test	0193	Leak detection pump test
804F	Configure Cluster	0326	View Adaptive Numerator Status
8050	Clear Learned Features	037A	EVR Enable/Disable
8051	Seatbelt Alert System 2007	0379	PTO RPM Adjustment
8052	Seatbelt Alert System 2006	02F9	Exhaust Phaser 1 Cleaning
8018	Horn Chirp	0304	Engine On Odometer
8017	Optical Horn Chirp	02FA	New Engine Installed
8015	Rolling Door Locks	02EA	First Pass Cool Down Test Results
8057	RKE Unlock Sequence	02EB	Most Recent Cool Down Test Results
8012	Enable VTSS	02E9	AC Cool Down Test
8058	Update Model Year to 2007	02A1	Initialize ORC
0073	AMP Mute Channel:7 Channel	018D	Check Vin
028B	AMP Channel Output Channel Test:7 Channel	0360	Replace TCM
0045	Diesel Particulate Filter (New) Initialization	035B	Shift Lever Position Test
0046	Diesel Particulate Filter (Used) Learning	035C	Trans Adapts Reset Trigger
014D	Manual Diesel Particulate Filter Regeneration	035D	Trans Fast Learn Trigger
00C8	Police VTA	035E	Trans Line Pressure
00C9	Program Tire Size:ND	035F	Transmission Cleaning Procedure
0060	Initialize ESP Module:PT	035A	Abs System Calibration
0092	Measurement Unit	034A	Aux Heater Coolant Pump Temp Test
0096	Seatbelt Alert System	034B	EVAP Temp Target Speed
028E	Program Tire Size:PT No TCM	02A7	Antenna Loop Test
0240	PCM Replaced 1.6L Only	0476	Program Tire Size/Pinion Factor
0243	PT WCM Replaced SCI		