

BMW_V1.00 Function List

NOTES:

- This function is supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Series	Model Series	Part	Systems	Ecu Info	Read DTC	Erase DTC	Live Data	Service function
1 Series	E81/E82/E87/E88	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	AL active front steering(AFS70)	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	AL active steering	●	●	●	●	●
3 Series	E46	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
3 Series	E46	Chassis	LWS Steering angle sensor	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	AL active front steering(AFS70)	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	AL active steering	●	●	●	●	●
5 Series	E39	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
5 Series	E39	Chassis	LEW Steering-angle sensor	●	●	●	●	●
5 Series	E60/E61	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
5 Series	E60/E61	Chassis	AL active front steering(AFS70)	●	●	●	●	●
5 Series	E60/E61	Chassis	AL active steering	●	●	●	●	●
6 Series	E63/E64	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
6 Series	E63/E64	Chassis	AL active front steering(AFS70)	●	●	●	●	●
6 Series	E63/E64	Chassis	AL active steering	●	●	●	●	●
7 Series	E38	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
7 Series	E38	Chassis	LEW Steering-angle sensor	●	●	●	●	●
7 Series	E65	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
X3 Series	E83	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
X3 Series	E83	Chassis	LWS Steering angle sensor	●	●	●	●	●
X5 Series	E53	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
X5 Series	E53	Chassis	LEW Steering-angle sensor	●	●	●	●	●
X5 Series	E70	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
X5 Series	E70	Chassis	AL active front steering(AFS70)	●	●	●	●	●
X6 Series	E71	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
X6 Series	E71	Chassis	AL active steering	●	●	●	●	●
Z3 Series	E36	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
Z3 Series	E36	Chassis	LEW Steering-angle sensor	●	●	●	●	●
Z4 Series	E85/E86	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
Z4 Series	E85/E86	Chassis	LWS Steering angle sensor	●	●	●	●	●
Z8 Series	E52	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
Z8 Series	E52	Chassis	LEW Steering-angle sensor	●	●	●	●	●
Z Reihe	Z4_E89	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●
1 Series	F20	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
3 Series	F30	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
5 Series	F07	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
5 Series	F10/F11	Chassis	AL active steering	●	●	●	●	●
5 Series	F10/F11	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
5 Series	F18	Chassis	AL active steering	●	●	●	●	●
5 Series	F18	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
6 Series	F12/F13	Chassis	AL active steering	●	●	●	●	●
6 Series	F12/F13	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
7 Series	F01/F02/F04	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
7 Series	F01/F02/F04	Chassis	AL active steering	●	●	●	●	●
X3 Series	F25	Chassis	DSC Dynamic Stability Control	●	●	●	●	●
X6 Series	E72	Chassis	DSC Dynamic Stability Control	●	●	●	●	●