

PCM0702M		Bdm(MPC5xx)	33
PCM0308M		Bdm(MPC5xx)	33
PCMBE0101		Bdm(MPC5xx)	33
PCM0309M		Bdm(MPC5xx)	33
PCM0702		Bdm(MPC5xx)	33
PCM0802		Bdm(MPC5xx)	33
PCM0702		Bdm(MPC5xx)	33
PCM0308M		Bdm(MPC5xx)	33
PCM0701		Bdm(MPC5xx)	33
PCM0801		Bdm(MPC5xx)	33
PCMBE0101		Bdm(MPC5xx)	33
PCM0309M		Bdm(MPC5xx)	33
PCM0702		Bdm(MPC5xx)	33
PCM0702		Bdm(MPC5xx)	33
PCM0309M		Bdm(MPC5xx)	33
PCM0702		Bdm(MPC5xx)	33
PCM0802		Bdm(MPC5xx)	33
PCM0702M		Bdm(MPC5xx)	33
ME17.8.5		Boot(Tricore)	1180
ME17.8.5		Boot(Tricore)	1180
ME17.8.5		Boot(Tricore)	1180
ME17.8.5		Boot(Tricore)	1180
ME17.8.5		Boot(Tricore)	1180
33920-93J40		Jtag(Mitsubishi)	616
33920-93J40		Jtag(Mitsubishi)	616
33920-93J74		Jtag(Mitsubishi)	616
33920-93J74		Jtag(Mitsubishi)	616
		Jtag(Mitsubishi)	254
		Jtag(Mitsubishi)	254
		Jtag(Mitsubishi)	254
EMS2	310	Bdm(MPC5xx)	138
EDC17CP22		Boot(Tricore)	1399
EDC17CP22		Boot(Tricore)	1399
EDC17CP22		Boot(Tricore)	1399
EDC17CP22		Boot(Tricore)	1399
EDC7C1/C2	252	Bdm(MPC5xx)	59
EDC7C1/C2	252	Bdm(MPC5xx)	59
EDC7C1/C2	252	Bdm(MPC5xx)	59
6D9-8591A-XX		Jtag(Mitsubishi)	631
6AK-8591A-3X		Jtag(Mitsubishi)	631
6C18591A-2X		Jtag(Mitsubishi)	631
6C5-8591A-4X		Jtag(Mitsubishi)	631
6D6-8591A-XX		Jtag(Mitsubishi)	631
6D7-8591A-XX		Jtag(Mitsubishi)	631
6D8-8591A-XX		Jtag(Mitsubishi)	631
F8T94875		Jtag(Mitsubishi)	574
F8T94873		Jtag(Mitsubishi)	574
F8T60xxx		Jtag(Mitsubishi)	284
F8T60xxx		Jtag(Mitsubishi)	284
F8T60xxx		Jtag(Mitsubishi)	284