



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------|--------------|-----------|----------|-----------|
| C30     | 2009 | TCM    | MPS6         | ●         | ●        | ●         |
| C30     | 2009 | ECM    | D5244T9      | ●         | ●        | ●         |
| C30     | 2009 | ECM    | D5244T8      | ●         | ●        | ●         |
| C30     | 2009 | ECM    | D5244T13     | ●         | ●        | ●         |
| C30     | 2009 | ECM    | D4204T       | ●         | ●        | ●         |
| C30     | 2009 | ADM    | D4204T       | ●         | ●        | ●         |
| C30     | 2009 | ECM    | D4204T       | ●         | ●        | ●         |
| C30     | 2009 | ADM    | D4164T       | ●         | ●        | ●         |
| C30     | 2009 | ECM    | D4164T       | ●         | ●        | ●         |
| C30     | 2009 | ECM    | B5254T7      | ●         | ●        | ●         |
| C30     | 2009 | ECM    | B5244S4      | ●         | ●        | ●         |
| C30     | 2009 | ECM    | B4204S3      | ●         | ●        | ●         |
| C30     | 2009 | ECM    | B4184S8      | ●         | ●        | ●         |
| C30     | 2009 | ECM    | B4184S11     | ●         | ●        | ●         |
| C30     | 2009 | ECM    | B4164S3      | ●         | ●        | ●         |
| C30     | 2009 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C30     | 2009 | AEM    |              | ●         | ●        | ●         |
| C30     | 2009 | KVM    |              | ●         | ●        | ●         |
| C30     | 2009 | RDAR   |              | ●         | ●        | ●         |
| C30     | 2009 | PHM    |              | ●         | ●        | ●         |
| C30     | 2009 | CPM    |              | ●         | ●        | ●         |
| C30     | 2009 | AUD    |              | ●         | ●        | ●         |
| C30     | 2009 | BPM    |              | ●         | ●        | ●         |
| C30     | 2009 | PAM    |              | ●         | ●        | ●         |
| C30     | 2009 | SRS    |              | ●         | ●        | ●         |
| C30     | 2009 | DDM    |              | ●         | ●        | ●         |
| C30     | 2009 | PDM    |              | ●         | ●        | ●         |
| C30     | 2009 | AUU    |              | ●         | ●        | ●         |
| C30     | 2009 | BCM    |              | ●         | ●        | ●         |
| C30     | 2009 | CCM    |              | ●         | ●        | ●         |
| C30     | 2009 | SWM    |              | ●         | ●        | ●         |
| C30     | 2009 | TRM    |              | ●         | ●        | ●         |
| C30     | 2009 | EPS    |              | ●         | ●        | ●         |
| C30     | 2009 | IAM    |              | ●         | ●        | ●         |
| C30     | 2009 | PSL    |              | ●         | ●        | ●         |
| C30     | 2009 | PSR    |              | ●         | ●        | ●         |
| C30     | 2009 | CEM    |              | ●         | ●        | ●         |
| C30     | 2009 | DIM    |              | ●         | ●        | ●         |
| C30     | 2009 | ICM    |              | ●         | ●        | ●         |
| C30     | 2009 | MMM    |              | ●         | ●        | ●         |
| C30     | 2008 | TCM    | MPS6         | ●         | ●        | ●         |
| C30     | 2008 | ECM    | D5244T9      | ●         | ●        | ●         |
| C30     | 2008 | ECM    | D5244T8      | ●         | ●        | ●         |
| C30     | 2008 | ECM    | D5244T13     | ●         | ●        | ●         |
| C30     | 2008 | ECM    | D4204T       | ●         | ●        | ●         |
| C30     | 2008 | ADM    | D4204T       | ●         | ●        | ●         |
| C30     | 2008 | ECM    | D4204T       | ●         | ●        | ●         |
| C30     | 2008 | ADM    | D4164T       | ●         | ●        | ●         |
| C30     | 2008 | ECM    | D4164T       | ●         | ●        | ●         |
| C30     | 2008 | ECM    | B5254T7      | ●         | ●        | ●         |
| C30     | 2008 | ECM    | B5244S4      | ●         | ●        | ●         |
| C30     | 2008 | ECM    | B4204S3      | ●         | ●        | ●         |
| C30     | 2008 | ECM    | B4184S8      | ●         | ●        | ●         |
| C30     | 2008 | ECM    | B4184S11     | ●         | ●        | ●         |
| C30     | 2008 | ECM    | B4164S3      | ●         | ●        | ●         |
| C30     | 2008 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C30     | 2008 | BCM    |              | ●         | ●        | ●         |
| C30     | 2008 | KVM    |              | ●         | ●        | ●         |
| C30     | 2008 | RDAR   |              | ●         | ●        | ●         |
| C30     | 2008 | CPM    |              | ●         | ●        | ●         |
| C30     | 2008 | AUD    |              | ●         | ●        | ●         |
| C30     | 2008 | PAM    |              | ●         | ●        | ●         |
| C30     | 2008 | SRS    |              | ●         | ●        | ●         |
| C30     | 2008 | DDM    |              | ●         | ●        | ●         |
| C30     | 2008 | PDM    |              | ●         | ●        | ●         |
| C30     | 2008 | PSL    |              | ●         | ●        | ●         |
| C30     | 2008 | PSR    |              | ●         | ●        | ●         |
| C30     | 2008 | AUU    |              | ●         | ●        | ●         |
| C30     | 2008 | CCM    |              | ●         | ●        | ●         |
| C30     | 2008 | PHM    |              | ●         | ●        | ●         |
| C30     | 2008 | CEM    |              | ●         | ●        | ●         |
| C30     | 2008 | DIM    |              | ●         | ●        | ●         |
| C30     | 2008 | SWM    |              | ●         | ●        | ●         |
| C30     | 2008 | TRM    |              | ●         | ●        | ●         |
| C30     | 2008 | EPS    |              | ●         | ●        | ●         |
| C30     | 2008 | IAM    |              | ●         | ●        | ●         |
| C30     | 2008 | ICM    |              | ●         | ●        | ●         |
| C30     | 2008 | MMM    |              | ●         | ●        | ●         |
| C30     | 2007 | ECM    | D5244T9      | ●         | ●        | ●         |
| C30     | 2007 | ECM    | D5244T8      | ●         | ●        | ●         |
| C30     | 2007 | ADM    | D4204T       | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------|--------------|-----------|----------|-----------|
| C30      | 2007 | ECM    | D4204T       | ●         | ●        | ●         |
| C30      | 2007 | ADM    | D4164T       | ●         | ●        | ●         |
| C30      | 2007 | ECM    | D4164T       | ●         | ●        | ●         |
| C30      | 2007 | ECM    | B5254T3      | ●         | ●        | ●         |
| C30      | 2007 | ECM    | B5244S4      | ●         | ●        | ●         |
| C30      | 2007 | ECM    | B4204S3      | ●         | ●        | ●         |
| C30      | 2007 | ECM    | B4184S8      | ●         | ●        | ●         |
| C30      | 2007 | ECM    | B4184S11     | ●         | ●        | ●         |
| C30      | 2007 | ECM    | B4164S3      | ●         | ●        | ●         |
| C30      | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C30      | 2007 | DIM    |              | ●         | ●        | ●         |
| C30      | 2007 | GPS    |              | ●         | ●        | ●         |
| C30      | 2007 | BCM    |              | ●         | ●        | ●         |
| C30      | 2007 | TMC    |              | ●         | ●        | ●         |
| C30      | 2007 | SWM    |              | ●         | ●        | ●         |
| C30      | 2007 | KVM    |              | ●         | ●        | ●         |
| C30      | 2007 | PHM    |              | ●         | ●        | ●         |
| C30      | 2007 | CEM    |              | ●         | ●        | ●         |
| C30      | 2007 | MMM    |              | ●         | ●        | ●         |
| C30      | 2007 | RDAR   |              | ●         | ●        | ●         |
| C30      | 2007 | CPM    |              | ●         | ●        | ●         |
| C30      | 2007 | IAM    |              | ●         | ●        | ●         |
| C30      | 2007 | AUD    |              | ●         | ●        | ●         |
| C30      | 2007 | PAM    |              | ●         | ●        | ●         |
| C30      | 2007 | SRS    |              | ●         | ●        | ●         |
| C30      | 2007 | DDM    |              | ●         | ●        | ●         |
| C30      | 2007 | PDM    |              | ●         | ●        | ●         |
| C30      | 2007 | PSL    |              | ●         | ●        | ●         |
| C30      | 2007 | PSR    |              | ●         | ●        | ●         |
| C30      | 2007 | CCM    |              | ●         | ●        | ●         |
| C30      | 2007 | TRM    |              | ●         | ●        | ●         |
| C30      | 2007 | ICM    |              | ●         | ●        | ●         |
| C30      | 2007 | EPS    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | TCM    | MPS6         | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | D5244T9      | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | D5244T8      | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | D5244T13     | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | D4204T       | ●         | ●        | ●         |
| C70(06-) | 2009 | ADM    | D4204T       | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | D4204T       | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | B5254T7      | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | B5244S5      | ●         | ●        | ●         |
| C70(06-) | 2009 | ECM    | B5244S4      | ●         | ●        | ●         |
| C70(06-) | 2009 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C70(06-) | 2009 | AEM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | KVM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | RDAR   |              | ●         | ●        | ●         |
| C70(06-) | 2009 | PHM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | CPM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | AUD    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | BPM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | PAM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | SRS    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | DDM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | PDM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | AUU    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | BCM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | CCM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | CRM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | SWM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | TRM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | EPS    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | SUB    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | IAM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | PSL    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | PSR    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | CEM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | DIM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | ICM    |              | ●         | ●        | ●         |
| C70(06-) | 2009 | MMM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | D5244T9      | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | D5244T8      | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | D5244T13     | ●         | ●        | ●         |
| C70(06-) | 2008 | ADM    | D4204T       | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | D4204T       | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | B5254T7      | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | B5244S5      | ●         | ●        | ●         |
| C70(06-) | 2008 | ECM    | B5244S4      | ●         | ●        | ●         |
| C70(06-) | 2008 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C70(06-) | 2008 | BCM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | AEM    |              | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------|--------------|-----------|----------|-----------|
| C70(06-) | 2008 | KVM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | RDAR   |              | ●         | ●        | ●         |
| C70(06-) | 2008 | CPM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | AUD    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | PAM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | SRS    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | DDM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | PDM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | PSL    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | PSR    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | AUU    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | CCM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | PHM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | CRM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | CEM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | DIM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | SWM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | TRM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | EPS    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | SUB    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | IAM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | ICM    |              | ●         | ●        | ●         |
| C70(06-) | 2008 | MMM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | ECM    | D5244T9      | ●         | ●        | ●         |
| C70(06-) | 2007 | ECM    | D5244T8      | ●         | ●        | ●         |
| C70(06-) | 2007 | ECM    | B5254T3      | ●         | ●        | ●         |
| C70(06-) | 2007 | ECM    | B5244S5      | ●         | ●        | ●         |
| C70(06-) | 2007 | ECM    | B5244S4      | ●         | ●        | ●         |
| C70(06-) | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C70(06-) | 2007 | DIM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | GPS    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | BCM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | TMC    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | SWM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | KVM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | AEM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | PHM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | TRM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | CEM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | MMM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | RDAR   |              | ●         | ●        | ●         |
| C70(06-) | 2007 | CPM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | SUB    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | IAM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | AUD    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | PAM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | SRS    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | DDM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | PDM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | PSL    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | PSR    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | CCM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | CRM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | ICM    |              | ●         | ●        | ●         |
| C70(06-) | 2007 | EPS    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | ECM    | B5254T3      | ●         | ●        | ●         |
| C70(06-) | 2006 | ECM    | B5244S5      | ●         | ●        | ●         |
| C70(06-) | 2006 | ECM    | B5244S4      | ●         | ●        | ●         |
| C70(06-) | 2006 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| C70(06-) | 2006 | DIM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | GPS    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | BCM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | TMC    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | SWM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | KVM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | AEM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | ICM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | IAM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | AUD    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | PHM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | TRM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | PSL    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | CEM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | MMM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | CPM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | SUB    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | PSR    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | DDM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | PDM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | CCM    |              | ●         | ●        | ●         |
| C70(06-) | 2006 | PAM    |              | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System                   | Type                     | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------------------------|--------------------------|-----------|----------|-----------|
| C70(06-) | 2006 | SRS                      |                          | ●         | ●        | ●         |
| C70(06-) | 2006 | CRM                      |                          | ●         | ●        | ●         |
| C70(06-) | 2006 | EPS                      |                          | ●         | ●        | ●         |
| C70 Conv | 2005 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv | 2005 | Petrol                   | B5234T9                  | ●         | ●        | ●         |
| C70 Conv | 2005 | Petrol                   | B5244T7                  | ●         | ●        | ●         |
| C70 Conv | 2005 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv | 2005 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv | 2005 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv | 2005 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Conv | 2005 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv | 2005 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv | 2005 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv | 2005 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv | 2005 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv | 2005 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv | 2005 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv | 2005 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Conv | 2004 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv | 2004 | Petrol                   | B5234T9                  | ●         | ●        | ●         |
| C70 Conv | 2004 | Petrol                   | B5244T7                  | ●         | ●        | ●         |
| C70 Conv | 2004 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv | 2004 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv | 2004 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv | 2004 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Conv | 2004 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv | 2004 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv | 2004 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv | 2004 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv | 2004 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv | 2004 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv | 2004 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv | 2004 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Conv | 2003 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv | 2003 | Petrol                   | B5234T9                  | ●         | ●        | ●         |
| C70 Conv | 2003 | Petrol                   | B5244T7                  | ●         | ●        | ●         |
| C70 Conv | 2003 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv | 2003 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv | 2003 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv | 2003 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Conv | 2003 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv | 2003 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv | 2003 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv | 2003 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv | 2003 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv | 2003 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv | 2003 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv | 2003 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Conv | 2002 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv | 2002 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Conv | 2002 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| C70 Conv | 2002 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv | 2002 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv | 2002 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv | 2002 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Conv | 2002 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv | 2002 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv | 2002 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv | 2002 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv | 2002 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv | 2002 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv | 2002 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv | 2002 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Conv | 2001 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv | 2001 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Conv | 2001 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| C70 Conv | 2001 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv | 2001 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv | 2001 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv | 2001 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Conv | 2001 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv | 2001 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv | 2001 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv | 2001 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv | 2001 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv | 2001 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv | 2001 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv | 2001 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Conv | 2000 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| C70 Conv | 2000 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv | 2000 | Petrol                   | B5234T3                  | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle   | Year | System                   | Type                     | ECU Info. | Read DTC | Clear DTC |
|-----------|------|--------------------------|--------------------------|-----------|----------|-----------|
| C70 Conv  | 2000 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| C70 Conv  | 2000 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| C70 Conv  | 2000 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv  | 2000 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv  | 2000 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv  | 2000 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| C70 Conv  | 2000 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Conv  | 2000 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv  | 2000 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv  | 2000 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv  | 2000 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv  | 2000 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv  | 2000 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv  | 2000 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv  | 2000 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Conv  | 1999 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| C70 Conv  | 1999 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Conv  | 1999 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Conv  | 1999 | Petrol                   | B5254T                   | ●         | ●        | ●         |
| C70 Conv  | 1999 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Conv  | 1999 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Conv  | 1999 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Conv  | 1999 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| C70 Conv  | 1999 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Conv  | 1999 | Cab control system       | Cab control system       | ●         | ●        | ●         |
| C70 Conv  | 1999 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Conv  | 1999 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Conv  | 1999 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Conv  | 1999 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Conv  | 1999 | Rollover protection      | Rollover protection      | ●         | ●        | ●         |
| C70 Conv  | 1999 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Coupe | 2002 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Coupe | 2002 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Coupe | 2002 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| C70 Coupe | 2002 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Coupe | 2002 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Coupe | 2002 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Coupe | 2002 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Coupe | 2002 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Coupe | 2002 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Coupe | 2002 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Coupe | 2002 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Coupe | 2002 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Coupe | 2002 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Coupe | 2001 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Coupe | 2001 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Coupe | 2001 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| C70 Coupe | 2001 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Coupe | 2001 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Coupe | 2001 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Coupe | 2001 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Coupe | 2001 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Coupe | 2001 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Coupe | 2001 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Coupe | 2001 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Coupe | 2001 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Coupe | 2001 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Coupe | 2000 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| C70 Coupe | 2000 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Coupe | 2000 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Coupe | 2000 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| C70 Coupe | 2000 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| C70 Coupe | 2000 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Coupe | 2000 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Coupe | 2000 | RTI                      | RTI                      | ●         | ●        | ●         |
| C70 Coupe | 2000 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| C70 Coupe | 2000 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| C70 Coupe | 2000 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Coupe | 2000 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Coupe | 2000 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Coupe | 2000 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Coupe | 2000 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Coupe | 2000 | SRS                      | SRS                      | ●         | ●        | ●         |
| C70 Coupe | 1999 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| C70 Coupe | 1999 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| C70 Coupe | 1999 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| C70 Coupe | 1999 | Petrol                   | B5254S DENSO             | ●         | ●        | ●         |
| C70 Coupe | 1999 | Petrol                   | B5254T                   | ●         | ●        | ●         |
| C70 Coupe | 1999 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| C70 Coupe | 1999 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| C70 Coupe | 1999 | RTI                      | RTI                      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

| NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a |      |                          |                          |           |          |           |
|---|------|--------------------------|--------------------------|-----------|----------|-----------|
| Vehicle   | Year | System                   | Type                     | ECU Info. | Read DTC | Clear DTC |
| C70 Coupe   | 1999 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| C70 Coupe   | 1999 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| C70 Coupe   | 1999 | CCM                      | CCM                      | ●         | ●        | ●         |
| C70 Coupe   | 1999 | CPM                      | CPM                      | ●         | ●        | ●         |
| C70 Coupe   | 1999 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| C70 Coupe   | 1999 | Power seat module, right | Power seat module, right | ●         | ●        | ●         |
| C70 Coupe   | 1999 | SRS                      | SRS                      | ●         | ●        | ●         |
| S40(04-)  | 2009 | TCM                      | MPS6                     | ●         | ●        | ●         |
| S40(04-)  | 2009 | DEM                      | M66 AWD                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | D5244T9                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | D5244T8                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | D5244T13                 | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | D4204T                   | ●         | ●        | ●         |
| S40(04-)  | 2009 | ADM                      | D4204T                   | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | D4204T                   | ●         | ●        | ●         |
| S40(04-)  | 2009 | ADM                      | D4164T                   | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | D4164T                   | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B5254T7                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B5244S7                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B5244S5                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B5244S4                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B4204S3                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B4184S8                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B4184S11                 | ●         | ●        | ●         |
| S40(04-)  | 2009 | ECM                      | B4164S3                  | ●         | ●        | ●         |
| S40(04-)  | 2009 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| S40(04-)  | 2009 | DEM                      | AW50/51 AWD              | ●         | ●        | ●         |
| S40(04-)  | 2009 | TCM                      | AW50/51 AWD              | ●         | ●        | ●         |
| S40(04-)  | 2009 | PSM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | AEM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | KVM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | RDAR                     |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | PHM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | CPM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | AUD                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | BPM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | PAM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | SRS                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | DDM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | PDM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | AUU                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | HCM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | BCM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | CCM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | SWM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | TRM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | EPS                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | IAM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | CEM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | DIM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | ICM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2009 | MMM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | TCM                      | MPS6                     | ●         | ●        | ●         |
| S40(04-)  | 2008 | DEM                      | M66 AWD                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | D5244T9                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | D5244T8                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | D5244T13                 | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | D4204T                   | ●         | ●        | ●         |
| S40(04-)  | 2008 | ADM                      | D4204T                   | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | D4204T                   | ●         | ●        | ●         |
| S40(04-)  | 2008 | ADM                      | D4164T                   | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | D4164T                   | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B5254T7                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B5254T3                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B5244S7                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B5244S5                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B5244S4                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B4204S3                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B4184S8                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B4184S11                 | ●         | ●        | ●         |
| S40(04-)  | 2008 | ECM                      | B4164S3                  | ●         | ●        | ●         |
| S40(04-)  | 2008 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| S40(04-)  | 2008 | DEM                      | AW50/51 AWD              | ●         | ●        | ●         |
| S40(04-)  | 2008 | TCM                      | AW50/51 AWD              | ●         | ●        | ●         |
| S40(04-)  | 2008 | BCM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | PSM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | AEM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | KVM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | RDAR                     |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | CPM                      |                          | ●         | ●        | ●         |
| S40(04-)  | 2008 | AUD                      |                          | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------|--------------|-----------|----------|-----------|
| S40(04-) | 2008 | PAM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | SRS    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | DDM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | PDM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | AUU    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | HCM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | CCM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | PHM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | CEM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | DIM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | SWM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | TRM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | EPS    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | IAM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | ICM    |              | ●         | ●        | ●         |
| S40(04-) | 2008 | MMM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | DEM    | M66 AWD      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | D5244T9      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | D5244T8      | ●         | ●        | ●         |
| S40(04-) | 2007 | ADM    | D4204T       | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | D4204T       | ●         | ●        | ●         |
| S40(04-) | 2007 | ADM    | D4164T       | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | D4164T       | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B5254T3      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B5244S7      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B5244S5      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B5244S4      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B4204S3      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B4184S8      | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B4184S11     | ●         | ●        | ●         |
| S40(04-) | 2007 | ECM    | B4164S3      | ●         | ●        | ●         |
| S40(04-) | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| S40(04-) | 2007 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| S40(04-) | 2007 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| S40(04-) | 2007 | GPS    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | BCM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | PSM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | TMC    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | SWM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | KVM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | AEM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | PHM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | TRM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | CEM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | MMM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | RDAR   |              | ●         | ●        | ●         |
| S40(04-) | 2007 | CPM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | IAM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | AUD    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | PAM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | DDM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | PDM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | SRS    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | CCM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | DIM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | ICM    |              | ●         | ●        | ●         |
| S40(04-) | 2007 | EPS    |              | ●         | ●        | ●         |
| S40(04-) | 2006 | DEM    | M66 AWD      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | D5244T8      | ●         | ●        | ●         |
| S40(04-) | 2006 | ADM    | D4204T2      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | D4204T2      | ●         | ●        | ●         |
| S40(04-) | 2006 | ADM    | D4204T       | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | D4204T       | ●         | ●        | ●         |
| S40(04-) | 2006 | ADM    | D4164T       | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | D4164T       | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B5254T3      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B5244S7      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B5244S5      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B5244S4      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B4184S8      | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B4184S11     | ●         | ●        | ●         |
| S40(04-) | 2006 | ECM    | B4164S3      | ●         | ●        | ●         |
| S40(04-) | 2006 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| S40(04-) | 2006 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| S40(04-) | 2006 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| S40(04-) | 2006 | DIM    |              | ●         | ●        | ●         |
| S40(04-) | 2006 | GPS    |              | ●         | ●        | ●         |
| S40(04-) | 2006 | DDM    |              | ●         | ●        | ●         |
| S40(04-) | 2006 | PDM    |              | ●         | ●        | ●         |
| S40(04-) | 2006 | BCM    |              | ●         | ●        | ●         |
| S40(04-) | 2006 | PSM    |              | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System                     | Type                       | ECU Info. | Read DTC | Clear DTC |
|----------|------|----------------------------|----------------------------|-----------|----------|-----------|
| S40(04-) | 2006 | TMC                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | SWM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | KVM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | AEM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | ICM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | IAM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | PHM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | TRM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | PAM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | CEM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | MMM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | CPM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | CCM                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | AUD                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | SRS                        |                            | ●         | ●        | ●         |
| S40(04-) | 2006 | EPS                        |                            | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| S40(-04) | 2004 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2004 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2004 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| S40(-04) | 2004 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(-04) | 2004 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| S40(-04) | 2004 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| S40(-04) | 2004 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| S40(-04) | 2004 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(-04) | 2004 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(-04) | 2004 | CPM                        | CPM                        | ●         | ●        | ●         |
| S40(-04) | 2004 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Petrol                     | B4204T5                    | ●         | ●        | ●         |
| S40(-04) | 2003 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2003 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2003 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| S40(-04) | 2003 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(-04) | 2003 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| S40(-04) | 2003 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| S40(-04) | 2003 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| S40(-04) | 2003 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(-04) | 2003 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(-04) | 2003 | CPM                        | CPM                        | ●         | ●        | ●         |
| S40(-04) | 2003 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Petrol                     | B4204T5                    | ●         | ●        | ●         |
| S40(-04) | 2002 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2002 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2002 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| S40(-04) | 2002 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(-04) | 2002 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| S40(-04) | 2002 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| S40(-04) | 2002 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| S40(-04) | 2002 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(-04) | 2002 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(-04) | 2002 | CPM                        | CPM                        | ●         | ●        | ●         |
| S40(-04) | 2002 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |





# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System                     | Type                       | ECU Info. | Read DTC | Clear DTC |
|----------|------|----------------------------|----------------------------|-----------|----------|-----------|
| S40(-04) | 2001 | Petrol                     | B4184SM                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Petrol                     | B4204T5                    | ●         | ●        | ●         |
| S40(-04) | 2001 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2001 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2001 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| S40(-04) | 2001 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(-04) | 2001 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| S40(-04) | 2001 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| S40(-04) | 2001 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| S40(-04) | 2001 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(-04) | 2001 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(-04) | 2001 | CPM                        | CPM                        | ●         | ●        | ●         |
| S40(-04) | 2001 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4184SM                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4194T2                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Petrol                     | B4204T2                    | ●         | ●        | ●         |
| S40(-04) | 2000 | Diesel                     | D4192T2(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 2000 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| S40(-04) | 2000 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(-04) | 2000 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| S40(-04) | 2000 | TCM                        | AW50-42                    | ●         | ●        | ●         |
| S40(-04) | 2000 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(-04) | 2000 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(-04) | 2000 | CPM                        | CPM                        | ●         | ●        | ●         |
| S40(-04) | 2000 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(-04) | 1999 | Petrol                     | B4164S(Anti-spin system)   | ●         | ●        | ●         |
| S40(-04) | 1999 | Petrol                     | B4184S(Anti-spin system)   | ●         | ●        | ●         |
| S40(-04) | 1999 | Petrol                     | B4184SM                    | ●         | ●        | ●         |
| S40(-04) | 1999 | Petrol                     | B4194T                     | ●         | ●        | ●         |
| S40(-04) | 1999 | Petrol                     | B4204S(Anti-spin system)   | ●         | ●        | ●         |
| S40(-04) | 1999 | Petrol                     | B4204T                     | ●         | ●        | ●         |
| S40(-04) | 1999 | Diesel                     | D4192T(Anti-spin system)   | ●         | ●        | ●         |
| S40(-04) | 1999 | Diesel                     | D4192T2(Anti-spin system)  | ●         | ●        | ●         |
| S40(-04) | 1999 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| S40(-04) | 1999 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(-04) | 1999 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| S40(-04) | 1999 | TCM                        | AW50-42                    | ●         | ●        | ●         |
| S40(-04) | 1999 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(-04) | 1999 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(-04) | 1999 | CPM                        | CPM                        | ●         | ●        | ●         |
| S40(-04) | 1999 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(04-) | 2005 | CEM                        | CEM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | Petrol                     | B4164S3                    | ●         | ●        | ●         |
| S40(04-) | 2005 | Petrol                     | B4184S11                   | ●         | ●        | ●         |
| S40(04-) | 2005 | Petrol                     | B5244S4                    | ●         | ●        | ●         |
| S40(04-) | 2005 | Petrol                     | B5244S5                    | ●         | ●        | ●         |
| S40(04-) | 2005 | Petrol                     | B5254T3                    | ●         | ●        | ●         |
| S40(04-) | 2005 | Diesel                     | D4164T                     | ●         | ●        | ●         |
| S40(04-) | 2005 | Diesel                     | D4204T                     | ●         | ●        | ●         |
| S40(04-) | 2005 | Diesel                     | D4204T2                    | ●         | ●        | ●         |
| S40(04-) | 2005 | AFM                        | AFM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | AEM                        | AEM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | AUD                        | AUD                        | ●         | ●        | ●         |
| S40(04-) | 2005 | DEM                        | DEM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | DIM                        | DIM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | ICM                        | ICM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | IAM                        | IAM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | KVM                        | KVM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | MPM                        | MPM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | MMM                        | MMM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | PAM                        | PAM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | PHM                        | PHM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | SWM                        | SWM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | SUB                        | SUB                        | ●         | ●        | ●         |
| S40(04-) | 2005 | TMC                        | TMC                        | ●         | ●        | ●         |
| S40(04-) | 2005 | TCM                        | AW50/51AWD                 | ●         | ●        | ●         |
| S40(04-) | 2005 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| S40(04-) | 2005 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| S40(04-) | 2005 | EPS                        | EPS                        | ●         | ●        | ●         |
| S40(04-) | 2005 | CCM                        | CCM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | DDM                        | DDM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | PDM                        | PDM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | PSM                        | PSM                        | ●         | ●        | ●         |
| S40(04-) | 2005 | SRS                        | SRS                        | ●         | ●        | ●         |
| S40(04-) | 2005 | TRM                        | TRM                        | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System  | Type         | ECU Info. | Read DTC | Clear DTC |
|----------|------|---------|--------------|-----------|----------|-----------|
| S40(04-) | 2005 | GPS     | GPS          | ●         | ●        | ●         |
| S40(04-) | 2004 | CEM     | CEM          | ●         | ●        | ●         |
| S40(04-) | 2004 | EPS     | EPS          | ●         | ●        | ●         |
| S40(04-) | 2004 | Petrol  | B5244S4      | ●         | ●        | ●         |
| S40(04-) | 2004 | Petrol  | B5244S5      | ●         | ●        | ●         |
| S40(04-) | 2004 | Petrol  | B5254T3      | ●         | ●        | ●         |
| S40(04-) | 2004 | Diesel  | D4204T       | ●         | ●        | ●         |
| S40(04-) | 2004 | Diesel  | D4204T2      | ●         | ●        | ●         |
| S40(04-) | 2004 | AFM     | AFM          | ●         | ●        | ●         |
| S40(04-) | 2004 | AEM     | AEM          | ●         | ●        | ●         |
| S40(04-) | 2004 | AUD     | AUD          | ●         | ●        | ●         |
| S40(04-) | 2004 | DIM     | DIM          | ●         | ●        | ●         |
| S40(04-) | 2004 | ICM     | ICM          | ●         | ●        | ●         |
| S40(04-) | 2004 | MPM     | MPM          | ●         | ●        | ●         |
| S40(04-) | 2004 | MMM     | MMM          | ●         | ●        | ●         |
| S40(04-) | 2004 | PHM     | PHM          | ●         | ●        | ●         |
| S40(04-) | 2004 | SWM     | SWM          | ●         | ●        | ●         |
| S40(04-) | 2004 | SUB     | SUB          | ●         | ●        | ●         |
| S40(04-) | 2004 | TMC     | TMC          | ●         | ●        | ●         |
| S40(04-) | 2004 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S40(04-) | 2004 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S40(04-) | 2004 | CCM     | CCM          | ●         | ●        | ●         |
| S40(04-) | 2004 | DDM     | DDM          | ●         | ●        | ●         |
| S40(04-) | 2004 | PDM     | PDM          | ●         | ●        | ●         |
| S40(04-) | 2004 | PSM     | PSM          | ●         | ●        | ●         |
| S40(04-) | 2004 | SRS     | SRS          | ●         | ●        | ●         |
| S40(04-) | 2004 | TRM     | TRM          | ●         | ●        | ●         |
| S40(04-) | 2004 | GPS     | GPS          | ●         | ●        | ●         |
| S60      | 2005 | CEM     | CEM          | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5244S       | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5244SG      | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5244T4      | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5244T5      | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5254T2      | ●         | ●        | ●         |
| S60      | 2005 | Petrol  | B5254T4      | ●         | ●        | ●         |
| S60      | 2005 | Diesel  | D5244T       | ●         | ●        | ●         |
| S60      | 2005 | Diesel  | D5244T2      | ●         | ●        | ●         |
| S60      | 2005 | Diesel  | D5244T3      | ●         | ●        | ●         |
| S60      | 2005 | AEM     | AEM          | ●         | ●        | ●         |
| S60      | 2005 | AUM     | AUM          | ●         | ●        | ●         |
| S60      | 2005 | DIM     | DIM          | ●         | ●        | ●         |
| S60      | 2005 | PHM     | PHM          | ●         | ●        | ●         |
| S60      | 2005 | REM     | REM          | ●         | ●        | ●         |
| S60      | 2005 | RTI     | RTI          | ●         | ●        | ●         |
| S60      | 2005 | UEM     | UEM          | ●         | ●        | ●         |
| S60      | 2005 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| S60      | 2005 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60      | 2005 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S60      | 2005 | SAS     | SAS          | ●         | ●        | ●         |
| S60      | 2005 | SUM     | SUM          | ●         | ●        | ●         |
| S60      | 2005 | CCM     | CCM          | ●         | ●        | ●         |
| S60      | 2005 | DDM     | DDM          | ●         | ●        | ●         |
| S60      | 2005 | PDM     | PDM          | ●         | ●        | ●         |
| S60      | 2005 | PSM     | PSM          | ●         | ●        | ●         |
| S60      | 2005 | SRS     | SRS          | ●         | ●        | ●         |
| S60      | 2005 | DEM     | DEM          | ●         | ●        | ●         |
| S60      | 2005 | DEM     | DEM          | ●         | ●        | ●         |
| S60      | 2004 | CEM     | CEM          | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5234T3      | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5234T7      | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5244S       | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5244SG      | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5254T2      | ●         | ●        | ●         |
| S60      | 2004 | Petrol  | B5254T4      | ●         | ●        | ●         |
| S60      | 2004 | Diesel  | D5244T       | ●         | ●        | ●         |
| S60      | 2004 | Diesel  | D5244T2      | ●         | ●        | ●         |
| S60      | 2004 | AEM     | AEM          | ●         | ●        | ●         |
| S60      | 2004 | AUM     | AUM          | ●         | ●        | ●         |
| S60      | 2004 | DIM     | DIM          | ●         | ●        | ●         |
| S60      | 2004 | PHM     | PHM          | ●         | ●        | ●         |
| S60      | 2004 | REM     | REM          | ●         | ●        | ●         |
| S60      | 2004 | RTI     | RTI          | ●         | ●        | ●         |
| S60      | 2004 | SWM     | SWM          | ●         | ●        | ●         |
| S60      | 2004 | UEM     | UEM          | ●         | ●        | ●         |
| S60      | 2004 | TCM     | AW50/51AWD   | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System  | Type         | ECU Info. | Read DTC | Clear DTC |
|---------|------|---------|--------------|-----------|----------|-----------|
| S60     | 2004 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2004 | DEM     | DEM          | ●         | ●        | ●         |
| S60     | 2004 | DEM     | DEM          | ●         | ●        | ●         |
| S60     | 2004 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S60     | 2004 | SAS     | SAS          | ●         | ●        | ●         |
| S60     | 2004 | SUM     | SUM          | ●         | ●        | ●         |
| S60     | 2004 | CCM     | CCM          | ●         | ●        | ●         |
| S60     | 2004 | DDM     | DDM          | ●         | ●        | ●         |
| S60     | 2004 | PDM     | PDM          | ●         | ●        | ●         |
| S60     | 2004 | PSM     | PSM          | ●         | ●        | ●         |
| S60     | 2004 | SRS     | SRS          | ●         | ●        | ●         |
| S60     | 2003 | CEM     | CEM          | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5234T3      | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5234T7      | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5244S       | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5244SG      | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5244T3      | ●         | ●        | ●         |
| S60     | 2003 | Petrol  | B5254T2      | ●         | ●        | ●         |
| S60     | 2003 | Diesel  | D5244T       | ●         | ●        | ●         |
| S60     | 2003 | Diesel  | D5244T2      | ●         | ●        | ●         |
| S60     | 2003 | AEM     | AEM          | ●         | ●        | ●         |
| S60     | 2003 | AUM     | AUM          | ●         | ●        | ●         |
| S60     | 2003 | DEM     | DEM          | ●         | ●        | ●         |
| S60     | 2003 | DIM     | DIM          | ●         | ●        | ●         |
| S60     | 2003 | PHM     | PHM          | ●         | ●        | ●         |
| S60     | 2003 | REM     | REM          | ●         | ●        | ●         |
| S60     | 2003 | RTI     | RTI          | ●         | ●        | ●         |
| S60     | 2003 | SWM     | SWM          | ●         | ●        | ●         |
| S60     | 2003 | UEM     | UEM          | ●         | ●        | ●         |
| S60     | 2003 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| S60     | 2003 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2003 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S60     | 2003 | SAS     | SAS          | ●         | ●        | ●         |
| S60     | 2003 | CCM     | CCM          | ●         | ●        | ●         |
| S60     | 2003 | DDM     | DDM          | ●         | ●        | ●         |
| S60     | 2003 | PDM     | PDM          | ●         | ●        | ●         |
| S60     | 2003 | PSM     | PSM          | ●         | ●        | ●         |
| S60     | 2003 | SRS     | SRS          | ●         | ●        | ●         |
| S60     | 2002 | CEM     | CEM          | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5234T3      | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5234T7      | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5244S       | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5244SG      | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| S60     | 2002 | Petrol  | B5244T3      | ●         | ●        | ●         |
| S60     | 2002 | Diesel  | D5244T       | ●         | ●        | ●         |
| S60     | 2002 | Diesel  | D5244T2      | ●         | ●        | ●         |
| S60     | 2002 | AEM     | AEM          | ●         | ●        | ●         |
| S60     | 2002 | AUM     | AUM          | ●         | ●        | ●         |
| S60     | 2002 | DIM     | DIM          | ●         | ●        | ●         |
| S60     | 2002 | PHM     | PHM          | ●         | ●        | ●         |
| S60     | 2002 | REM     | REM          | ●         | ●        | ●         |
| S60     | 2002 | RTI     | RTI          | ●         | ●        | ●         |
| S60     | 2002 | SWM     | SWM          | ●         | ●        | ●         |
| S60     | 2002 | UEM     | UEM          | ●         | ●        | ●         |
| S60     | 2002 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| S60     | 2002 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2002 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S60     | 2002 | SAS     | SAS          | ●         | ●        | ●         |
| S60     | 2002 | CCM     | CCM          | ●         | ●        | ●         |
| S60     | 2002 | DDM     | DDM          | ●         | ●        | ●         |
| S60     | 2002 | PDM     | PDM          | ●         | ●        | ●         |
| S60     | 2002 | PSM     | PSM          | ●         | ●        | ●         |
| S60     | 2002 | SRS     | SRS          | ●         | ●        | ●         |
| S60     | 2001 | CEM     | CEM          | ●         | ●        | ●         |
| S60     | 2001 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S60     | 2001 | Petrol  | B5234T3      | ●         | ●        | ●         |
| S60     | 2001 | Petrol  | B5234T7      | ●         | ●        | ●         |
| S60     | 2001 | Petrol  | B5244S       | ●         | ●        | ●         |
| S60     | 2001 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S60     | 2001 | Petrol  | B5244T3      | ●         | ●        | ●         |
| S60     | 2001 | Diesel  | D5244T       | ●         | ●        | ●         |
| S60     | 2001 | AEM     | AEM          | ●         | ●        | ●         |
| S60     | 2001 | AUM     | AUM          | ●         | ●        | ●         |
| S60     | 2001 | DIM     | DIM          | ●         | ●        | ●         |
| S60     | 2001 | PHM     | PHM          | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System  | Type         | ECU Info. | Read DTC | Clear DTC |
|---------|------|---------|--------------|-----------|----------|-----------|
| S60     | 2001 | REM     | REM          | ●         | ●        | ●         |
| S60     | 2001 | RTI     | RTI          | ●         | ●        | ●         |
| S60     | 2001 | SWM     | SWM          | ●         | ●        | ●         |
| S60     | 2001 | UEM     | UEM          | ●         | ●        | ●         |
| S60     | 2001 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2001 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S60     | 2001 | SAS     | SAS          | ●         | ●        | ●         |
| S60     | 2001 | CCM     | CCM          | ●         | ●        | ●         |
| S60     | 2001 | DDM     | DDM          | ●         | ●        | ●         |
| S60     | 2001 | PDM     | PDM          | ●         | ●        | ●         |
| S60     | 2001 | PSM     | PSM          | ●         | ●        | ●         |
| S60     | 2001 | SRS     | SRS          | ●         | ●        | ●         |
| S60     | 2009 | TCM     | TF-80SC      | ●         | ●        | ●         |
| S60     | 2009 | DEM     | M66 AWD      | ●         | ●        | ●         |
| S60     | 2009 | DEM     | M58          | ●         | ●        | ●         |
| S60     | 2009 | ECM     | D5244T7      | ●         | ●        | ●         |
| S60     | 2009 | ECM     | D5244T5      | ●         | ●        | ●         |
| S60     | 2009 | ECM     | D5244T4      | ●         | ●        | ●         |
| S60     | 2009 | ECM     | B5254T2      | ●         | ●        | ●         |
| S60     | 2009 | ECM     | B5244T5      | ●         | ●        | ●         |
| S60     | 2009 | ECM     | B5244S2      | ●         | ●        | ●         |
| S60     | 2009 | ECM     | B5244S       | ●         | ●        | ●         |
| S60     | 2009 | ECM     | B5204T5      | ●         | ●        | ●         |
| S60     | 2009 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2009 | DEM     | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2009 | TCM     | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2009 | AUM     |              | ●         | ●        | ●         |
| S60     | 2009 | BCM     |              | ●         | ●        | ●         |
| S60     | 2009 | SRS     |              | ●         | ●        | ●         |
| S60     | 2009 | PSM     |              | ●         | ●        | ●         |
| S60     | 2009 | DDM     |              | ●         | ●        | ●         |
| S60     | 2009 | PDM     |              | ●         | ●        | ●         |
| S60     | 2009 | SUM     |              | ●         | ●        | ●         |
| S60     | 2009 | AEM     |              | ●         | ●        | ●         |
| S60     | 2009 | REM     |              | ●         | ●        | ●         |
| S60     | 2009 | CPM     |              | ●         | ○        | ○         |
| S60     | 2009 | RTI     |              | ●         | ●        | ●         |
| S60     | 2009 | SAS     |              | ●         | ●        | ●         |
| S60     | 2009 | HCM     |              | ●         | ●        | ●         |
| S60     | 2009 | CCM     |              | ●         | ●        | ●         |
| S60     | 2009 | DIM     |              | ●         | ●        | ●         |
| S60     | 2009 | UEM     |              | ●         | ●        | ●         |
| S60     | 2009 | PHM     |              | ●         | ●        | ●         |
| S60     | 2009 | CEM     |              | ●         | ●        | ●         |
| S60     | 2008 | TCM     | TF-80SC      | ●         | ●        | ●         |
| S60     | 2008 | DEM     | M66 AWD      | ●         | ●        | ●         |
| S60     | 2008 | DEM     | M58          | ●         | ●        | ●         |
| S60     | 2008 | ECM     | D5244T7      | ●         | ●        | ●         |
| S60     | 2008 | ECM     | D5244T5      | ●         | ●        | ●         |
| S60     | 2008 | ECM     | D5244T4      | ●         | ●        | ●         |
| S60     | 2008 | ECM     | B5254T2      | ●         | ●        | ●         |
| S60     | 2008 | ECM     | B5244T5      | ●         | ●        | ●         |
| S60     | 2008 | ETM     | B5244SG      | ●         | ○        | ○         |
| S60     | 2008 | ECM     | B5244SG      | ●         | ●        | ●         |
| S60     | 2008 | ECM     | B5244S2      | ●         | ●        | ●         |
| S60     | 2008 | ECM     | B5244S       | ●         | ●        | ●         |
| S60     | 2008 | ECM     | B5204T5      | ●         | ●        | ●         |
| S60     | 2008 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2008 | DEM     | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2008 | TCM     | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2008 | AUM     |              | ●         | ●        | ●         |
| S60     | 2008 | BCM     |              | ●         | ●        | ●         |
| S60     | 2008 | SRS     |              | ●         | ●        | ●         |
| S60     | 2008 | PSM     |              | ●         | ●        | ●         |
| S60     | 2008 | DDM     |              | ●         | ●        | ●         |
| S60     | 2008 | PDM     |              | ●         | ●        | ●         |
| S60     | 2008 | SUM     |              | ●         | ●        | ●         |
| S60     | 2008 | AEM     |              | ●         | ●        | ●         |
| S60     | 2008 | PHM     |              | ●         | ●        | ●         |
| S60     | 2008 | REM     |              | ●         | ●        | ●         |
| S60     | 2008 | CPM     |              | ●         | ○        | ○         |
| S60     | 2008 | CEM     |              | ●         | ●        | ●         |
| S60     | 2008 | HCM     |              | ●         | ●        | ●         |
| S60     | 2008 | RTI     |              | ●         | ●        | ●         |
| S60     | 2008 | SAS     |              | ●         | ●        | ●         |
| S60     | 2008 | CCM     |              | ●         | ●        | ●         |
| S60     | 2008 | DIM     |              | ●         | ●        | ●         |
| S60     | 2008 | UEM     |              | ●         | ●        | ●         |
| S60     | 2007 | DEM     | TF-80SC AWD  | ●         | ●        | ●         |
| S60     | 2007 | DEM     | M66 AWD      | ●         | ●        | ●         |
| S60     | 2007 | DEM     | M58          | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------|--------------|-----------|----------|-----------|
| S60     | 2007 | ECM    | D5244T7      | ●         | ●        | ●         |
| S60     | 2007 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S60     | 2007 | ECM    | D5244T5      | ●         | ●        | ●         |
| S60     | 2007 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S60     | 2007 | ECM    | D5244T4      | ●         | ●        | ●         |
| S60     | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| S60     | 2007 | ECM    | B5254T4      | ●         | ●        | ●         |
| S60     | 2007 | ECM    | B5254T2      | ●         | ●        | ●         |
| S60     | 2007 | ECM    | B5244T5      | ●         | ●        | ●         |
| S60     | 2007 | ETM    | B5244SG      | ●         | ○        | ○         |
| S60     | 2007 | ECM    | B5244SG      | ●         | ●        | ●         |
| S60     | 2007 | ECM    | B5244S2      | ●         | ●        | ●         |
| S60     | 2007 | ECM    | B5244S       | ●         | ●        | ●         |
| S60     | 2007 | ECM    | B5204T5      | ●         | ●        | ●         |
| S60     | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2007 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2007 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2007 | AUM    |              | ●         | ●        | ●         |
| S60     | 2007 | BCM    |              | ●         | ●        | ●         |
| S60     | 2007 | SRS    |              | ●         | ●        | ●         |
| S60     | 2007 | PSM    |              | ●         | ●        | ●         |
| S60     | 2007 | DDM    |              | ●         | ●        | ●         |
| S60     | 2007 | PDM    |              | ●         | ●        | ●         |
| S60     | 2007 | SUM    |              | ●         | ●        | ●         |
| S60     | 2007 | AEM    |              | ●         | ●        | ●         |
| S60     | 2007 | PHM    |              | ●         | ●        | ●         |
| S60     | 2007 | REM    |              | ●         | ●        | ●         |
| S60     | 2007 | CPM    |              | ●         | ○        | ○         |
| S60     | 2007 | CEM    |              | ●         | ●        | ●         |
| S60     | 2007 | HCM    |              | ●         | ●        | ●         |
| S60     | 2007 | CCM    |              | ●         | ●        | ●         |
| S60     | 2007 | RTI    |              | ●         | ●        | ●         |
| S60     | 2007 | SAS    |              | ●         | ●        | ●         |
| S60     | 2007 | DIM    |              | ●         | ●        | ●         |
| S60     | 2007 | UEM    |              | ●         | ●        | ●         |
| S60     | 2006 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| S60     | 2006 | DEM    | M66 AWD      | ●         | ●        | ●         |
| S60     | 2006 | DEM    | M58          | ●         | ●        | ●         |
| S60     | 2006 | ECM    | D5244T7      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | D5244T6      | ●         | ●        | ●         |
| S60     | 2006 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | D5244T5      | ●         | ●        | ●         |
| S60     | 2006 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | D5244T4      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | D5244T2      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | D5244T       | ●         | ●        | ●         |
| S60     | 2006 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5254T4      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5254T2      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5244T5      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5244T4      | ●         | ●        | ●         |
| S60     | 2006 | ETM    | B5244SG      | ●         | ○        | ○         |
| S60     | 2006 | ECM    | B5244SG      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5244S6      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5244S2      | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5244S       | ●         | ●        | ●         |
| S60     | 2006 | ECM    | B5204T5      | ●         | ●        | ●         |
| S60     | 2006 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| S60     | 2006 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2006 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| S60     | 2006 | REM    |              | ●         | ●        | ●         |
| S60     | 2006 | AUM    |              | ●         | ●        | ●         |
| S60     | 2006 | BCM    |              | ●         | ●        | ●         |
| S60     | 2006 | SRS    |              | ●         | ●        | ●         |
| S60     | 2006 | PSM    |              | ●         | ●        | ●         |
| S60     | 2006 | DDM    |              | ●         | ●        | ●         |
| S60     | 2006 | PDM    |              | ●         | ●        | ●         |
| S60     | 2006 | SUM    |              | ●         | ●        | ●         |
| S60     | 2006 | AEM    |              | ●         | ●        | ●         |
| S60     | 2006 | PHM    |              | ●         | ●        | ●         |
| S60     | 2006 | DIM    |              | ●         | ●        | ●         |
| S60     | 2006 | CPM    |              | ●         | ○        | ○         |
| S60     | 2006 | UEM    |              | ●         | ●        | ●         |
| S60     | 2006 | CEM    |              | ●         | ●        | ●         |
| S60     | 2006 | CCM    |              | ●         | ●        | ●         |
| S60     | 2006 | RTI    |              | ●         | ●        | ●         |
| S60     | 2006 | SAS    |              | ●         | ●        | ●         |
| S70     | 2000 | Petrol | B5204T3      | ●         | ●        | ●         |
| S70     | 2000 | Petrol | B5204T4      | ●         | ●        | ●         |
| S70     | 2000 | Petrol | B5234T3      | ●         | ●        | ●         |
| S70     | 2000 | Petrol | B5234T7      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System                   | Type                     | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------------------------|--------------------------|-----------|----------|-----------|
| S70     | 2000 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| S70     | 2000 | Petrol                   | B5244S2                  | ●         | ●        | ●         |
| S70     | 2000 | Petrol                   | B5244SG                  | ●         | ●        | ●         |
| S70     | 2000 | Petrol                   | B5244SG2                 | ●         | ●        | ●         |
| S70     | 2000 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| S70     | 2000 | Diesel                   | D5252T MSA 15.8          | ●         | ○        | ○         |
| S70     | 2000 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| S70     | 2000 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| S70     | 2000 | RTI                      | RTI                      | ●         | ●        | ●         |
| S70     | 2000 | TCM                      | AW42AWD                  | ●         | ●        | ●         |
| S70     | 2000 | TCM                      | AW50/51AWD               | ●         | ●        | ●         |
| S70     | 2000 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| S70     | 2000 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| S70     | 2000 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| S70     | 2000 | CCM                      | CCM                      | ●         | ●        | ●         |
| S70     | 2000 | CPM                      | CPM                      | ●         | ●        | ●         |
| S70     | 2000 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| S70     | 2000 | Power seat module, right | Power seat module, Right | ●         | ●        | ●         |
| S70     | 2000 | SRS                      | SRS                      | ●         | ●        | ●         |
| S70     | 1999 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| S70     | 1999 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| S70     | 1999 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| S70     | 1999 | Petrol                   | B5234T7                  | ●         | ●        | ●         |
| S70     | 1999 | Petrol                   | B5254S DENSO             | ●         | ●        | ●         |
| S70     | 1999 | Petrol                   | B5254T                   | ●         | ●        | ●         |
| S70     | 1999 | Diesel                   | D5252T MSA 15.8          | ●         | ○        | ○         |
| S70     | 1999 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| S70     | 1999 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| S70     | 1999 | RTI                      | RTI                      | ●         | ●        | ●         |
| S70     | 1999 | TCM                      | AW42AWD                  | ●         | ●        | ●         |
| S70     | 1999 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| S70     | 1999 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| S70     | 1999 | CCM                      | CCM                      | ●         | ●        | ●         |
| S70     | 1999 | CPM                      | CPM                      | ●         | ●        | ●         |
| S70     | 1999 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| S70     | 1999 | Power seat module, right | Power seat module, Right | ●         | ●        | ●         |
| S70     | 1999 | SRS                      | SRS                      | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5204T5                  | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5244S2                  | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5244SG                  | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5244SG2                 | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5244T4                  | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B5254T2                  | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B6294S2                  | ●         | ●        | ●         |
| S80     | 2005 | Petrol                   | B6294T                   | ●         | ●        | ●         |
| S80     | 2005 | Diesel                   | D5244T                   | ●         | ●        | ●         |
| S80     | 2005 | Diesel                   | D5244T2                  | ●         | ●        | ●         |
| S80     | 2005 | AEM                      | AEM                      | ●         | ●        | ●         |
| S80     | 2005 | AUM                      | AUM                      | ●         | ●        | ●         |
| S80     | 2005 | DIM                      | DIM                      | ●         | ●        | ●         |
| S80     | 2005 | PHM                      | PHM                      | ●         | ●        | ●         |
| S80     | 2005 | REM                      | REM                      | ●         | ●        | ●         |
| S80     | 2005 | RTI                      | RTI                      | ●         | ●        | ●         |
| S80     | 2005 | UEM                      | UEM                      | ●         | ●        | ●         |
| S80     | 2005 | TCM                      | 4T65EV                   | ●         | ●        | ●         |
| S80     | 2005 | TCM                      | 4T65EV-GT                | ●         | ●        | ●         |
| S80     | 2005 | TCM                      | AW50/51AWD               | ●         | ●        | ●         |
| S80     | 2005 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| S80     | 2005 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| S80     | 2005 | SAS                      | SAS                      | ●         | ●        | ●         |
| S80     | 2005 | SUM                      | SUM                      | ●         | ●        | ●         |
| S80     | 2005 | CCM                      | CCM                      | ●         | ●        | ●         |
| S80     | 2005 | DDM                      | DDM                      | ●         | ●        | ●         |
| S80     | 2005 | PDM                      | PDM                      | ●         | ●        | ●         |
| S80     | 2005 | PSM                      | PSM                      | ●         | ●        | ●         |
| S80     | 2005 | SRS                      | SRS                      | ●         | ●        | ●         |
| S80     | 2005 | CEM                      | CEM                      | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5204T5                  | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5234T7                  | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5244S2                  | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5244SG                  | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5244SG2                 | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B5254T2                  | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B6294S2                  | ●         | ●        | ●         |
| S80     | 2004 | Petrol                   | B6294T                   | ●         | ●        | ●         |
| S80     | 2004 | Diesel                   | D5244T                   | ●         | ●        | ●         |
| S80     | 2004 | Diesel                   | D5244T2                  | ●         | ●        | ●         |
| S80     | 2004 | AEM                      | AEM                      | ●         | ●        | ●         |
| S80     | 2004 | AUM                      | AUM                      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

| NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a |      |         |              |           |          |           |
|---|------|---------|--------------|-----------|----------|-----------|
| Vehicle   | Year | System  | Type         | ECU Info. | Read DTC | Clear DTC |
| S80   | 2004 | CEM     | CEM          | ●         | ●        | ●         |
| S80   | 2004 | DIM     | DIM          | ●         | ●        | ●         |
| S80   | 2004 | PHM     | PHM          | ●         | ●        | ●         |
| S80   | 2004 | REM     | REM          | ●         | ●        | ●         |
| S80   | 2004 | RTI     | RTI          | ●         | ●        | ●         |
| S80   | 2004 | SWM     | SWM          | ●         | ●        | ●         |
| S80   | 2004 | UEM     | UEM          | ●         | ●        | ●         |
| S80   | 2004 | TCM     | 4T65EV       | ●         | ●        | ●         |
| S80   | 2004 | TCM     | 4T65EV-GT    | ●         | ●        | ●         |
| S80   | 2004 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| S80   | 2004 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S80   | 2004 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S80   | 2004 | SAS     | SAS          | ●         | ●        | ●         |
| S80   | 2004 | SUM     | SUM          | ●         | ●        | ●         |
| S80   | 2004 | CCM     | CCM          | ●         | ●        | ●         |
| S80   | 2004 | DDM     | DDM          | ●         | ●        | ●         |
| S80   | 2004 | PDM     | PDM          | ●         | ●        | ●         |
| S80   | 2004 | PSM     | PSM          | ●         | ●        | ●         |
| S80   | 2004 | SRS     | SRS          | ●         | ●        | ●         |
| S80   | 2003 | CEM     | CEM          | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5234T7      | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5244S       | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5244SG      | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B5244T3      | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B6294S2      | ●         | ●        | ●         |
| S80   | 2003 | Petrol  | B6294T       | ●         | ●        | ●         |
| S80   | 2003 | Diesel  | D5244T       | ●         | ●        | ●         |
| S80   | 2003 | Diesel  | D5244T2      | ●         | ●        | ●         |
| S80   | 2003 | AEM     | AEM          | ●         | ●        | ●         |
| S80   | 2003 | AUM     | AUM          | ●         | ●        | ●         |
| S80   | 2003 | DIM     | DIM          | ●         | ●        | ●         |
| S80   | 2003 | PHM     | PHM          | ●         | ●        | ●         |
| S80   | 2003 | REM     | REM          | ●         | ●        | ●         |
| S80   | 2003 | RTI     | RTI          | ●         | ●        | ●         |
| S80   | 2003 | SWM     | SWM          | ●         | ●        | ●         |
| S80   | 2003 | UEM     | UEM          | ●         | ●        | ●         |
| S80   | 2003 | TCM     | 4T65EV       | ●         | ●        | ●         |
| S80   | 2003 | TCM     | 4T65EV-GT    | ●         | ●        | ●         |
| S80   | 2003 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| S80   | 2003 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S80   | 2003 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S80   | 2003 | SAS     | SAS          | ●         | ●        | ●         |
| S80   | 2003 | CCM     | CCM          | ●         | ●        | ●         |
| S80   | 2003 | DDM     | DDM          | ●         | ●        | ●         |
| S80   | 2003 | PDM     | PDM          | ●         | ●        | ●         |
| S80   | 2003 | PSM     | PSM          | ●         | ●        | ●         |
| S80   | 2003 | SRS     | SRS          | ●         | ●        | ●         |
| S80   | 2002 | CEM     | CEM          | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5204T5      | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5234T7      | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5244S       | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5244S2      | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5244SG      | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B5244T3      | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B6294S2      | ●         | ●        | ●         |
| S80   | 2002 | Petrol  | B6294T       | ●         | ●        | ●         |
| S80   | 2002 | Diesel  | D5244T       | ●         | ●        | ●         |
| S80   | 2002 | Diesel  | D5244T2      | ●         | ●        | ●         |
| S80   | 2002 | AEM     | AEM          | ●         | ●        | ●         |
| S80   | 2002 | AUM     | AUM          | ●         | ●        | ●         |
| S80   | 2002 | DIM     | DIM          | ●         | ●        | ●         |
| S80   | 2002 | PHM     | PHM          | ●         | ●        | ●         |
| S80   | 2002 | REM     | REM          | ●         | ●        | ●         |
| S80   | 2002 | RTI     | RTI          | ●         | ●        | ●         |
| S80   | 2002 | SWM     | SWM          | ●         | ●        | ●         |
| S80   | 2002 | UEM     | UEM          | ●         | ●        | ●         |
| S80   | 2002 | TCM     | 4T65EV       | ●         | ●        | ●         |
| S80   | 2002 | TCM     | 4T65EV-GT    | ●         | ●        | ●         |
| S80   | 2002 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| S80   | 2002 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| S80   | 2002 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| S80   | 2002 | SAS     | SAS          | ●         | ●        | ●         |
| S80   | 2002 | CCM     | CCM          | ●         | ●        | ●         |
| S80   | 2002 | DDM     | DDM          | ●         | ●        | ●         |
| S80   | 2002 | PDM     | PDM          | ●         | ●        | ●         |
| S80   | 2002 | PSM     | PSM          | ●         | ●        | ●         |
| S80   | 2002 | SRS     | SRS          | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

| NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a |      |         |                 |           |          |           |
|---|------|---------|-----------------|-----------|----------|-----------|
| Vehicle   | Year | System  | Type            | ECU Info. | Read DTC | Clear DTC |
| S80   | 2001 | CEM     | CEM             | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B5204T5         | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B5234T7         | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B5244S          | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B5244S2         | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B5244SG         | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B5244T3         | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B6284T          | ●         | ●        | ●         |
| S80   | 2001 | Petrol  | B6294S          | ●         | ●        | ●         |
| S80   | 2001 | Diesel  | D5244T          | ●         | ●        | ●         |
| S80   | 2001 | Diesel  | D5252T MSA 15.8 | ●         | ○        | ○         |
| S80   | 2001 | AEM     | AEM             | ●         | ●        | ●         |
| S80   | 2001 | AUM     | AUM             | ●         | ●        | ●         |
| S80   | 2001 | DIM     | DIM             | ●         | ●        | ●         |
| S80   | 2001 | PHM     | PHM             | ●         | ●        | ●         |
| S80   | 2001 | REM     | REM             | ●         | ●        | ●         |
| S80   | 2001 | RTI     | RTI             | ●         | ●        | ●         |
| S80   | 2001 | SWM     | SWM             | ●         | ●        | ●         |
| S80   | 2001 | UEM     | UEM             | ●         | ●        | ●         |
| S80   | 2001 | TCM     | 4T65EV          | ●         | ●        | ●         |
| S80   | 2001 | TCM     | 4T65EV-GT       | ●         | ●        | ●         |
| S80   | 2001 | TCM     | AW50/51AWD      | ●         | ●        | ●         |
| S80   | 2001 | TCM     | AW50-42         | ●         | ●        | ●         |
| S80   | 2001 | TCM     | AW55-50/51SN    | ●         | ●        | ●         |
| S80   | 2001 | ABS/BCM | ABS/BCM         | ●         | ●        | ●         |
| S80   | 2001 | SAS     | SAS             | ●         | ●        | ●         |
| S80   | 2001 | CCM     | CCM             | ●         | ●        | ●         |
| S80   | 2001 | DDM     | DDM             | ●         | ●        | ●         |
| S80   | 2001 | PDM     | PDM             | ●         | ●        | ●         |
| S80   | 2001 | PSM     | PSM             | ●         | ●        | ●         |
| S80   | 2001 | SRS     | SRS             | ●         | ●        | ●         |
| S80   | 2000 | CEM     | CEM             | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B5204T3         | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B5204T4         | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B5204T5         | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B5234T7         | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B5244S          | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B5244S2         | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B6284T          | ●         | ●        | ●         |
| S80   | 2000 | Petrol  | B6294S          | ●         | ●        | ●         |
| S80   | 2000 | Diesel  | D5252T MSA 15.8 | ●         | ○        | ○         |
| S80   | 2000 | AUM     | AUM             | ●         | ●        | ●         |
| S80   | 2000 | DIM     | DIM             | ●         | ●        | ●         |
| S80   | 2000 | PHM     | PHM             | ●         | ●        | ●         |
| S80   | 2000 | REM     | REM             | ●         | ●        | ●         |
| S80   | 2000 | RTI     | RTI             | ●         | ●        | ●         |
| S80   | 2000 | SWM     | SWM             | ●         | ●        | ●         |
| S80   | 2000 | UEM     | UEM             | ●         | ●        | ●         |
| S80   | 2000 | TCM     | 4T65EV          | ●         | ●        | ●         |
| S80   | 2000 | TCM     | 4T65EV-GT       | ●         | ●        | ●         |
| S80   | 2000 | TCM     | AW50-42         | ●         | ●        | ●         |
| S80   | 2000 | TCM     | AW55-50/51SN    | ●         | ●        | ●         |
| S80   | 2000 | ABS/BCM | ABS/BCM         | ●         | ●        | ●         |
| S80   | 2000 | SAS     | SAS             | ●         | ●        | ●         |
| S80   | 2000 | CCM     | CCM             | ●         | ●        | ●         |
| S80   | 2000 | DDM     | DDM             | ●         | ●        | ●         |
| S80   | 2000 | PDM     | PDM             | ●         | ●        | ●         |
| S80   | 2000 | PSM     | PSM             | ●         | ●        | ●         |
| S80   | 2000 | SRS     | SRS             | ●         | ●        | ●         |
| S80   | 1999 | CEM     | CEM             | ●         | ●        | ●         |
| S80   | 1999 | Petrol  | B5204T3         | ●         | ●        | ●         |
| S80   | 1999 | Petrol  | B5204T4         | ●         | ●        | ●         |
| S80   | 1999 | Petrol  | B5244S          | ●         | ●        | ●         |
| S80   | 1999 | Petrol  | B5244S2         | ●         | ●        | ●         |
| S80   | 1999 | Petrol  | B6284T          | ●         | ●        | ●         |
| S80   | 1999 | Petrol  | B6304S3         | ●         | ●        | ●         |
| S80   | 1999 | Diesel  | D5252T MSA 15.8 | ●         | ○        | ○         |
| S80   | 1999 | AUM     | AUM             | ●         | ●        | ●         |
| S80   | 1999 | DIM     | DIM             | ●         | ●        | ●         |
| S80   | 1999 | PHM     | PHM             | ●         | ●        | ●         |
| S80   | 1999 | REM     | REM             | ●         | ●        | ●         |
| S80   | 1999 | RTI     | RTI             | ●         | ●        | ●         |
| S80   | 1999 | SWM     | SWM             | ●         | ●        | ●         |
| S80   | 1999 | UEM     | UEM             | ●         | ●        | ●         |
| S80   | 1999 | TCM     | 4T65EV          | ●         | ●        | ●         |
| S80   | 1999 | TCM     | 4T65EV-GT       | ●         | ●        | ●         |
| S80   | 1999 | TCM     | AW50-42         | ●         | ●        | ●         |
| S80   | 1999 | TCM     | AW55-50/51SN    | ●         | ●        | ●         |
| S80   | 1999 | ABS/BCM | ABS/BCM         | ●         | ●        | ●         |
| S80   | 1999 | SAS     | SAS             | ●         | ●        | ●         |
| S80   | 1999 | CCM     | CCM             | ●         | ●        | ●         |





# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------|--------------|-----------|----------|-----------|
| S80      | 1999 | DDM    | DDM          | ●         | ●        | ●         |
| S80      | 1999 | PDM    | PDM          | ●         | ●        | ●         |
| S80      | 1999 | PSM    | PSM          | ●         | ●        | ●         |
| S80      | 1999 | SRS    | SRS          | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | D5244T2      | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | D5244T       | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B6294T       | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B6294S2      | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B5254T2      | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B5244T4      | ●         | ●        | ●         |
| S80(-06) | 2006 | ETM    | B5244SG      | ●         | ○        | ○         |
| S80(-06) | 2006 | ECM    | B5244SG      | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B5244S2      | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B5244S       | ●         | ●        | ●         |
| S80(-06) | 2006 | ECM    | B5204T5      | ●         | ●        | ●         |
| S80(-06) | 2006 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| S80(-06) | 2006 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| S80(-06) | 2006 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| S80(-06) | 2006 | TCM    | 4T65EV-GT    | ●         | ●        | ●         |
| S80(-06) | 2006 | TCM    | 4T65EV       | ●         | ●        | ●         |
| S80(-06) | 2006 | REM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | AUM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | BCM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | SRS    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | PSM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | DDM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | PDM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | SUM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | AEM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | PHM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | DIM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | CPM    |              | ●         | ○        | ○         |
| S80(-06) | 2006 | UEM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | CEM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | CCM    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | RTI    |              | ●         | ●        | ●         |
| S80(-06) | 2006 | SAS    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| S80(07-) | 2009 | DEM    | M66 AWD      | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | D5244T5      | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | D5244T4      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | D4204T       | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B8444S       | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B6324S       | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B6304T2      | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B5254T8      | ●         | ●        | ●         |
| S80(07-) | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B5254T6      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B4204S4      | ●         | ●        | ●         |
| S80(07-) | 2009 | ECM    | B4204S3      | ●         | ●        | ●         |
| S80(07-) | 2009 | SUM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | IAM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | PSM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | HLDF   |              | ●         | ●        | ●         |
| S80(07-) | 2009 | AUU    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | DDM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | PDM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | PAM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | KVM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | AUD    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | CPM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | HCM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | BCM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | SAS    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | SRS    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | CCM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | CEM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | TRM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | PBM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | FSM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | DIM    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | PAC    |              | ●         | ●        | ●         |
| S80(07-) | 2009 | RDAR   |              | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System | Type        | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------|-------------|-----------|----------|-----------|
| S80(07-) | 2009 | MMM    |             | ●         | ●        | ●         |
| S80(07-) | 2009 | ICM    |             | ●         | ●        | ●         |
| S80(07-) | 2009 | BPM    |             | ●         | ●        | ●         |
| S80(07-) | 2009 | PHM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| S80(07-) | 2008 | DEM    | M66 AWD     | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | D5244T5     | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | D5244T4     | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | D4204T      | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | B8444S      | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | B8444S      | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | B6324S      | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | B6324S      | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | B6324S      | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | B6304T2     | ●         | ●        | ●         |
| S80(07-) | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | B5254T6     | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | B4204S4     | ●         | ●        | ●         |
| S80(07-) | 2008 | ECM    | B4204S3     | ●         | ●        | ●         |
| S80(07-) | 2008 | SUM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | IAM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | PSM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | RDAR   |             | ●         | ●        | ●         |
| S80(07-) | 2008 | HLDF   |             | ●         | ●        | ●         |
| S80(07-) | 2008 | AUU    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | DDM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | PDM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | PAM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | KVM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | AUD    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | PHM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | CPM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | HCM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | BCM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | SAS    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | SRS    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | CEM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | DIM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | CCM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | TRM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | PBM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | BPM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | MMM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | FSM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | ICM    |             | ●         | ●        | ●         |
| S80(07-) | 2008 | PAC    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| S80(07-) | 2007 | ECM    | B5254T6     | ●         | ●        | ●         |
| S80(07-) | 2007 | SUM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | PSM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | HLDF   |             | ●         | ●        | ●         |
| S80(07-) | 2007 | AUU    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | DDM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | PDM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | PAM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | KVM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | AUD    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | PHM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | CPM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | HCM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | SAS    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | CCM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | TRM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2007 | ECM    | D5244T5     | ●         | ●        | ●         |
| S80(07-) | 2007 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2007 | ECM    | D5244T4     | ●         | ●        | ●         |
| S80(07-) | 2007 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| S80(07-) | 2007 | ECM    | B8444S      | ●         | ●        | ●         |
| S80(07-) | 2007 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| S80(07-) | 2007 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2007 | ECM    | B6324S      | ●         | ●        | ●         |
| S80(07-) | 2007 | TCM    | TF-80SC     | ●         | ●        | ●         |
| S80(07-) | 2007 | BCM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | FSM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | IAM    |             | ●         | ●        | ●         |
| S80(07-) | 2007 | PAC    |             | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System                     | Type                       | ECU Info. | Read DTC | Clear DTC |
|----------|------|----------------------------|----------------------------|-----------|----------|-----------|
| S80(07-) | 2007 | RDAR                       |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | ICM                        |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | SRS                        |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | PBM                        |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | CEM                        |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | BPM                        |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | DIM                        |                            | ●         | ●        | ●         |
| S80(07-) | 2007 | MMM                        |                            | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| V40      | 2004 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| V40      | 2004 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2004 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2004 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| V40      | 2004 | DIM                        | DIM                        | ●         | ●        | ●         |
| V40      | 2004 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| V40      | 2004 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| V40      | 2004 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| V40      | 2004 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V40      | 2004 | CCM                        | CCM                        | ●         | ●        | ●         |
| V40      | 2004 | CPM                        | CPM                        | ●         | ●        | ●         |
| V40      | 2004 | SRS                        | SRS                        | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| V40      | 2003 | Petrol                     | B4204T5                    | ●         | ●        | ●         |
| V40      | 2003 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2003 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2003 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| V40      | 2003 | DIM                        | DIM                        | ●         | ●        | ●         |
| V40      | 2003 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| V40      | 2003 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| V40      | 2003 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| V40      | 2003 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V40      | 2003 | CCM                        | CCM                        | ●         | ●        | ●         |
| V40      | 2003 | CPM                        | CPM                        | ●         | ●        | ●         |
| V40      | 2003 | SRS                        | SRS                        | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| V40      | 2002 | Petrol                     | B4204T5                    | ●         | ●        | ●         |
| V40      | 2002 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2002 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2002 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| V40      | 2002 | DIM                        | DIM                        | ●         | ●        | ●         |
| V40      | 2002 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| V40      | 2002 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| V40      | 2002 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| V40      | 2002 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V40      | 2002 | CCM                        | CCM                        | ●         | ●        | ●         |
| V40      | 2002 | CPM                        | CPM                        | ●         | ●        | ●         |
| V40      | 2002 | SRS                        | SRS                        | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4184S10                   | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4184S9                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4184SJ                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4184SM                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4204T3                    | ●         | ●        | ●         |
| V40      | 2001 | Petrol                     | B4204T5                    | ●         | ●        | ●         |
| V40      | 2001 | Diesel                     | D4192T3(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2001 | Diesel                     | D4192T4(Anti-spin system)  | ●         | ●        | ●         |
| V40      | 2001 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| V40      | 2001 | DIM                        | DIM                        | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System                     | Type                       | ECU Info. | Read DTC | Clear DTC |
|---------|------|----------------------------|----------------------------|-----------|----------|-----------|
| V40     | 2001 | Gas discharge light module | Gas discharge light module | ●         | ●        | ●         |
| V40     | 2001 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| V40     | 2001 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| V40     | 2001 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V40     | 2001 | CCM                        | CCM                        | ●         | ●        | ●         |
| V40     | 2001 | CPM                        | CPM                        | ●         | ●        | ●         |
| V40     | 2001 | SRS                        | SRS                        | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4164S2                    | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4184S2                    | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4184S3                    | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4184SM                    | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4194T2                    | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4204S2                    | ●         | ●        | ●         |
| V40     | 2000 | Petrol                     | B4204T2                    | ●         | ●        | ●         |
| V40     | 2000 | Diesel                     | D4192T2(Anti-spin system)  | ●         | ●        | ●         |
| V40     | 2000 | Anti-spin system           | Anti-spin system           | ●         | ●        | ●         |
| V40     | 2000 | DIM                        | DIM                        | ●         | ●        | ●         |
| V40     | 2000 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| V40     | 2000 | TCM                        | AW50-42                    | ●         | ●        | ●         |
| V40     | 2000 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V40     | 2000 | CCM                        | CCM                        | ●         | ●        | ●         |
| V40     | 2000 | CPM                        | CPM                        | ●         | ●        | ●         |
| V40     | 2000 | SRS                        | SRS                        | ●         | ●        | ●         |
| V40     | 1999 | Petrol                     | B4164S(Anti-spin system)   | ●         | ●        | ●         |
| V40     | 1999 | Petrol                     | B4184S(Anti-spin system)   | ●         | ●        | ●         |
| V40     | 1999 | Petrol                     | B4184SM                    | ●         | ●        | ●         |
| V40     | 1999 | Petrol                     | B4194T                     | ●         | ●        | ●         |
| V40     | 1999 | Petrol                     | B4204S(Anti-spin system)   | ●         | ●        | ●         |
| V40     | 1999 | Petrol                     | B4204T                     | ●         | ●        | ●         |
| V40     | 1999 | Diesel                     | D4192T(Anti-spin system)   | ●         | ●        | ●         |
| V40     | 1999 | Diesel                     | D4192T2(Anti-spin system)  | ●         | ●        | ●         |
| V40     | 1999 | DIM                        | DIM                        | ●         | ●        | ●         |
| V40     | 1999 | Lock and alarm             | Lock and alarm             | ●         | ●        | ●         |
| V40     | 1999 | TCM                        | AW50-42                    | ●         | ●        | ●         |
| V40     | 1999 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V40     | 1999 | CCM                        | CCM                        | ●         | ●        | ●         |
| V40     | 1999 | CPM                        | CPM                        | ●         | ●        | ●         |
| V40     | 1999 | SRS                        | SRS                        | ●         | ●        | ●         |
| V50     | 2005 | Petrol                     | B4164S3                    | ●         | ●        | ●         |
| V50     | 2005 | Petrol                     | B4184S11                   | ●         | ●        | ●         |
| V50     | 2005 | Petrol                     | B5244S4                    | ●         | ●        | ●         |
| V50     | 2005 | Petrol                     | B5244S5                    | ●         | ●        | ●         |
| V50     | 2005 | Petrol                     | B5254T3                    | ●         | ●        | ●         |
| V50     | 2005 | Diesel                     | D4164T                     | ●         | ●        | ●         |
| V50     | 2005 | Diesel                     | D4204T                     | ●         | ●        | ●         |
| V50     | 2005 | Diesel                     | D4204T2                    | ●         | ●        | ●         |
| V50     | 2005 | AFM                        | AFM                        | ●         | ●        | ●         |
| V50     | 2005 | AEM                        | AEM                        | ●         | ●        | ●         |
| V50     | 2005 | AUD                        | AUD                        | ●         | ●        | ●         |
| V50     | 2005 | CEM                        | CEM                        | ●         | ●        | ●         |
| V50     | 2005 | DIM                        | DIM                        | ●         | ●        | ●         |
| V50     | 2005 | ICM                        | ICM                        | ●         | ●        | ●         |
| V50     | 2005 | IAM                        | IAM                        | ●         | ●        | ●         |
| V50     | 2005 | KVM                        | KVM                        | ●         | ●        | ●         |
| V50     | 2005 | MPM                        | MPM                        | ●         | ●        | ●         |
| V50     | 2005 | MMM                        | MMM                        | ●         | ●        | ●         |
| V50     | 2005 | PAM                        | PAM                        | ●         | ●        | ●         |
| V50     | 2005 | PHM                        | PHM                        | ●         | ●        | ●         |
| V50     | 2005 | SWM                        | SWM                        | ●         | ●        | ●         |
| V50     | 2005 | SUB                        | SUB                        | ●         | ●        | ●         |
| V50     | 2005 | TMC                        | TMC                        | ●         | ●        | ●         |
| V50     | 2005 | TCM                        | AW50/51AWD                 | ●         | ●        | ●         |
| V50     | 2005 | TCM                        | AW55-50/51SN               | ●         | ●        | ●         |
| V50     | 2005 | ABS/BCM                    | ABS/BCM                    | ●         | ●        | ●         |
| V50     | 2005 | EPS                        | EPS                        | ●         | ●        | ●         |
| V50     | 2005 | CCM                        | CCM                        | ●         | ●        | ●         |
| V50     | 2005 | DDM                        | DDM                        | ●         | ●        | ●         |
| V50     | 2005 | PDM                        | PDM                        | ●         | ●        | ●         |
| V50     | 2005 | PSM                        | PSM                        | ●         | ●        | ●         |
| V50     | 2005 | SRS                        | SRS                        | ●         | ●        | ●         |
| V50     | 2005 | TRM                        | TRM                        | ●         | ●        | ●         |
| V50     | 2005 | DEM                        | DEM                        | ●         | ●        | ●         |
| V50     | 2005 | GPS                        | GPS                        | ●         | ●        | ●         |
| V50     | 2004 | Petrol                     | B5244S4                    | ●         | ●        | ●         |
| V50     | 2004 | Petrol                     | B5244S5                    | ●         | ●        | ●         |
| V50     | 2004 | Petrol                     | B5254T3                    | ●         | ●        | ●         |
| V50     | 2004 | Diesel                     | D4204T                     | ●         | ●        | ●         |
| V50     | 2004 | Diesel                     | D4204T2                    | ●         | ●        | ●         |
| V50     | 2004 | AFM                        | AFM                        | ●         | ●        | ●         |
| V50     | 2004 | AEM                        | AEM                        | ●         | ●        | ●         |
| V50     | 2004 | AUD                        | AUD                        | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

| NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a |      |         |              |           |          |           |
|---|------|---------|--------------|-----------|----------|-----------|
| Vehicle   | Year | System  | Type         | ECU Info. | Read DTC | Clear DTC |
| V50   | 2004 | CEM     | CEM          | ●         | ●        | ●         |
| V50   | 2004 | DIM     | DIM          | ●         | ●        | ●         |
| V50   | 2004 | ICM     | ICM          | ●         | ●        | ●         |
| V50   | 2004 | MPM     | MPM          | ●         | ●        | ●         |
| V50   | 2004 | MMM     | MMM          | ●         | ●        | ●         |
| V50   | 2004 | PHM     | PHM          | ●         | ●        | ●         |
| V50   | 2004 | SWM     | SWM          | ●         | ●        | ●         |
| V50   | 2004 | SUB     | SUB          | ●         | ●        | ●         |
| V50   | 2004 | TMC     | TMC          | ●         | ●        | ●         |
| V50   | 2004 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| V50   | 2004 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| V50   | 2004 | CCM     | CCM          | ●         | ●        | ●         |
| V50   | 2004 | DDM     | DDM          | ●         | ●        | ●         |
| V50   | 2004 | PDM     | PDM          | ●         | ●        | ●         |
| V50   | 2004 | PSM     | PSM          | ●         | ●        | ●         |
| V50   | 2004 | SRS     | SRS          | ●         | ●        | ●         |
| V50   | 2004 | TRM     | TRM          | ●         | ●        | ●         |
| V50   | 2004 | EPS     | EPS          | ●         | ●        | ●         |
| V50   | 2004 | GPS     | GPS          | ●         | ●        | ●         |
| V50   | 2009 | TCM     | MPS6         | ●         | ●        | ●         |
| V50   | 2009 | DEM     | M66 AWD      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | D5244T9      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | D5244T8      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | D5244T13     | ●         | ●        | ●         |
| V50   | 2009 | ECM     | D4204T       | ●         | ●        | ●         |
| V50   | 2009 | ADM     | D4204T       | ●         | ●        | ●         |
| V50   | 2009 | ECM     | D4204T       | ●         | ●        | ●         |
| V50   | 2009 | ADM     | D4164T       | ●         | ●        | ●         |
| V50   | 2009 | ECM     | D4164T       | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B5254T7      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B5244S7      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B5244S5      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B5244S4      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B4204S3      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B4184S8      | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B4184S11     | ●         | ●        | ●         |
| V50   | 2009 | ECM     | B4164S3      | ●         | ●        | ●         |
| V50   | 2009 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| V50   | 2009 | DEM     | AW50/51 AWD  | ●         | ●        | ●         |
| V50   | 2009 | TCM     | AW50/51 AWD  | ●         | ●        | ●         |
| V50   | 2009 | PSM     |              | ●         | ●        | ●         |
| V50   | 2009 | AEM     |              | ●         | ●        | ●         |
| V50   | 2009 | KVM     |              | ●         | ●        | ●         |
| V50   | 2009 | RDAR    |              | ●         | ●        | ●         |
| V50   | 2009 | PHM     |              | ●         | ●        | ●         |
| V50   | 2009 | CPM     |              | ●         | ●        | ●         |
| V50   | 2009 | AUD     |              | ●         | ●        | ●         |
| V50   | 2009 | BPM     |              | ●         | ●        | ●         |
| V50   | 2009 | PAM     |              | ●         | ●        | ●         |
| V50   | 2009 | SRS     |              | ●         | ●        | ●         |
| V50   | 2009 | DDM     |              | ●         | ●        | ●         |
| V50   | 2009 | PDM     |              | ●         | ●        | ●         |
| V50   | 2009 | AUU     |              | ●         | ●        | ●         |
| V50   | 2009 | HCM     |              | ●         | ●        | ●         |
| V50   | 2009 | BCM     |              | ●         | ●        | ●         |
| V50   | 2009 | CCM     |              | ●         | ●        | ●         |
| V50   | 2009 | SWM     |              | ●         | ●        | ●         |
| V50   | 2009 | TRM     |              | ●         | ●        | ●         |
| V50   | 2009 | EPS     |              | ●         | ●        | ●         |
| V50   | 2009 | IAM     |              | ●         | ●        | ●         |
| V50   | 2009 | CEM     |              | ●         | ●        | ●         |
| V50   | 2009 | DIM     |              | ●         | ●        | ●         |
| V50   | 2009 | ICM     |              | ●         | ●        | ●         |
| V50   | 2009 | MMM     |              | ●         | ●        | ●         |
| V50   | 2008 | TCM     | MPS6         | ●         | ●        | ●         |
| V50   | 2008 | DEM     | M66 AWD      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | D5244T9      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | D5244T8      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | D5244T13     | ●         | ●        | ●         |
| V50   | 2008 | ECM     | D4204T       | ●         | ●        | ●         |
| V50   | 2008 | ADM     | D4204T       | ●         | ●        | ●         |
| V50   | 2008 | ECM     | D4204T       | ●         | ●        | ●         |
| V50   | 2008 | ADM     | D4164T       | ●         | ●        | ●         |
| V50   | 2008 | ECM     | D4164T       | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B5254T7      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B5244S7      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B5244S5      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B5244S4      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B4204S3      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B4184S8      | ●         | ●        | ●         |
| V50   | 2008 | ECM     | B4184S11     | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------|--------------|-----------|----------|-----------|
| V50     | 2008 | ECM    | B4164S3      | ●         | ●        | ●         |
| V50     | 2008 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| V50     | 2008 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| V50     | 2008 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| V50     | 2008 | BCM    |              | ●         | ●        | ●         |
| V50     | 2008 | PSM    |              | ●         | ●        | ●         |
| V50     | 2008 | AEM    |              | ●         | ●        | ●         |
| V50     | 2008 | KVM    |              | ●         | ●        | ●         |
| V50     | 2008 | RDAR   |              | ●         | ●        | ●         |
| V50     | 2008 | CPM    |              | ●         | ●        | ●         |
| V50     | 2008 | AUD    |              | ●         | ●        | ●         |
| V50     | 2008 | PAM    |              | ●         | ●        | ●         |
| V50     | 2008 | SRS    |              | ●         | ●        | ●         |
| V50     | 2008 | DDM    |              | ●         | ●        | ●         |
| V50     | 2008 | PDM    |              | ●         | ●        | ●         |
| V50     | 2008 | AUU    |              | ●         | ●        | ●         |
| V50     | 2008 | HCM    |              | ●         | ●        | ●         |
| V50     | 2008 | CCM    |              | ●         | ●        | ●         |
| V50     | 2008 | PHM    |              | ●         | ●        | ●         |
| V50     | 2008 | CEM    |              | ●         | ●        | ●         |
| V50     | 2008 | DIM    |              | ●         | ●        | ●         |
| V50     | 2008 | SWM    |              | ●         | ●        | ●         |
| V50     | 2008 | TRM    |              | ●         | ●        | ●         |
| V50     | 2008 | EPS    |              | ●         | ●        | ●         |
| V50     | 2008 | IAM    |              | ●         | ●        | ●         |
| V50     | 2008 | ICM    |              | ●         | ●        | ●         |
| V50     | 2008 | MMM    |              | ●         | ●        | ●         |
| V50     | 2007 | DEM    | M66 AWD      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | D5244T9      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | D5244T8      | ●         | ●        | ●         |
| V50     | 2007 | ADM    | D4204T       | ●         | ●        | ●         |
| V50     | 2007 | ECM    | D4204T       | ●         | ●        | ●         |
| V50     | 2007 | ADM    | D4164T       | ●         | ●        | ●         |
| V50     | 2007 | ECM    | D4164T       | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B5254T3      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B5244S7      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B5244S5      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B5244S4      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B4204S3      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B4184S8      | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B4184S11     | ●         | ●        | ●         |
| V50     | 2007 | ECM    | B4164S3      | ●         | ●        | ●         |
| V50     | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| V50     | 2007 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| V50     | 2007 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| V50     | 2007 | GPS    |              | ●         | ●        | ●         |
| V50     | 2007 | BCM    |              | ●         | ●        | ●         |
| V50     | 2007 | PSM    |              | ●         | ●        | ●         |
| V50     | 2007 | TMC    |              | ●         | ●        | ●         |
| V50     | 2007 | SWM    |              | ●         | ●        | ●         |
| V50     | 2007 | KVM    |              | ●         | ●        | ●         |
| V50     | 2007 | AEM    |              | ●         | ●        | ●         |
| V50     | 2007 | PHM    |              | ●         | ●        | ●         |
| V50     | 2007 | TRM    |              | ●         | ●        | ●         |
| V50     | 2007 | CEM    |              | ●         | ●        | ●         |
| V50     | 2007 | MMM    |              | ●         | ●        | ●         |
| V50     | 2007 | RDAR   |              | ●         | ●        | ●         |
| V50     | 2007 | CPM    |              | ●         | ●        | ●         |
| V50     | 2007 | IAM    |              | ●         | ●        | ●         |
| V50     | 2007 | AUD    |              | ●         | ●        | ●         |
| V50     | 2007 | PAM    |              | ●         | ●        | ●         |
| V50     | 2007 | DDM    |              | ●         | ●        | ●         |
| V50     | 2007 | PDM    |              | ●         | ●        | ●         |
| V50     | 2007 | SRS    |              | ●         | ●        | ●         |
| V50     | 2007 | CCM    |              | ●         | ●        | ●         |
| V50     | 2007 | DIM    |              | ●         | ●        | ●         |
| V50     | 2007 | ICM    |              | ●         | ●        | ●         |
| V50     | 2007 | EPS    |              | ●         | ●        | ●         |
| V50     | 2006 | DEM    | M66 AWD      | ●         | ●        | ●         |
| V50     | 2006 | ECM    | D5244T8      | ●         | ●        | ●         |
| V50     | 2006 | ADM    | D4204T2      | ●         | ●        | ●         |
| V50     | 2006 | ECM    | D4204T2      | ●         | ●        | ●         |
| V50     | 2006 | ADM    | D4204T       | ●         | ●        | ●         |
| V50     | 2006 | ECM    | D4204T       | ●         | ●        | ●         |
| V50     | 2006 | ADM    | D4164T       | ●         | ●        | ●         |
| V50     | 2006 | ECM    | D4164T       | ●         | ●        | ●         |
| V50     | 2006 | ECM    | B5254T3      | ●         | ●        | ●         |
| V50     | 2006 | ECM    | B5244S7      | ●         | ●        | ●         |
| V50     | 2006 | ECM    | B5244S5      | ●         | ●        | ●         |
| V50     | 2006 | ECM    | B5244S4      | ●         | ●        | ●         |
| V50     | 2006 | ECM    | B4184S8      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle    | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|------------|------|--------|--------------|-----------|----------|-----------|
| V50        | 2006 | ECM    | B4184S11     | ●         | ●        | ●         |
| V50        | 2006 | ECM    | B4164S3      | ●         | ●        | ●         |
| V50        | 2006 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| V50        | 2006 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| V50        | 2006 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| V50        | 2006 | DIM    |              | ●         | ●        | ●         |
| V50        | 2006 | GPS    |              | ●         | ●        | ●         |
| V50        | 2006 | DDM    |              | ●         | ●        | ●         |
| V50        | 2006 | PDM    |              | ●         | ●        | ●         |
| V50        | 2006 | BCM    |              | ●         | ●        | ●         |
| V50        | 2006 | PSM    |              | ●         | ●        | ●         |
| V50        | 2006 | TMC    |              | ●         | ●        | ●         |
| V50        | 2006 | SWM    |              | ●         | ●        | ●         |
| V50        | 2006 | KVM    |              | ●         | ●        | ●         |
| V50        | 2006 | AEM    |              | ●         | ●        | ●         |
| V50        | 2006 | ICM    |              | ●         | ●        | ●         |
| V50        | 2006 | IAM    |              | ●         | ●        | ●         |
| V50        | 2006 | PHM    |              | ●         | ●        | ●         |
| V50        | 2006 | TRM    |              | ●         | ●        | ●         |
| V50        | 2006 | PAM    |              | ●         | ●        | ●         |
| V50        | 2006 | CEM    |              | ●         | ●        | ●         |
| V50        | 2006 | MMM    |              | ●         | ●        | ●         |
| V50        | 2006 | CPM    |              | ●         | ●        | ●         |
| V50        | 2006 | CCM    |              | ●         | ●        | ●         |
| V50        | 2006 | AUD    |              | ●         | ●        | ●         |
| V50        | 2006 | SRS    |              | ●         | ●        | ●         |
| V50        | 2006 | EPS    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2008 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(00-08) | 2008 | DEM    | M66 AWD      | ●         | ●        | ●         |
| V70(00-08) | 2008 | ECM    | D5244T7      | ●         | ●        | ●         |
| V70(00-08) | 2008 | ECM    | D5244T5      | ●         | ●        | ●         |
| V70(00-08) | 2008 | ECM    | B5254T2      | ●         | ●        | ●         |
| V70(00-08) | 2008 | ETM    | B5244SG      | ●         | ○        | ○         |
| V70(00-08) | 2008 | ECM    | B5244SG      | ●         | ●        | ●         |
| V70(00-08) | 2008 | ECM    | B5244S2      | ●         | ●        | ●         |
| V70(00-08) | 2008 | ECM    | B5244S       | ●         | ●        | ●         |
| V70(00-08) | 2008 | DEM    | AW55-50/51SN | ●         | ●        | ●         |
| V70(00-08) | 2008 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| V70(00-08) | 2008 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| V70(00-08) | 2008 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| V70(00-08) | 2008 | PHM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | AUM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | BCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | SRS    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | PSM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | DDM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | PDM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | SUM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | AEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | REM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | CPM    |              | ●         | ○        | ○         |
| V70(00-08) | 2008 | CEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | HCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | RTI    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | SAS    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | AUU    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | CCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | DIM    |              | ●         | ●        | ●         |
| V70(00-08) | 2008 | UEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2007 | DEM    | M66 AWD      | ●         | ●        | ●         |
| V70(00-08) | 2007 | DEM    | M58          | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | D5244T7      | ●         | ●        | ●         |
| V70(00-08) | 2007 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | D5244T5      | ●         | ●        | ●         |
| V70(00-08) | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2007 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | D5244T4      | ●         | ●        | ●         |
| V70(00-08) | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | B5254T4      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | B5254T2      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | B5244T5      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ETM    | B5244SG      | ●         | ○        | ○         |
| V70(00-08) | 2007 | ECM    | B5244SG      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | B5244S2      | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | B5244S       | ●         | ●        | ●         |
| V70(00-08) | 2007 | ECM    | B5204T5      | ●         | ●        | ●         |
| V70(00-08) | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| V70(00-08) | 2007 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| V70(00-08) | 2007 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle    | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|------------|------|--------|--------------|-----------|----------|-----------|
| V70(00-08) | 2007 | PHM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | AUM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | BCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | SRS    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | PSM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | DDM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | PDM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | SUM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | AEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | REM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | CPM    |              | ●         | ○        | ○         |
| V70(00-08) | 2007 | CEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | HCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | CCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | RTI    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | SAS    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | DIM    |              | ●         | ●        | ●         |
| V70(00-08) | 2007 | UEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2006 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(00-08) | 2006 | DEM    | M66 AWD      | ●         | ●        | ●         |
| V70(00-08) | 2006 | DEM    | M58          | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | D5244T7      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | D5244T6      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | D5244T5      | ●         | ●        | ●         |
| V70(00-08) | 2006 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | D5244T4      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | D5244T2      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | D5244T       | ●         | ●        | ●         |
| V70(00-08) | 2006 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5254T4      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5254T2      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5244T5      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ETM    | B5244SG      | ●         | ○        | ○         |
| V70(00-08) | 2006 | ECM    | B5244SG      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5244S6      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5244S2      | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5244S       | ●         | ●        | ●         |
| V70(00-08) | 2006 | ECM    | B5204T5      | ●         | ●        | ●         |
| V70(00-08) | 2006 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| V70(00-08) | 2006 | TCM    | AW50/51 AWD  | ●         | ●        | ●         |
| V70(00-08) | 2006 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| V70(00-08) | 2006 | REM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | AUM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | BCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | SRS    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | PSM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | DDM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | PDM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | SUM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | AEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | PHM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | DIM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | CPM    |              | ●         | ○        | ○         |
| V70(00-08) | 2006 | UEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | CEM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | CCM    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | RTI    |              | ●         | ●        | ●         |
| V70(00-08) | 2006 | SAS    |              | ●         | ●        | ●         |
| V70(08-)   | 2009 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(08-)   | 2009 | DEM    | M66 AWD      | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | D5244T5      | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | D5244T4      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | D4204T       | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | B6324S       | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | B6304T2      | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | B5254T8      | ●         | ●        | ●         |
| V70(08-)   | 2009 | TCM    | TF-80SC      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | B5254T6      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | B4204S4      | ●         | ●        | ●         |
| V70(08-)   | 2009 | ECM    | B4204S3      | ●         | ●        | ●         |
| V70(08-)   | 2009 | POT    |              | ●         | ●        | ●         |
| V70(08-)   | 2009 | SUM    |              | ●         | ●        | ●         |
| V70(08-)   | 2009 | IAM    |              | ●         | ●        | ●         |





# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle          | Year | System | Type        | ECU Info. | Read DTC | Clear DTC |
|------------------|------|--------|-------------|-----------|----------|-----------|
| V70(08-)         | 2009 | PSM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | HLDF   |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | AUU    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | DDM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | PDM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | PAM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | KVM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | AUD    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | CPM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | SUB    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | HCM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | SRS    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | BCM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | SAS    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | CCM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | CEM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | TRM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | PBM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | FSM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | DIM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | PAC    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | RDAR   |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | MMM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | ICM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | BPM    |             | ●         | ●        | ●         |
| V70(08-)         | 2009 | PHM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| V70(08-)         | 2008 | DEM    | M66 AWD     | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | D5244T5     | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | D5244T4     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | D4204T      | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | B6324S      | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | B6304T2     | ●         | ●        | ●         |
| V70(08-)         | 2008 | TCM    | TF-80SC     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | B5254T6     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | B4204S4     | ●         | ●        | ●         |
| V70(08-)         | 2008 | ECM    | B4204S3     | ●         | ●        | ●         |
| V70(08-)         | 2008 | POT    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | SUM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | IAM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | PSM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | RDAR   |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | HLDF   |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | AUU    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | DDM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | PDM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | PAM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | KVM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | AUD    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | PHM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | CPM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | SUB    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | HCM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | SRS    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | BCM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | SAS    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | CEM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | DIM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | CCM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | TRM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | PBM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | BPM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | MMM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | FSM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | ICM    |             | ●         | ●        | ●         |
| V70(08-)         | 2008 | PAC    |             | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | DEM    | M66 AWD     | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | DEM    | M58         | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | ECM    | D5244T4     | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | ECM    | B5254T2     | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | DEM    | AW50/51 AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | TCM    | AW50/51 AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | PHM    |             | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle          | Year | System                   | Type                     | ECU Info. | Read DTC | Clear DTC |
|------------------|------|--------------------------|--------------------------|-----------|----------|-----------|
| V70 XC(01-)/XC70 | 2007 | AUM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | BCM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | SRS                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | PSM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | DDM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | PDM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | SUM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | AEM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | REM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | CPM                      |                          | ●         | ○        | ○         |
| V70 XC(01-)/XC70 | 2007 | CEM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | HCM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | CCM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | RTI                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | SAS                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | DIM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2007 | UEM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | TCM                      | TF-80SC AWD              | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | DEM                      | TF-80SC AWD              | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | DEM                      | M66 AWD                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | DEM                      | M58                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | ECM                      | D5244T4                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | ECM                      | D5244T                   | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | ECM                      | B5254T2                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | ECM                      | B5244T4                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | TCM                      | AW50/51 AWD              | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | DEM                      | AW50/51 AWD              | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | REM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | AUM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | BCM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | SRS                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | PSM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | DDM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | PDM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | SUM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | AEM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | PHM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | DIM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | CPM                      |                          | ●         | ○        | ○         |
| V70 XC(01-)/XC70 | 2006 | UEM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | CEM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | CCM                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | RTI                      |                          | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2006 | SAS                      |                          | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | RTI                      | RTI                      | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | TCM                      | AW42AWD                  | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | CCM                      | CCM                      | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | CPM                      | CPM                      | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | Power seat module, Right | Power seat module, Right | ●         | ●        | ●         |
| V70 XC(-00)      | 2000 | SRS                      | SRS                      | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | Petrol                   | B5254T                   | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | RTI                      | RTI                      | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | TCM                      | AW42AWD                  | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | CCM                      | CCM                      | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | CPM                      | CPM                      | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | Power seat module, Right | Power seat module, Right | ●         | ●        | ●         |
| V70 XC(-00)      | 1999 | SRS                      | SRS                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | Petrol                   | B5244T4                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | Petrol                   | B5254T2                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | Diesel                   | D5244T                   | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | AEM                      | AEM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | AUM                      | AUM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | CEM                      | CEM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | DIM                      | DIM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | PHM                      | PHM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | REM                      | REM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | RTI                      | RTI                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | UEM                      | UEM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | TCM                      | AW50/51AWD               | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | DEM                      | DEM                      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle          | Year | System  | Type       | ECU Info. | Read DTC | Clear DTC |
|------------------|------|---------|------------|-----------|----------|-----------|
| V70 XC(01-)/XC70 | 2005 | DEM     | DEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | ABS/BCM | ABS/BCM    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | SAS     | SAS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | SUM     | SUM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | CCM     | CCM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | DDM     | DDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | PDM     | PDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | PSM     | PSM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2005 | SRS     | SRS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | Petrol  | B5234T7    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | Petrol  | B5254T2    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | Diesel  | D5244T     | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | AEM     | AEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | AUM     | AUM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | CEM     | CEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | DIM     | DIM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | PHM     | PHM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | REM     | REM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | RTI     | RTI        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | SWM     | SWM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | UEM     | UEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | TCM     | AW50/51AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | DEM     | DEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | DEM     | DEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | ABS/BCM | ABS/BCM    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | SAS     | SAS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | CCM     | CCM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | DDM     | DDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | PDM     | PDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | PSM     | PSM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2004 | SRS     | SRS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | Petrol  | B5234T7    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | Petrol  | B5254T2    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | Diesel  | D5244T     | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | AEM     | AEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | AUM     | AUM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | CEM     | CEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | DIM     | DIM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | PHM     | PHM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | REM     | REM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | RTI     | RTI        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | SWM     | SWM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | UEM     | UEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | TCM     | AW50/51AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | DEM     | DEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | ABS/BCM | ABS/BCM    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | SAS     | SAS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | CCM     | CCM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | DDM     | DDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | PDM     | PDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | PSM     | PSM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2003 | SRS     | SRS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | Petrol  | B5234T7    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | Petrol  | B5244T3    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | AEM     | AEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | AUM     | AUM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | CEM     | CEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | DIM     | DIM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | PHM     | PHM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | REM     | REM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | RTI     | RTI        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | SWM     | SWM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | UEM     | UEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | TCM     | AW50/51AWD | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | ABS/BCM | ABS/BCM    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | SAS     | SAS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | CCM     | CCM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | DDM     | DDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | PDM     | PDM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | PSM     | PSM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2002 | SRS     | SRS        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | Petrol  | B5234T7    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | Petrol  | B5244T3    | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | AEM     | AEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | AUM     | AUM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | CEM     | CEM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | DIM     | DIM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | PHM     | PHM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | REM     | REM        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | RTI     | RTI        | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | SWM     | SWM        | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle          | Year | System                   | Type                     | ECU Info. | Read DTC | Clear DTC |
|------------------|------|--------------------------|--------------------------|-----------|----------|-----------|
| V70 XC(01-)/XC70 | 2001 | UEM                      | UEM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | TCM                      | AW50/51AWD               | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | SAS                      | SAS                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | CCM                      | CCM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | DDM                      | DDM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | PDM                      | PDM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | PSM                      | PSM                      | ●         | ●        | ●         |
| V70 XC(01-)/XC70 | 2001 | SRS                      | SRS                      | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5234T7                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5244S2                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5244SG                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5244SG2                 | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5244T                   | ●         | ●        | ●         |
| V70(-00)         | 2000 | Petrol                   | B5244T2                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Diesel                   | D5252T MSA 15.8          | ●         | ○        | ○         |
| V70(-00)         | 2000 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| V70(-00)         | 2000 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| V70(-00)         | 2000 | RTI                      | RTI                      | ●         | ●        | ●         |
| V70(-00)         | 2000 | TCM                      | AW42AWD                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | TCM                      | AW50/51AWD               | ●         | ●        | ●         |
| V70(-00)         | 2000 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| V70(-00)         | 2000 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| V70(-00)         | 2000 | CCM                      | CCM                      | ●         | ●        | ●         |
| V70(-00)         | 2000 | CPM                      | CPM                      | ●         | ●        | ●         |
| V70(-00)         | 2000 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| V70(-00)         | 2000 | Power seat module, right | Power seat module, Right | ●         | ●        | ●         |
| V70(-00)         | 2000 | SRS                      | SRS                      | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5204T3                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5204T4                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5234T3                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5234T7                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5234T8                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5254S DENSO             | ●         | ●        | ●         |
| V70(-00)         | 1999 | Petrol                   | B5254T                   | ●         | ●        | ●         |
| V70(-00)         | 1999 | Diesel                   | D5252T MSA 15.7          | ●         | ●        | ●         |
| V70(-00)         | 1999 | Diesel                   | D5252T MSA 15.8          | ●         | ○        | ○         |
| V70(-00)         | 1999 | Combined instrument      | Combined instrument      | ●         | ●        | ●         |
| V70(-00)         | 1999 | Lock and alarm           | Lock and alarm           | ●         | ●        | ●         |
| V70(-00)         | 1999 | RTI                      | RTI                      | ●         | ●        | ●         |
| V70(-00)         | 1999 | TCM                      | AW42AWD                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | TCM                      | AW50-42                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| V70(-00)         | 1999 | CCM                      | CCM                      | ●         | ●        | ●         |
| V70(-00)         | 1999 | CPM                      | CPM                      | ●         | ●        | ●         |
| V70(-00)         | 1999 | Power seat module, left  | Power seat module, left  | ●         | ●        | ●         |
| V70(-00)         | 1999 | Power seat module, right | Power seat module, Right | ●         | ●        | ●         |
| V70(-00)         | 1999 | SRS                      | SRS                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5204T5                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5244S                   | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5244S2                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5244SG                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5244SG2                 | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5244T4                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5244T5                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5254T2                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Petrol                   | B5254T4                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Diesel                   | D5244T                   | ●         | ●        | ●         |
| V70(00-)         | 2005 | Diesel                   | D5244T2                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | Diesel                   | D5244T3                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | AEM                      | AEM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | AUM                      | AUM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | CEM                      | CEM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | DIM                      | DIM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | PHM                      | PHM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | REM                      | REM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | RTI                      | RTI                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | UEM                      | UEM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | TCM                      | AW50/51AWD               | ●         | ●        | ●         |
| V70(00-)         | 2005 | TCM                      | AW55-50/51SN             | ●         | ●        | ●         |
| V70(00-)         | 2005 | DEM                      | DEM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | DEM                      | DEM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | ABS/BCM                  | ABS/BCM                  | ●         | ●        | ●         |
| V70(00-)         | 2005 | SAS                      | SAS                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | SUM                      | SUM                      | ●         | ●        | ●         |
| V70(00-)         | 2005 | CCM                      | CCM                      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System  | Type         | ECU Info. | Read DTC | Clear DTC |
|----------|------|---------|--------------|-----------|----------|-----------|
| V70(00-) | 2005 | DDM     | DDM          | ●         | ●        | ●         |
| V70(00-) | 2005 | PDM     | PDM          | ●         | ●        | ●         |
| V70(00-) | 2005 | PSM     | PSM          | ●         | ●        | ●         |
| V70(00-) | 2005 | SRS     | SRS          | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5204T5      | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5234T3      | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5234T7      | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5244S       | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5244S2      | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5244SG      | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5254T2      | ●         | ●        | ●         |
| V70(00-) | 2004 | Petrol  | B5254T4      | ●         | ●        | ●         |
| V70(00-) | 2004 | Diesel  | D5244T       | ●         | ●        | ●         |
| V70(00-) | 2004 | Diesel  | D5244T2      | ●         | ●        | ●         |
| V70(00-) | 2004 | AEM     | AEM          | ●         | ●        | ●         |
| V70(00-) | 2004 | AUM     | AUM          | ●         | ●        | ●         |
| V70(00-) | 2004 | CEM     | CEM          | ●         | ●        | ●         |
| V70(00-) | 2004 | DIM     | DIM          | ●         | ●        | ●         |
| V70(00-) | 2004 | PHM     | PHM          | ●         | ●        | ●         |
| V70(00-) | 2004 | REM     | REM          | ●         | ●        | ●         |
| V70(00-) | 2004 | RTI     | RTI          | ●         | ●        | ●         |
| V70(00-) | 2004 | SWM     | SWM          | ●         | ●        | ●         |
| V70(00-) | 2004 | UEM     | UEM          | ●         | ●        | ●         |
| V70(00-) | 2004 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| V70(00-) | 2004 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| V70(00-) | 2004 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| V70(00-) | 2004 | SAS     | SAS          | ●         | ●        | ●         |
| V70(00-) | 2004 | SUM     | SUM          | ●         | ●        | ●         |
| V70(00-) | 2004 | CCM     | CCM          | ●         | ●        | ●         |
| V70(00-) | 2004 | DDM     | DDM          | ●         | ●        | ●         |
| V70(00-) | 2004 | PDM     | PDM          | ●         | ●        | ●         |
| V70(00-) | 2004 | PSM     | PSM          | ●         | ●        | ●         |
| V70(00-) | 2004 | SRS     | SRS          | ●         | ●        | ●         |
| V70(00-) | 2004 | DEM     | DEM          | ●         | ●        | ●         |
| V70(00-) | 2004 | DEM     | DEM          | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5204T5      | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5234T3      | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5234T7      | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5244S       | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5244S2      | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5244SG      | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5244T3      | ●         | ●        | ●         |
| V70(00-) | 2003 | Petrol  | B5254T2      | ●         | ●        | ●         |
| V70(00-) | 2003 | Diesel  | D5244T       | ●         | ●        | ●         |
| V70(00-) | 2003 | Diesel  | D5244T2      | ●         | ●        | ●         |
| V70(00-) | 2003 | AEM     | AEM          | ●         | ●        | ●         |
| V70(00-) | 2003 | AUM     | AUM          | ●         | ●        | ●         |
| V70(00-) | 2003 | CEM     | CEM          | ●         | ●        | ●         |
| V70(00-) | 2003 | DIM     | DIM          | ●         | ●        | ●         |
| V70(00-) | 2003 | PHM     | PHM          | ●         | ●        | ●         |
| V70(00-) | 2003 | REM     | REM          | ●         | ●        | ●         |
| V70(00-) | 2003 | RTI     | RTI          | ●         | ●        | ●         |
| V70(00-) | 2003 | SWM     | SWM          | ●         | ●        | ●         |
| V70(00-) | 2003 | UEM     | UEM          | ●         | ●        | ●         |
| V70(00-) | 2003 | TCM     | AW50/51AWD   | ●         | ●        | ●         |
| V70(00-) | 2003 | TCM     | AW55-50/51SN | ●         | ●        | ●         |
| V70(00-) | 2003 | ABS/BCM | ABS/BCM      | ●         | ●        | ●         |
| V70(00-) | 2003 | SAS     | SAS          | ●         | ●        | ●         |
| V70(00-) | 2003 | CCM     | CCM          | ●         | ●        | ●         |
| V70(00-) | 2003 | DDM     | DDM          | ●         | ●        | ●         |
| V70(00-) | 2003 | PDM     | PDM          | ●         | ●        | ●         |
| V70(00-) | 2003 | PSM     | PSM          | ●         | ●        | ●         |
| V70(00-) | 2003 | SRS     | SRS          | ●         | ●        | ●         |
| V70(00-) | 2003 | DEM     | DEM          | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5204T5      | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5234T3      | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5234T7      | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5244S       | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5244S2      | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5244SG      | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5244SG2     | ●         | ●        | ●         |
| V70(00-) | 2002 | Petrol  | B5244T3      | ●         | ●        | ●         |
| V70(00-) | 2002 | Diesel  | D5244T       | ●         | ●        | ●         |
| V70(00-) | 2002 | Diesel  | D5244T2      | ●         | ●        | ●         |
| V70(00-) | 2002 | AEM     | AEM          | ●         | ●        | ●         |
| V70(00-) | 2002 | AUM     | AUM          | ●         | ●        | ●         |
| V70(00-) | 2002 | CEM     | CEM          | ●         | ●        | ●         |
| V70(00-) | 2002 | DIM     | DIM          | ●         | ●        | ●         |
| V70(00-) | 2002 | PHM     | PHM          | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System  | Type            | ECU Info. | Read DTC | Clear DTC |
|----------|------|---------|-----------------|-----------|----------|-----------|
| V70(00-) | 2002 | REM     | REM             | ●         | ●        | ●         |
| V70(00-) | 2002 | RTI     | RTI             | ●         | ●        | ●         |
| V70(00-) | 2002 | SWM     | SWM             | ●         | ●        | ●         |
| V70(00-) | 2002 | UEM     | UEM             | ●         | ●        | ●         |
| V70(00-) | 2002 | TCM     | AW50/51AWD      | ●         | ●        | ●         |
| V70(00-) | 2002 | TCM     | AW55-50/51SN    | ●         | ●        | ●         |
| V70(00-) | 2002 | ABS/BCM | ABS/BCM         | ●         | ●        | ●         |
| V70(00-) | 2002 | SAS     | SAS             | ●         | ●        | ●         |
| V70(00-) | 2002 | CCM     | CCM             | ●         | ●        | ●         |
| V70(00-) | 2002 | DDM     | DDM             | ●         | ●        | ●         |
| V70(00-) | 2002 | PDM     | PDM             | ●         | ●        | ●         |
| V70(00-) | 2002 | PSM     | PSM             | ●         | ●        | ●         |
| V70(00-) | 2002 | SRS     | SRS             | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5204T5         | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5234T3         | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5234T7         | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5244S          | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5244S2         | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5244SG         | ●         | ●        | ●         |
| V70(00-) | 2001 | Petrol  | B5244T3         | ●         | ●        | ●         |
| V70(00-) | 2001 | Diesel  | D5244T          | ●         | ●        | ●         |
| V70(00-) | 2001 | Diesel  | D5252T MSA 15.8 | ●         | ○        | ○         |
| V70(00-) | 2001 | AEM     | AEM             | ●         | ●        | ●         |
| V70(00-) | 2001 | AUM     | AUM             | ●         | ●        | ●         |
| V70(00-) | 2001 | CEM     | CEM             | ●         | ●        | ●         |
| V70(00-) | 2001 | DIM     | DIM             | ●         | ●        | ●         |
| V70(00-) | 2001 | PHM     | PHM             | ●         | ●        | ●         |
| V70(00-) | 2001 | REM     | REM             | ●         | ●        | ●         |
| V70(00-) | 2001 | RTI     | RTI             | ●         | ●        | ●         |
| V70(00-) | 2001 | SWM     | SWM             | ●         | ●        | ●         |
| V70(00-) | 2001 | UEM     | UEM             | ●         | ●        | ●         |
| V70(00-) | 2001 | TCM     | AW50/51AWD      | ●         | ●        | ●         |
| V70(00-) | 2001 | TCM     | AW55-50/51SN    | ●         | ●        | ●         |
| V70(00-) | 2001 | ABS/BCM | ABS/BCM         | ●         | ●        | ●         |
| V70(00-) | 2001 | SAS     | SAS             | ●         | ●        | ●         |
| V70(00-) | 2001 | CCM     | CCM             | ●         | ●        | ●         |
| V70(00-) | 2001 | DDM     | DDM             | ●         | ●        | ●         |
| V70(00-) | 2001 | PDM     | PDM             | ●         | ●        | ●         |
| V70(00-) | 2001 | PSM     | PSM             | ●         | ●        | ●         |
| V70(00-) | 2001 | SRS     | SRS             | ●         | ●        | ●         |
| V70(00-) | 2000 | Petrol  | B5204T5         | ●         | ●        | ●         |
| V70(00-) | 2000 | Petrol  | B5234T3         | ●         | ●        | ●         |
| V70(00-) | 2000 | Petrol  | B5244T3         | ●         | ●        | ●         |
| V70(00-) | 2000 | Diesel  | D5252T MSA 15.8 | ●         | ○        | ○         |
| V70(00-) | 2000 | AUM     | AUM             | ●         | ●        | ●         |
| V70(00-) | 2000 | CEM     | CEM             | ●         | ●        | ●         |
| V70(00-) | 2000 | DIM     | DIM             | ●         | ●        | ●         |
| V70(00-) | 2000 | PHM     | PHM             | ●         | ●        | ●         |
| V70(00-) | 2000 | REM     | REM             | ●         | ●        | ●         |
| V70(00-) | 2000 | RTI     | RTI             | ●         | ●        | ●         |
| V70(00-) | 2000 | SWM     | SWM             | ●         | ●        | ●         |
| V70(00-) | 2000 | UEM     | UEM             | ●         | ●        | ●         |
| V70(00-) | 2000 | TCM     | AW50/51AWD      | ●         | ●        | ●         |
| V70(00-) | 2000 | TCM     | AW55-50/51SN    | ●         | ●        | ●         |
| V70(00-) | 2000 | ABS/BCM | ABS/BCM         | ●         | ●        | ●         |
| V70(00-) | 2000 | SAS     | SAS             | ●         | ●        | ●         |
| V70(00-) | 2000 | CCM     | CCM             | ●         | ●        | ●         |
| V70(00-) | 2000 | DDM     | DDM             | ●         | ●        | ●         |
| V70(00-) | 2000 | PDM     | PDM             | ●         | ●        | ●         |
| V70(00-) | 2000 | PSM     | PSM             | ●         | ●        | ●         |
| V70(00-) | 2000 | SRS     | SRS             | ●         | ●        | ●         |
| XC60     | 2009 | DEM     | TF-80SC AWD     | ●         | ●        | ●         |
| XC60     | 2009 | DEM     | M66 AWD         | ●         | ●        | ●         |
| XC60     | 2009 | TCM     | TF-80SC AWD     | ●         | ●        | ●         |
| XC60     | 2009 | TCM     | TF-80SC AWD     | ●         | ●        | ●         |
| XC60     | 2009 | TCM     | TF-80SC AWD     | ●         | ●        | ●         |
| XC60     | 2009 | SUM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | PSM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | AUU     |                 | ●         | ●        | ●         |
| XC60     | 2009 | DDM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | PDM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | PAM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | KVM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | AUD     |                 | ●         | ●        | ●         |
| XC60     | 2009 | CPM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | SUB     |                 | ●         | ●        | ●         |
| XC60     | 2009 | BCM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | SAS     |                 | ●         | ●        | ●         |
| XC60     | 2009 | TRM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | PBM     |                 | ●         | ●        | ●         |
| XC60     | 2009 | MMM     |                 | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle   | Year | System | Type        | ECU Info. | Read DTC | Clear DTC |
|-----------|------|--------|-------------|-----------|----------|-----------|
| XC60      | 2009 | PHM    |             | ●         | ●        | ●         |
| XC60      | 2009 | ECM    | D5244T5     | ●         | ●        | ●         |
| XC60      | 2009 | ECM    | D5244T4     | ●         | ●        | ●         |
| XC60      | 2009 | ECM    | B6304T2     | ●         | ●        | ●         |
| XC60      | 2009 | CVM    |             | ●         | ●        | ●         |
| XC60      | 2009 | HCM    |             | ●         | ●        | ●         |
| XC60      | 2009 | BPM    |             | ●         | ●        | ●         |
| XC60      | 2009 | CEM    |             | ●         | ●        | ●         |
| XC60      | 2009 | CCM    |             | ●         | ●        | ●         |
| XC60      | 2009 | ICM    |             | ●         | ●        | ●         |
| XC60      | 2009 | POT    |             | ●         | ●        | ●         |
| XC60      | 2009 | HLDF   |             | ●         | ●        | ●         |
| XC60      | 2009 | IAM    |             | ●         | ●        | ●         |
| XC60      | 2009 | DIM    |             | ●         | ●        | ●         |
| XC60      | 2009 | DABM   |             | ●         | ●        | ●         |
| XC60      | 2009 | RDAR   |             | ●         | ●        | ●         |
| XC60      | 2009 | SRS    |             | ●         | ●        | ●         |
| XC60      | 2009 | FSM    |             | ●         | ●        | ●         |
| XC60      | 2009 | PAC    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2009 | DEM    | M66 AWD     | ●         | ●        | ●         |
| XC70(08-) | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2009 | ECM    | D5244T5     | ●         | ●        | ●         |
| XC70(08-) | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2009 | ECM    | D5244T4     | ●         | ●        | ●         |
| XC70(08-) | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2009 | ECM    | B6324S      | ●         | ●        | ●         |
| XC70(08-) | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2009 | ECM    | B6304T2     | ●         | ●        | ●         |
| XC70(08-) | 2009 | POT    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | SUM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | IAM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | PSM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | HLDF   |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | AUU    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | DDM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | PDM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | PAM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | KVM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | AUD    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | CPM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | SUB    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | HCM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | SRS    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | BCM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | SAS    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | CCM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | CEM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | TRM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | PBM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | FSM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | DIM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | PAC    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | RDAR   |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | MMM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | ICM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | BPM    |             | ●         | ●        | ●         |
| XC70(08-) | 2009 | PHM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2008 | DEM    | M66 AWD     | ●         | ●        | ●         |
| XC70(08-) | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2008 | ECM    | D5244T5     | ●         | ●        | ●         |
| XC70(08-) | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2008 | ECM    | D5244T4     | ●         | ●        | ●         |
| XC70(08-) | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC70(08-) | 2008 | ECM    | B6324S      | ●         | ●        | ●         |
| XC70(08-) | 2008 | POT    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | SUM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | IAM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | PSM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | RDAR   |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | HLDF   |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | AUU    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | DDM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | PDM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | PAM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | KVM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | AUD    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | PHM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | CPM    |             | ●         | ●        | ●         |
| XC70(08-) | 2008 | SUB    |             | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle   | Year | System  | Type       | ECU Info. | Read DTC | Clear DTC |
|-----------|------|---------|------------|-----------|----------|-----------|
| XC70(08-) | 2008 | HCM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | SRS     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | BCM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | SAS     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | CEM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | DIM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | CCM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | TRM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | PBM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | BPM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | MMM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | FSM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | ICM     |            | ●         | ●        | ●         |
| XC70(08-) | 2008 | PAC     |            | ●         | ●        | ●         |
| XC90      | 2005 | AEM     | AEM        | ●         | ●        | ●         |
| XC90      | 2005 | ATM     | ATM        | ●         | ●        | ●         |
| XC90      | 2005 | AUD     | AUD        | ●         | ●        | ●         |
| XC90      | 2005 | MP2     | MP2        | ●         | ●        | ●         |
| XC90      | 2005 | CEM     | CEM        | ●         | ●        | ●         |
| XC90      | 2005 | DIM     | DIM        | ●         | ●        | ●         |
| XC90      | 2005 | ICM     | ICM        | ●         | ●        | ●         |
| XC90      | 2005 | MP1     | MP1        | ●         | ●        | ●         |
| XC90      | 2005 | MMM     | MMM        | ●         | ●        | ●         |
| XC90      | 2005 | PHM     | PHM        | ●         | ●        | ●         |
| XC90      | 2005 | REM     | REM        | ●         | ●        | ●         |
| XC90      | 2005 | SAS     | SAS        | ●         | ●        | ●         |
| XC90      | 2005 | SAS     | SAS        | ●         | ●        | ●         |
| XC90      | 2005 | CCM     | CCM        | ●         | ●        | ●         |
| XC90      | 2005 | DDM     | DDM        | ●         | ●        | ●         |
| XC90      | 2005 | PDM     | PDM        | ●         | ●        | ●         |
| XC90      | 2005 | PSM     | PSM        | ●         | ●        | ●         |
| XC90      | 2004 | Petrol  | B5254T2    | ●         | ●        | ●         |
| XC90      | 2004 | Petrol  | B6294T     | ●         | ●        | ●         |
| XC90      | 2004 | Diesel  | D5244T     | ●         | ●        | ●         |
| XC90      | 2004 | AEM     | AEM        | ●         | ●        | ●         |
| XC90      | 2004 | ATM     | ATM        | ●         | ●        | ●         |
| XC90      | 2004 | AUD     | AUD        | ●         | ●        | ●         |
| XC90      | 2004 | MP2     | MP2        | ●         | ●        | ●         |
| XC90      | 2004 | CEM     | CEM        | ●         | ●        | ●         |
| XC90      | 2004 | DIM     | DIM        | ●         | ●        | ●         |
| XC90      | 2004 | ICM     | ICM        | ●         | ●        | ●         |
| XC90      | 2004 | MP1     | MP1        | ●         | ●        | ●         |
| XC90      | 2004 | MMM     | MMM        | ●         | ●        | ●         |
| XC90      | 2004 | PHM     | PHM        | ●         | ●        | ●         |
| XC90      | 2004 | REM     | REM        | ●         | ●        | ●         |
| XC90      | 2004 | SWM     | SWM        | ●         | ●        | ●         |
| XC90      | 2004 | SUB     | SUB        | ●         | ●        | ●         |
| XC90      | 2004 | UEM     | UEM        | ●         | ●        | ●         |
| XC90      | 2004 | TCM     | 4T65AWD    | ●         | ●        | ●         |
| XC90      | 2004 | TCM     | AW50/51AWD | ●         | ●        | ●         |
| XC90      | 2004 | DEM     | DEM        | ●         | ●        | ●         |
| XC90      | 2004 | ABS/BCM | ABS/BCM    | ●         | ●        | ●         |
| XC90      | 2004 | SAS     | SAS        | ●         | ●        | ●         |
| XC90      | 2004 | CCM     | CCM        | ●         | ●        | ●         |
| XC90      | 2004 | DDM     | DDM        | ●         | ●        | ●         |
| XC90      | 2004 | PDM     | PDM        | ●         | ●        | ●         |
| XC90      | 2004 | PSM     | PSM        | ●         | ●        | ●         |
| XC90      | 2004 | SRS     | SRS        | ●         | ●        | ●         |
| XC90      | 2003 | Petrol  | B5254T2    | ●         | ●        | ●         |
| XC90      | 2003 | Petrol  | B6294T     | ●         | ●        | ●         |
| XC90      | 2003 | Diesel  | D5244T     | ●         | ●        | ●         |
| XC90      | 2003 | AEM     | AEM        | ●         | ●        | ●         |
| XC90      | 2003 | ATM     | ATM        | ●         | ●        | ●         |
| XC90      | 2003 | AUD     | AUD        | ●         | ●        | ●         |
| XC90      | 2003 | MP2     | MP2        | ●         | ●        | ●         |
| XC90      | 2003 | CEM     | CEM        | ●         | ●        | ●         |
| XC90      | 2003 | DIM     | DIM        | ●         | ●        | ●         |
| XC90      | 2003 | ICM     | ICM        | ●         | ●        | ●         |
| XC90      | 2003 | MP1     | MP1        | ●         | ●        | ●         |
| XC90      | 2003 | MMM     | MMM        | ●         | ●        | ●         |
| XC90      | 2003 | PHM     | PHM        | ●         | ●        | ●         |
| XC90      | 2003 | REM     | REM        | ●         | ●        | ●         |
| XC90      | 2003 | SWM     | SWM        | ●         | ●        | ●         |
| XC90      | 2003 | SUB     | SUB        | ●         | ●        | ●         |
| XC90      | 2003 | UEM     | UEM        | ●         | ●        | ●         |
| XC90      | 2003 | TCM     | 4T65AWD    | ●         | ●        | ●         |
| XC90      | 2003 | TCM     | AW50/51AWD | ●         | ●        | ●         |
| XC90      | 2003 | ABS/BCM | ABS/BCM    | ●         | ●        | ●         |
| XC90      | 2003 | SAS     | SAS        | ●         | ●        | ●         |
| XC90      | 2003 | CCM     | CCM        | ●         | ●        | ●         |
| XC90      | 2003 | DDM     | DDM        | ●         | ●        | ●         |





# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System | Type        | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------|-------------|-----------|----------|-----------|
| XC90    | 2003 | PDM    | PDM         | ●         | ●        | ●         |
| XC90    | 2003 | PSM    | PSM         | ●         | ●        | ●         |
| XC90    | 2003 | SRS    | SRS         | ●         | ●        | ●         |
| XC90    | 2003 | DEM    | DEM         | ●         | ●        | ●         |
| XC90    | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | M66 AWD     | ●         | ●        | ●         |
| XC90    | 2009 | BCM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2009 | SAS    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2009 | HCM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2009 | ECM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2009 | CEM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | M66 AWD     | ●         | ●        | ●         |
| XC90    | 2009 | BCM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2009 | SAS    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2009 | HCM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2009 | CEM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2009 | ECM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | BCM    | B8444S      | ●         | ●        | ●         |
| XC90    | 2009 | ECM    | B8444S      | ●         | ●        | ●         |
| XC90    | 2009 | SAS    | B8444S      | ●         | ●        | ●         |
| XC90    | 2009 | HCM    | B8444S      | ●         | ●        | ●         |
| XC90    | 2009 | CEM    | B8444S      | ●         | ●        | ●         |
| XC90    | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | BCM    | B6324S      | ●         | ●        | ●         |
| XC90    | 2009 | SAS    | B6324S      | ●         | ●        | ●         |
| XC90    | 2009 | HCM    | B6324S      | ●         | ●        | ●         |
| XC90    | 2009 | ECM    | B6324S      | ●         | ●        | ●         |
| XC90    | 2009 | CEM    | B6324S      | ●         | ●        | ●         |
| XC90    | 2009 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2009 | BCM    | B5254T2     | ●         | ●        | ●         |
| XC90    | 2009 | SAS    | B5254T2     | ●         | ●        | ●         |
| XC90    | 2009 | ECM    | B5254T2     | ●         | ●        | ●         |
| XC90    | 2009 | HCM    | B5254T2     | ●         | ●        | ●         |
| XC90    | 2009 | CEM    | B5254T2     | ●         | ●        | ●         |
| XC90    | 2009 | GPS    |             | ●         | ●        | ●         |
| XC90    | 2009 | SRS    |             | ●         | ●        | ●         |
| XC90    | 2009 | PSM    |             | ●         | ●        | ●         |
| XC90    | 2009 | DDM    |             | ●         | ●        | ●         |
| XC90    | 2009 | PDM    |             | ●         | ●        | ●         |
| XC90    | 2009 | AEM    |             | ●         | ●        | ●         |
| XC90    | 2009 | REM    |             | ●         | ●        | ●         |
| XC90    | 2009 | CPM    |             | ●         | ○        | ○         |
| XC90    | 2009 | RDAR   |             | ●         | ●        | ●         |
| XC90    | 2009 | AUD    |             | ●         | ●        | ●         |
| XC90    | 2009 | PAC    |             | ●         | ○        | ○         |
| XC90    | 2009 | AUU    |             | ●         | ●        | ●         |
| XC90    | 2009 | CCM    |             | ●         | ●        | ●         |
| XC90    | 2009 | DIM    |             | ●         | ●        | ●         |
| XC90    | 2009 | UEM    |             | ●         | ●        | ●         |
| XC90    | 2009 | IAM    |             | ●         | ●        | ●         |
| XC90    | 2009 | ICM    |             | ●         | ●        | ●         |
| XC90    | 2009 | MMM    |             | ●         | ●        | ●         |
| XC90    | 2009 | PHM    |             | ●         | ●        | ●         |
| XC90    | 2009 | TCM    | TF-80SC     | ●         | ●        | ●         |
| XC90    | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | M66 AWD     | ●         | ●        | ●         |
| XC90    | 2008 | BCM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2008 | CEM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2008 | HCM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2008 | SAS    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2008 | ECM    | D5244T5     | ●         | ●        | ●         |
| XC90    | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | M66 AWD     | ●         | ●        | ●         |
| XC90    | 2008 | BCM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2008 | CEM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2008 | HCM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2008 | SAS    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2008 | ECM    | D5244T4     | ●         | ●        | ●         |
| XC90    | 2008 | TCM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2008 | BCM    | B8444S      | ●         | ●        | ●         |
| XC90    | 2008 | ECM    | B8444S      | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System | Type         | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------|--------------|-----------|----------|-----------|
| XC90    | 2008 | SAS    | B8444S       | ●         | ●        | ●         |
| XC90    | 2008 | CEM    | B8444S       | ●         | ●        | ●         |
| XC90    | 2008 | HCM    | B8444S       | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2008 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2008 | BCM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2008 | SAS    | B6324S       | ●         | ●        | ●         |
| XC90    | 2008 | CEM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2008 | HCM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2008 | ECM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2008 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2008 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2008 | BCM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2008 | CEM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2008 | HCM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2008 | SAS    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2008 | ECM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2008 | GPS    |              | ●         | ●        | ●         |
| XC90    | 2008 | SRS    |              | ●         | ●        | ●         |
| XC90    | 2008 | PSM    |              | ●         | ●        | ●         |
| XC90    | 2008 | DDM    |              | ●         | ●        | ●         |
| XC90    | 2008 | PDM    |              | ●         | ●        | ●         |
| XC90    | 2008 | AEM    |              | ●         | ●        | ●         |
| XC90    | 2008 | REM    |              | ●         | ●        | ●         |
| XC90    | 2008 | CPM    |              | ●         | ○        | ○         |
| XC90    | 2008 | RDAR   |              | ●         | ●        | ●         |
| XC90    | 2008 | IAM    |              | ●         | ●        | ●         |
| XC90    | 2008 | AUD    |              | ●         | ●        | ●         |
| XC90    | 2008 | PAC    |              | ●         | ○        | ○         |
| XC90    | 2008 | AUU    |              | ●         | ●        | ●         |
| XC90    | 2008 | PHM    |              | ●         | ●        | ●         |
| XC90    | 2008 | CCM    |              | ●         | ●        | ●         |
| XC90    | 2008 | DIM    |              | ●         | ●        | ●         |
| XC90    | 2008 | UEM    |              | ●         | ●        | ●         |
| XC90    | 2008 | ICM    |              | ●         | ●        | ●         |
| XC90    | 2008 | MMM    |              | ●         | ●        | ●         |
| XC90    | 2008 | TCM    | TF-80SC      | ●         | ●        | ●         |
| XC90    | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | DEM    | M66 AWD      | ●         | ●        | ●         |
| XC90    | 2007 | BCM    | D5244T4      | ●         | ●        | ●         |
| XC90    | 2007 | CEM    | D5244T4      | ●         | ●        | ●         |
| XC90    | 2007 | HCM    | D5244T4      | ●         | ●        | ●         |
| XC90    | 2007 | SAS    | D5244T4      | ●         | ●        | ●         |
| XC90    | 2007 | ECM    | D5244T4      | ●         | ●        | ●         |
| XC90    | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | BCM    | B8444S       | ●         | ●        | ●         |
| XC90    | 2007 | SAS    | B8444S       | ●         | ●        | ●         |
| XC90    | 2007 | CEM    | B8444S       | ●         | ●        | ●         |
| XC90    | 2007 | HCM    | B8444S       | ●         | ●        | ●         |
| XC90    | 2007 | ECM    | B8444S       | ●         | ●        | ●         |
| XC90    | 2007 | DEM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | BCM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2007 | SAS    | B6324S       | ●         | ●        | ●         |
| XC90    | 2007 | CEM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2007 | HCM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2007 | ECM    | B6324S       | ●         | ●        | ●         |
| XC90    | 2007 | DEM    | M66 AWD      | ●         | ●        | ●         |
| XC90    | 2007 | TCM    | AW55-50/51SN | ●         | ●        | ●         |
| XC90    | 2007 | DEM    | AW50/51 AWD  | ●         | ●        | ●         |
| XC90    | 2007 | TCM    | TF-80SC AWD  | ●         | ●        | ●         |
| XC90    | 2007 | BCM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2007 | CEM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2007 | HCM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2007 | SAS    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2007 | ECM    | B5254T2      | ●         | ●        | ●         |
| XC90    | 2007 | GPS    |              | ●         | ●        | ●         |
| XC90    | 2007 | SRS    |              | ●         | ●        | ●         |
| XC90    | 2007 | PSM    |              | ●         | ●        | ●         |
| XC90    | 2007 | DDM    |              | ●         | ●        | ●         |
| XC90    | 2007 | PDM    |              | ●         | ●        | ●         |
| XC90    | 2007 | AEM    |              | ●         | ●        | ●         |
| XC90    | 2007 | PHM    |              | ●         | ●        | ●         |
| XC90    | 2007 | REM    |              | ●         | ●        | ●         |
| XC90    | 2007 | CPM    |              | ●         | ○        | ○         |
| XC90    | 2007 | RDAR   |              | ●         | ●        | ●         |
| XC90    | 2007 | CCM    |              | ●         | ●        | ●         |
| XC90    | 2007 | IAM    |              | ●         | ●        | ●         |
| XC90    | 2007 | AUD    |              | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System      | Type        | ECU Info. | Read DTC | Clear DTC |
|---------|------|-------------|-------------|-----------|----------|-----------|
| XC90    | 2007 | PAC         |             | ●         | ○        | ○         |
| XC90    | 2007 | MMM         |             | ●         | ●        | ●         |
| XC90    | 2007 | AUU         |             | ●         | ●        | ●         |
| XC90    | 2007 | DIM         |             | ●         | ●        | ●         |
| XC90    | 2007 | UEM         |             | ●         | ●        | ●         |
| XC90    | 2007 | ICM         |             | ●         | ●        | ●         |
| XC90    | 2007 | TCM         | TF-80SC     | ●         | ●        | ●         |
| XC90    | 2006 | TCM         | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | M66 AWD     | ●         | ●        | ●         |
| XC90    | 2006 | BCM         | D5244T4     | ●         | ●        | ●         |
| XC90    | 2006 | CEM         | D5244T4     | ●         | ●        | ●         |
| XC90    | 2006 | SAS         | D5244T4     | ●         | ●        | ●         |
| XC90    | 2006 | ECM         | D5244T4     | ●         | ●        | ●         |
| XC90    | 2006 | TCM         | AW50/51 AWD | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | AW50/51 AWD | ●         | ●        | ●         |
| XC90    | 2006 | ECM         | D5244T      | ●         | ●        | ●         |
| XC90    | 2006 | BCM         | D5244T      | ●         | ●        | ●         |
| XC90    | 2006 | CEM         | D5244T      | ●         | ●        | ●         |
| XC90    | 2006 | SAS         | D5244T      | ●         | ●        | ●         |
| XC90    | 2006 | TCM         | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2006 | BCM         | B8444S      | ●         | ●        | ●         |
| XC90    | 2006 | SAS         | B8444S      | ●         | ●        | ●         |
| XC90    | 2006 | CEM         | B8444S      | ●         | ●        | ●         |
| XC90    | 2006 | ECM         | B8444S      | ●         | ●        | ●         |
| XC90    | 2006 | TCM         | 4T65 AWD    | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | 4T65 AWD    | ●         | ●        | ●         |
| XC90    | 2006 | BCM         | B6294T      | ●         | ●        | ●         |
| XC90    | 2006 | ECM         | B6294T      | ●         | ●        | ●         |
| XC90    | 2006 | CEM         | B6294T      | ●         | ●        | ●         |
| XC90    | 2006 | SAS         | B6294T      | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | M66 AWD     | ●         | ●        | ●         |
| XC90    | 2006 | TCM         | AW50/51 AWD | ●         | ●        | ●         |
| XC90    | 2006 | DEM         | AW50/51 AWD | ●         | ●        | ●         |
| XC90    | 2006 | BCM         | B5254T2     | ●         | ●        | ●         |
| XC90    | 2006 | CEM         | B5254T2     | ●         | ●        | ●         |
| XC90    | 2006 | ECM         | B5254T2     | ●         | ●        | ●         |
| XC90    | 2006 | SAS         | B5254T2     | ●         | ●        | ●         |
| XC90    | 2006 | MP1         |             | ●         | ●        | ●         |
| XC90    | 2006 | MP2         |             | ●         | ●        | ●         |
| XC90    | 2006 | ATM         |             | ●         | ●        | ●         |
| XC90    | 2006 | REM         |             | ●         | ●        | ●         |
| XC90    | 2006 | SRS         |             | ●         | ●        | ●         |
| XC90    | 2006 | PSM         |             | ●         | ●        | ●         |
| XC90    | 2006 | DDM         |             | ●         | ●        | ●         |
| XC90    | 2006 | PDM         |             | ●         | ●        | ●         |
| XC90    | 2006 | AEM         |             | ●         | ●        | ●         |
| XC90    | 2006 | AUD         |             | ●         | ●        | ●         |
| XC90    | 2006 | ICM         |             | ●         | ●        | ●         |
| XC90    | 2006 | PHM         |             | ●         | ●        | ●         |
| XC90    | 2006 | DIM         |             | ●         | ●        | ●         |
| XC90    | 2006 | CPM         |             | ●         | ○        | ○         |
| XC90    | 2006 | UEM         |             | ●         | ●        | ●         |
| XC90    | 2006 | CCM         |             | ●         | ●        | ●         |
| XC90    | 2006 | MMM         |             | ●         | ●        | ●         |
| XC90    | 2005 | Petrol      | B5254T2     | ●         | ●        | ●         |
| XC90    | 2005 | Petrol      | B6294T      | ●         | ●        | ●         |
| XC90    | 2005 | Petrol      | B8444S      | ●         | ●        | ●         |
| XC90    | 2005 | Diesel      | D5244T      | ●         | ●        | ●         |
| XC90    | 2005 | TCM         | 4T65AWD     | ●         | ●        | ●         |
| XC90    | 2005 | TCM         | AW50/51AWD  | ●         | ●        | ●         |
| XC90    | 2005 | DEM         | DEM         | ●         | ●        | ●         |
| XC90    | 2005 | TCM         | TF-80SC AWD | ●         | ●        | ●         |
| XC90    | 2005 | ABS/BCM     | ABS/BCM     | ●         | ●        | ●         |
| XC90    | 2005 | SUB         | SUB         | ●         | ●        | ●         |
| XC90    | 2005 | SRS         | SRS         | ●         | ●        | ●         |
| XC90    | 2005 | UEM         | UEM         | ●         | ●        | ●         |
| V90     | 1998 | ABS/BCM     | ABS/BCM     | ●         | ●        | ●         |
| V90     | 1998 | Immobilizer | IMM         | ●         | ●        | ●         |
| V90     | 1998 | Petrol      | ECM         | ●         | ●        | ●         |
| V90     | 1998 | CI          | CI          | ●         | ○        | ○         |
| V90     | 1998 | PSL         | PSL         | ●         | ●        | ●         |
| V90     | 1998 | PSR         | PSR         | ●         | ●        | ●         |
| V90     | 1998 | RTI         | RTI         | ●         | ●        | ●         |
| V90     | 1998 | SRS         | SRS         | ●         | ●        | ●         |
| V90     | 1998 | TCM         | AW30-40     | ●         | ●        | ●         |
| V90     | 1997 | ABS/BCM     | ABS/BCM     | ●         | ●        | ●         |
| V90     | 1997 | Immobilizer | IMM         | ●         | ●        | ●         |
| V90     | 1997 | Petrol      | ECM         | ●         | ●        | ●         |
| V90     | 1997 | CI          | CI          | ●         | ○        | ○         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle     | Year | System       | Type            | ECU Info. | Read DTC | Clear DTC |
|-------------|------|--------------|-----------------|-----------|----------|-----------|
| V90         | 1997 | PSL          | PSL             | ●         | ●        | ●         |
| V90         | 1997 | PSR          | PSR             | ●         | ●        | ●         |
| V90         | 1997 | RTI          | RTI             | ●         | ●        | ●         |
| V90         | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| V90         | 1997 | TCM          | AW30-40         | ●         | ●        | ●         |
| V70(-00)    | 1998 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| V70(-00)    | 1998 | ECM          | D5252T MSA 15.7 | ●         | ●        | ●         |
| V70(-00)    | 1998 | Motronic 4.4 | ECM             | ●         | ●        | ●         |
| V70(-00)    | 1998 | Immobilizer  | IMM             | ●         | ●        | ●         |
| V70(-00)    | 1998 | CI           | CI              | ●         | ●        | ●         |
| V70(-00)    | 1998 | VGLA         | VGLA            | ●         | ●        | ●         |
| V70(-00)    | 1998 | PSL          | PSL             | ●         | ●        | ●         |
| V70(-00)    | 1998 | PSR          | PSR             | ●         | ●        | ●         |
| V70(-00)    | 1998 | CPM          | CPM             | ●         | ●        | ●         |
| V70(-00)    | 1998 | RTI          | RTI             | ●         | ●        | ●         |
| V70(-00)    | 1998 | SRS          | SRS             | ●         | ●        | ●         |
| V70(-00)    | 1998 | TCM          | AW42AWD         | ●         | ●        | ●         |
| V70(-00)    | 1997 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| V70(-00)    | 1997 | ECM          | D5252T MSA 15.7 | ●         | ●        | ●         |
| V70(-00)    | 1997 | Motronic 4.4 | ECM             | ●         | ●        | ●         |
| V70(-00)    | 1997 | Immobilizer  | IMM             | ●         | ●        | ●         |
| V70(-00)    | 1997 | CI           | CI              | ●         | ●        | ●         |
| V70(-00)    | 1997 | VGLA         | VGLA            | ●         | ●        | ●         |
| V70(-00)    | 1997 | PSL          | PSL             | ●         | ●        | ●         |
| V70(-00)    | 1997 | PSR          | PSR             | ●         | ●        | ●         |
| V70(-00)    | 1997 | CPM          | CPM             | ●         | ●        | ●         |
| V70(-00)    | 1997 | RTI          | RTI             | ●         | ●        | ●         |
| V70(-00)    | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| V70(-00)    | 1997 | TCM          | AW42AWD         | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | CI           | CI              | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | VGLA         | VGLA            | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | PSL          | PSL             | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | PSR          | PSR             | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | Immobilizer  | IMM             | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | ECM          | D5252T MSA 15.7 | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | RTI          | RTI             | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | SRS          | SRS             | ●         | ●        | ●         |
| V70 XC(-00) | 1998 | TCM          | AW42AWD         | ●         | ●        | ●         |
| V40         | 1998 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| V40         | 1998 | CI           | CI              | ●         | ●        | ●         |
| V40         | 1998 | Immobilizer  | IMM             | ●         | ●        | ●         |
| V40         | 1998 | VGLA         | VGLA            | ●         | ●        | ●         |
| V40         | 1998 | CPM          | CPM             | ●         | ●        | ●         |
| V40         | 1998 | DSA          | DSA             | ●         | ●        | ●         |
| V40         | 1998 | SRS          | SRS             | ●         | ●        | ●         |
| V40         | 1998 | TCM          | AW50-42         | ●         | ●        | ●         |
| V40         | 1998 | CCM          | CCM             | ●         | ●        | ●         |
| V40         | 1998 | RTI          | RTI             | ●         | ●        | ●         |
| V40         | 1997 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| V40         | 1997 | CI           | CI              | ●         | ●        | ●         |
| V40         | 1997 | Immobilizer  | IMM             | ●         | ●        | ●         |
| V40         | 1997 | VGLA         | VGLA            | ●         | ●        | ●         |
| V40         | 1997 | CPM          | CPM             | ●         | ●        | ●         |
| V40         | 1997 | DSA          | DSA             | ●         | ●        | ●         |
| V40         | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| V40         | 1997 | TCM          | AW50-42         | ●         | ●        | ●         |
| V40         | 1997 | CCM          | CCM             | ●         | ●        | ●         |
| V40         | 1997 | RTI          | RTI             | ●         | ●        | ●         |
| V40         | 1996 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| V40         | 1996 | CI           | CI              | ●         | ●        | ●         |
| V40         | 1996 | Immobilizer  | IMM             | ●         | ●        | ●         |
| V40         | 1996 | VGLA         | VGLA            | ●         | ●        | ●         |
| V40         | 1996 | CPM          | CPM             | ●         | ●        | ●         |
| V40         | 1996 | DSA          | DSA             | ●         | ●        | ●         |
| V40         | 1996 | SRS          | SRS             | ●         | ●        | ●         |
| V40         | 1996 | TCM          | AW50-42         | ●         | ●        | ●         |
| V40         | 1996 | CCM          | CCM             | ●         | ●        | ●         |
| V40         | 1996 | RTI          | RTI             | ●         | ●        | ●         |
| S90         | 1998 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S90         | 1998 | Immobilizer  | IMM             | ●         | ●        | ●         |
| S90         | 1998 | CI           | CI              | ●         | ○        | ○         |
| S90         | 1998 | PSL          | PSL             | ●         | ●        | ●         |
| S90         | 1998 | PSR          | PSR             | ●         | ●        | ●         |
| S90         | 1998 | Engine 1     | ECM             | ●         | ●        | ●         |
| S90         | 1998 | SRS          | SRS             | ●         | ●        | ●         |
| S90         | 1998 | RTI          | RTI             | ●         | ●        | ●         |
| S90         | 1998 | TCM          | AW30-43         | ●         | ●        | ●         |
| S90         | 1997 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S90         | 1997 | Immobilizer  | IMM             | ●         | ●        | ●         |
| S90         | 1997 | CI           | CI              | ●         | ○        | ○         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle  | Year | System       | Type            | ECU Info. | Read DTC | Clear DTC |
|----------|------|--------------|-----------------|-----------|----------|-----------|
| S90      | 1997 | PSL          | PSL             | ●         | ●        | ●         |
| S90      | 1997 | PSR          | PSR             | ●         | ●        | ●         |
| S90      | 1997 | Engine 1     | ECM             | ●         | ●        | ●         |
| S90      | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| S90      | 1997 | RTI          | RTI             | ●         | ●        | ●         |
| S90      | 1997 | TCM          | AW30-43         | ●         | ●        | ●         |
| S70      | 1998 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S70      | 1998 | Motronic 4.4 | ECM             | ●         | ●        | ●         |
| S70      | 1998 | ECM          | D5252T MSA 15.7 | ●         | ●        | ●         |
| S70      | 1998 | Engine 1     | ECM             | ●         | ●        | ●         |
| S70      | 1998 | Immobilizer  | IMM             | ●         | ●        | ●         |
| S70      | 1998 | CI           | CI              | ●         | ○        | ○         |
| S70      | 1998 | VGLA         | VGLA            | ●         | ●        | ●         |
| S70      | 1998 | PSL          | PSL             | ●         | ●        | ●         |
| S70      | 1998 | PSR          | PSR             | ●         | ●        | ●         |
| S70      | 1998 | CPM          | CPM             | ●         | ●        | ●         |
| S70      | 1998 | RTI          | RTI             | ●         | ●        | ●         |
| S70      | 1998 | SRS          | SRS             | ●         | ●        | ●         |
| S70      | 1998 | TCM          | AW50-42         | ●         | ●        | ●         |
| S70      | 1997 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S70      | 1997 | Petrol       | ECM             | ●         | ●        | ●         |
| S70      | 1997 | Motronic 4.4 | ECM             | ●         | ●        | ●         |
| S70      | 1997 | ECM          | D5252T MSA 15.7 | ●         | ●        | ●         |
| S70      | 1997 | Immobilizer  | IMM             | ●         | ●        | ●         |
| S70      | 1997 | CI           | CI              | ●         | ○        | ○         |
| S70      | 1997 | VGLA         | VGLA            | ●         | ●        | ●         |
| S70      | 1997 | PSL          | PSL             | ●         | ●        | ●         |
| S70      | 1997 | PSR          | PSR             | ●         | ●        | ●         |
| S70      | 1997 | CPM          | CPM             | ●         | ●        | ●         |
| S70      | 1997 | RTI          | RTI             | ●         | ●        | ●         |
| S70      | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| S70      | 1997 | TCM          | AW50-42         | ●         | ●        | ●         |
| S40(-04) | 1998 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S40(-04) | 1998 | CI           | CI              | ●         | ●        | ●         |
| S40(-04) | 1998 | immobilizer  | IMM             | ●         | ●        | ●         |
| S40(-04) | 1998 | VGLA         | VGLA            | ●         | ●        | ●         |
| S40(-04) | 1998 | CPM          | CPM             | ●         | ●        | ●         |
| S40(-04) | 1998 | DSA          | DSA             | ●         | ●        | ●         |
| S40(-04) | 1998 | CCM          | CCM             | ●         | ●        | ●         |
| S40(-04) | 1998 | RTI          | RTI             | ●         | ●        | ●         |
| S40(-04) | 1998 | SRS          | SRS             | ●         | ●        | ●         |
| S40(-04) | 1998 | TCM          | AW50-42         | ●         | ●        | ●         |
| S40(-04) | 1997 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S40(-04) | 1997 | CI           | CI              | ●         | ●        | ●         |
| S40(-04) | 1997 | immobilizer  | IMM             | ●         | ●        | ●         |
| S40(-04) | 1997 | VGLA         | VGLA            | ●         | ●        | ●         |
| S40(-04) | 1997 | CPM          | CPM             | ●         | ●        | ●         |
| S40(-04) | 1997 | DSA          | DSA             | ●         | ●        | ●         |
| S40(-04) | 1997 | CCM          | CCM             | ●         | ●        | ●         |
| S40(-04) | 1997 | RTI          | RTI             | ●         | ●        | ●         |
| S40(-04) | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| S40(-04) | 1997 | TCM          | AW50-42         | ●         | ●        | ●         |
| S40(-04) | 1996 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| S40(-04) | 1996 | CI           | CI              | ●         | ●        | ●         |
| S40(-04) | 1996 | immobilizer  | IMM             | ●         | ●        | ●         |
| S40(-04) | 1996 | VGLA         | VGLA            | ●         | ●        | ●         |
| S40(-04) | 1996 | CPM          | CPM             | ●         | ●        | ●         |
| S40(-04) | 1996 | DSA          | DSA             | ●         | ●        | ●         |
| S40(-04) | 1996 | CCM          | CCM             | ●         | ●        | ●         |
| S40(-04) | 1996 | RTI          | RTI             | ●         | ●        | ●         |
| S40(-04) | 1996 | SRS          | SRS             | ●         | ●        | ●         |
| S40(-04) | 1996 | TCM          | AW50-42         | ●         | ●        | ●         |
| 960      | 1997 | Petrol       | ECM             | ●         | ●        | ●         |
| 960      | 1997 | CI           | CI              | ●         | ●        | ●         |
| 960      | 1997 | immobilizer  | IMM             | ●         | ●        | ●         |
| 960      | 1997 | PSL          | PSL             | ●         | ●        | ●         |
| 960      | 1997 | PSR          | PSR             | ●         | ●        | ●         |
| 960      | 1997 | TCM          | AW30-43         | ●         | ●        | ●         |
| 960      | 1997 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| 960      | 1997 | SRS          | SRS             | ●         | ●        | ●         |
| 960      | 1996 | Petrol       | ECM             | ●         | ●        | ●         |
| 960      | 1996 | CI           | CI              | ●         | ●        | ●         |
| 960      | 1996 | immobilizer  | IMM             | ●         | ●        | ●         |
| 960      | 1996 | PSL          | PSL             | ●         | ●        | ●         |
| 960      | 1996 | PSR          | PSR             | ●         | ●        | ●         |
| 960      | 1996 | TCM          | AW30-43         | ●         | ●        | ●         |
| 960      | 1996 | ABS/BCM      | ABS/BCM         | ●         | ●        | ●         |
| 960      | 1996 | SRS          | SRS             | ●         | ●        | ●         |
| 960      | 1995 | Petrol       | ECM             | ●         | ●        | ●         |
| 960      | 1995 | CI           | CI              | ●         | ●        | ●         |
| 960      | 1995 | immobilizer  | IMM             | ●         | ●        | ●         |



# Check\_AbsSrs\_Volvo\_V1.00 Function List

NOTES: ● This function is supported. ○ This function is not supported. ※ This function may be supported, which depends on the a

| Vehicle | Year | System       | Type    | ECU Info. | Read DTC | Clear DTC |
|---------|------|--------------|---------|-----------|----------|-----------|
| 960     | 1995 | PSL          | PSL     | ●         | ●        | ●         |
| 960     | 1995 | PSR          | PSR     | ●         | ●        | ●         |
| 960     | 1995 | TCM          | AW30-43 | ●         | ●        | ●         |
| 960     | 1995 | ABS/BCM      | ABS/BCM | ●         | ●        | ●         |
| 960     | 1995 | SRS          | SRS     | ●         | ●        | ●         |
| 850     | 1997 | Motronic 4.4 | ECM     | ●         | ●        | ●         |
| 850     | 1997 | CI           | CI      | ●         | ●        | ●         |
| 850     | 1997 | Immobilizer  | IMM     | ●         | ●        | ●         |
| 850     | 1997 | PSL          | PSL     | ●         | ●        | ●         |
| 850     | 1997 | PSR          | PSR     | ●         | ●        | ●         |
| 850     | 1997 | TCM          | AW50-42 | ●         | ●        | ●         |
| 850     | 1997 | ABS/BCM      | ABS/BCM | ●         | ●        | ●         |
| 850     | 1997 | SRS          | SRS     | ●         | ●        | ●         |
| 850     | 1996 | CI           | CI      | ●         | ●        | ●         |
| 850     | 1996 | Immobilizer  | IMM     | ●         | ●        | ●         |
| 850     | 1996 | PSL          | PSL     | ●         | ●        | ●         |
| 850     | 1996 | PSR          | PSR     | ●         | ●        | ●         |
| 850     | 1996 | Motronic 4.4 | ECM     | ●         | ●        | ●         |
| 850     | 1996 | TCM          | AW50-42 | ●         | ●        | ●         |
| 850     | 1996 | ABS/BCM      | ABS/BCM | ●         | ●        | ●         |
| 850     | 1996 | SRS          | SRS     | ●         | ●        | ●         |
| 850     | 1995 | CI           | CI      | ●         | ●        | ●         |
| 850     | 1995 | Immobilizer  | IMM     | ●         | ●        | ●         |
| 850     | 1995 | PSL          | PSL     | ●         | ●        | ●         |
| 850     | 1995 | PSR          | PSR     | ●         | ●        | ●         |
| 850     | 1995 | Petrol       | ECM     | ●         | ●        | ●         |
| 850     | 1995 | TCM          | AW50-42 | ●         | ●        | ●         |
| 850     | 1995 | ABS/BCM      | ABS/BCM | ●         | ●        | ●         |
| 850     | 1995 | SRS          | SRS     | ●         | ●        | ●         |