

● This function is supported.  
※ This function may be supported, which depends on the actual condition of the vehicle.  
○ This function is not supported.  
▲ This function is the new feature in this version.  
As for special function please refer to the special function table.

[illegible]

## MaxiDiagElite\_Benz\_DPF\_V1.00 Function List

### NOTES:

- This function is supported.
  - ※ This function may be supported, which depends on the actual condition of the vehicle.
  - This function is not supported.
  - ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Infor.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Special Function
All	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	0019 0022 0071 0024 0075 0076 0074
Up to 08/2002	S-Class	220	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	
Up to 08/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	0019 0073 0074 0024
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	
As of 09/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	
All	M-Class	164	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	0066 0064 0065 0019 0074
All	M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●	●	●	0074 0024 0077 0023
All	M-Class	164	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	0019 0022 0071 0024 0075 0076 0074
All	M-Class	163	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	
All	M-Class	163	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	0066 0064 0065 0019 0074
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	0066 0064 0065 0019 0074
All	G-Class	461(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	
All	GL-Class	X 164	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	0066 0064 0065 0019 0074
All	GL-Class	X 164	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	0019 0022 0071 0024 0075 0076 0074
All	R-Class	251	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	0066 0064 0065 0019 0074
All	R-Class	251	Drive	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●	●	●	0074 0024 0077 0023
As of 2010	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	0023 0024 0071 0074
As of 2010	E-Class	212	Drive	CDID-Common Rail Diesel Injection	●	●	●	●	○	●	0074 0023 0024
As of 2010	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	0023 0024 0071 0074
As of 2010	E-Class	207	Drive	CDID-Common Rail Diesel Injection	●	●	●	●	○	●	0074 0023 0024