## **CAN DI Self test**

Please confirm the connection among OBD interface, candi main cable, GM and power is correct. When test candi, you must provide power from OBD connector, please refer to the following picture.









## F0: Diagnostics F1: Service Programming System F2: View Captured Data F3: GM Performance Parts Diagnostics F4: Tool Options F5: Getting Started

## F0: Set Clock F1: Set Screen Contrast F2: Set Units F3: Self Test F4: Programming TECH 2 F5: Set Communication By-Pass Mode F6: Set Language F7: CANdi Diagnostics

## CANdi Diagnostics Version 1.00

FO: POST Results

**7.** 

CANdi POST Resu	
Test Complete	Test stati
CANdi Present	Pa
Boot S/W Revision	1.
App. S/W Revision	4.
Hardware Revision	
CANdi RAM	Pa
CANdi Boot	Pa
UART Data Link	Pa



CANdi Self Test Res	Test state
Test Complete	1636 3696
CANdi Present	Pa
Boot S/W Revision	
App. S/W Revision	4.
Hardware Revision	1.
CANdi RAM	Ra
CANdi Boot	Pa
CANdi Resident	Pa
CANdi Application	
Low Speed Data Link	
Med. Spd. Data Link	
High Speed Data Link	

Mark: there are two kinds of CANDI self test, please refer to the picture NO.8 and NO.10.