

Model	System
AN250K3-L1	Engine
AN250MK7-L1	Engine & Transmission
AN400K3-L2	Engine
AN400AK9-L2	Engine, ABS
AN650K3-K4	Engine, Transmission
AN650K5-L1	Engine & Transmission
AN650AK4	Engine, Transmission, ABS
AN650AK5-L2	Engine & Transmission, ABS
DL650K4-L1	Engine
DL650AK7-L2	Engine, ABS
DL1000K4-L2	Engine
DR125SMK9-L1	Engine
FL125SDWK7-K9	Engine
GSF650/SK7-L2	Engine
GSF650A/SAK5-K6	ABS
GSF650A/SAK7-L2	Engine, ABS
GSF1200A/SAK6	ABS
GSF1250K7-L1	Engine
GSF1250SK7-L2	Engine
GSF1250AK7-L1	Engine, ABS
GSF1250SAK7-L2	Engine, ABS
GSR400K6-L0	Engine
GSR400AK7-L1	Engine, ABS
GSR600K6-L0	Engine
GSR600AK7-L0	Engine, ABS
GSR750L1-L2	Engine
GSR750AL1-L2	Engine, ABS
GSX650FK8-L2	Engine
GSX650FAK9-L2	Engine, ABS
GSX-R600/750K4-L2	Engine
GSX-R1000K3-L2	Engine
GSX1250FAL0-L2	Engine, ABS
GSX1300BKK8-L0	Engine
GSX1300BKAK8-L0	Engine, ABS
GSX1300RK8-L2	Engine
GSX1400K4-K7	Engine
GW250L2-L3	Engine
GZ125K7-L1	Engine
RMX450ZL0-L2	Engine
RM-Z250L0-L3	Engine
RM-Z450K8-L3	Engine
RV125K7-L3	Engine
RV200K8-L3	Engine
SFV400AL0-L2	Engine, ABS
SFV650K9-L2	Engine
SFV650AK9-L2	Engine, ABS
ST250XK8-L0	Engine
SV650K3-K9	Engine
SV650SK3-L2	Engine
SV650AK7-K9	Engine, ABS
SV650SAK7-L2	Engine, ABS
SV1000/SK3-K7	Engine
TU250G/G2K9-L1	Engine

TU250XK9-L2	Engine
UH125/200K7-L2	Engine
UL250K8	Engine
UX125/150K8-L1	Engine
VL400K9-L1	Engine
VL800K5-L2	Engine
VL1500K5-L0	Engine
VLR1800K8-L1	Engine
VZ400K9-L1	Engine
VZ800K5-L2	Engine
VZ1500K9-L0	Engine
VZR1800K6-L2	Engine
LT-A400/FL0-L3	Engine
LT-A450XK7-L0	Engine
LT-A500XPK9-L3	Engine, EPS
LT-A700XK5-K7	Engine
LT-A750XK8-L3	Engine
LT-A750XPK9-L3	Engine, EPS
LT-F400/FL0-L3	Engine
LT-R450K6-L2	Engine
LT-Z400K9-L2	Engine