

SKP-100 User manual

1.How to use the SKP-100 to match the car keys.

SKP-100 connect to the main cable, and plug in the car's OBD diagnostic interface.



Press [OK] to enter the menu.



Press [OK] to enter the vehicle selection. Press the arrow keys to select vehicles.



***The operation can be done according to the SKP-100 tips.**

2.the menu HARDWARE TEST reserves , you can ignore it.

3.How to upgrade the SKP-100.

Connect to the computer with a USB cable and SKP-100.




4.1 Installing the SKP-100 driver

If this is the first time using the SKP-100 connect to the computer to install the driver to normal use.




Select "Install a list or specific location (Advanced)", click "NEXT".



Select "Include this location in the search:", click "Browse".



Locate the folder where the disc "USB Drive", click "OK".



Click "Next".




Click "Continue Anyway".




Click "Finish".

4.2 Upgrade the SKP-100.


Run the SKP-100 Upgrade Tool.




Click "Find Device", If the device list is empty, reconnect SKP-100 or to install the driver.





Click "Open Upgrade File" to Open the upgrade file from the dealer.





Click "Upgrade" to upgrade SKP-100.





Upgrade finish.