


Write the original key through the NEC adapter

CG-MB




Please insert the key into CG-MB device




Click "Read", show related key information




Disassemble the key, take the chip out, and solder it to the NEC adapter




Read key, view related information




Reset and erase new key



Click open/write, please note the prompt



Choose—unused key position data, click and open it



Write success



Take the chip out, weld NEC adapter back the key, get on the car