Catalog

Super MB STAR Updater v3.0 Installation Package
How to get new version Super MB STAR Updater2
Super MB STAR Updater v3.0 Installation2
Super MB STAR Updater v3.0 User Manual
Active and Link email7
Edit User Information
Upgrade Steps11
Renew Steps
Change Password14
Forget Password15
Other Notice16

Super MB STAR Updater v3.0 Install Guide

How to get new version v3.0

- 1. Upgrade directly from Super MB STAR Updater v2.0.0.1
- 2. Download from Super MB STAR Offical website http://www.supermbstar.com/update/
- 3. Contact with your local dealer to get the upgrade installation software


Installation

- 1. After get the new version of Super MB STAR Updater V3.0, please insert the USB Key, and then install this software in **Super MB STAR OS**. (*Do not install in your local HDD*)
- 2. Un-zip it on the Super MB STAR Desktop, double click to run choose the language, and click [OK]. [Pic.1]




[Pic.1]

3. Click [Next], as [Pic.2]




[Pic.2]

4. Setting the installation path, click [Next] as default install path. [Pic.3]




[Pic.3]

5. Create desktop icon is necessary, click [Next] as [Pic.4]




[Pic.4]

6. Click [Install] to start the installation after check everything alright. [Pic.5]




[Pic.5]

7. Software requires user install Microsoft Visual C++, please click [Next] to continue. [Pic.6]




[Pic.6]

8. Click [Install] to start installing visual C++ [Pic.7]




[Pic.7]

9. Click [Finish] to continue. [Pic.8]



[Pic.8]

10. Click [Finish] to finish the installation of Super MB STAR Updater V3.0 [Pic.9]



[Pic.9]


Super MB STAR Updater v3.0 user manual

Active and Link

1. Double click the Super MB STAR Updater V3.0 icon on your Super MB STAR OS Desktop, then [choose a serve] near you, input the Super MB STAR [Serial number], [input the password], click [Login] button to login. [Pic.1]


Note:

Serial number: You can find it *at the side of your USB Key*. Format: [SUPXXXXXXER]
Password: You can find it *in the Super MB STAR Password letter*. [*Last 8 digital numbers is the default login password*, you can change it after your login.]




[Pic.1]

2. If this is the first time your Super MB STAR login, it will be automatically active, the expiration days will start to count from this time, and you will see the following screen. [Pic.2]



[Pic.2]

3. Please input your email address, and then click [**Register**], Super MB STAR system will send you a register code to your email automatically, please checks your email to get the code. [Pic.3]




[Pic.3]


4. Input the register code to your Super MB STAR Updater, and click [Link] to finish the active and link steps. [Pic.4]

Notice:

You can click [Remind Later] button to login the Super MB STAR Updater directly without linking to your email, but the upgrade function not available until you linked your email successfully.




[Pic.4]



Edit User Information


1. In Super MB STAR Updater main page, click [**User Center**] to edit your information. The address information is not able to be edited once you click [**update**] button. [Pic.1]



[Pic.1]


Upgrade Super MB STAR Software

Super MB STAR Updater knows what version of your current software version is, and you are
only able to upgrade new version software by clicking them, old version will be marked as
"Upgrade Installed", new version which are available to upgrade will be marked as "Upgrade
Available" [Pic.1]



[Pic.1]

- 2. Click [**Download**] button to download the upgrade software for your software, you can see the download progress in "Progress" menu.
 - This V3.0 Super MB STAR Updater supports **breakpoint continuingly** function, if you lost your internet connection or laptop shut off, next time when you launch the Super MB STAR Updater, download progress will be continued from your last breakpoint. [Pic.2]




[Pic.2]

3. After downloading finished, the upgrade software will automatically running and installing.

Renew Super MB STAR License


- 1. Login Super MB STAR Updater by your serial number and password.
- 2. Click [Renew] button
- 3. Input [card number] and [security code] to renew your Super MB STAR license. [Pic.1]



[Pic.1]

Change Password


- 1. Double Click to run your Super MB STAR Updater
- 2. Input your S/N
- 3. Click [Modify] button
- 4. Input the [current password] and [new password] to change your Super MB STAR Password [Pic.1]



[Pic.1]

Forget password

- 1. Double click to run Super MB STAR Updater
- 2. Input your S/N
- 3. Click [Forget] button
- 4. System will pop up a window and shows your linked email
- 5. Click [OK], Super MB STAR Updater will send your password to your linked email. [Pic.1]



[Pic.1]

Other Notice

- 1. Please install Super MB STAR Updater v3.0 in your Super MB STAR OS.
- 2. Please do not mix the Super MB STAR serial number when upgrading. (Use the same serial number to upgrade in Super MB STAR OS.)
- 3. Please keep your laptop battery charged during the upgrade progress.
- 4. Please do not install or trying to use Super MB STAR Updater to upgrade other software (*such as MB STAR, STAR COMPACT3 or SD Connect*) we do not pay any responsibility for your destroy or lose.
- 5. Please contact with your local dealer for technical support immediately if you meet any errors during upgrading.
- 6. Super MB STAR Inc. reserves the final interpretation.
- 7. Verify your Super MB STAR Online by: http://verify.supermbstar.com