Some customer encounter "can not buy single car software" problem when using X431 iDiag, they feel can only buy software package. Here is instructions to help you resolve that problem. Step 1: You can use your pc to log in your account



@1999-2012 LAUNCH Corporation All Rights Reserved #83-20042020

Hompage | LADER hompage | About un | Contact un | LADER dealer

Step 2: After log in, it show you the serial number, please click "submit"

omepage	Products	News center	Service	User center	About us	
Shoppin	g center					Navigation menu
-> +omepage	User center -> Shopp	ping center				Purchase center
Notice: after s	switching products, th	he shopping cart in shop	ping center will be er	mptied.)		Upgrade center
reduct ON -	065200004007	Select default		Californit		Order information
	305230004307	Select deladit	1211	Subinit		Download center
						Product management
						Users E-mail box
						Product register
						User info maintenance

Step 3: Find the software model you want to buy and click "subscribe"

		-	
	TN.		

Welcome Malyshkov Users E-mail box | Exit

Homepage -	<b>ng center</b> > Usercenter-> Sho	pping center			
roduct SN :	965290004907 🛩	( Notice: after switching	products, the shopping	g cart in shopping c	enter will be
mptied.)				Return Subscr	Ny shapping c
	Software name	Purchasable	Upload date	Purchase price	Operate
<b>_</b>	ACURA	10.42	2013-02-21	66.0(USD)	View
	AUDI	26.33	2013-06-14	66.0(USD)	View
	BeiJing Hyunda	i 20.41	2013-06-14	66.0(USD)	View
	BENZ	46.00	2013-06-14	66.0(USD)	View
	BMW	46.30	2013-06-14	66.0(USD)	View
	Brilliance-auto	30.01	2013-06-14	66.0(USD)	View
	BXFIAT	10.01	2013-06-09 11:20:46	66.0(USD)	View
	CHANGAN	15.01	2013-06-14	66.0(USD)	View
	CHANGCHENG	32.01	2013-06-14	66.0(USD)	View
	CHANGFENG	20.01	2013-06-09 11:38:25	66.0(USD)	View

Navigation menu

There are 102 records in total Current page: 1/11 Page [1] 2 3 4 5 6 ... 11 Turn to page 60

Step 4: Click "create order"



Step 5: After create the order, you can pay for it. Please notice you must pay in USD. If the iPad or iPhone inform you "Diagnosis software system, language was not found, please switch device language." After you buy the software in USD, this problem can automatically resolve.