X-431 HD Module (Android-based) User Manual



LAUNCH

X-431 HD Module (Android-based) User Manual

LAUNCH

3 Activate X-431 HD Module

Follow the steps described below to activate X-431 HD module:

Note: Please make sure that your diagnostic tool is properly connected to the internet before proceed this step.

	Activate Device
Serial Number: Enter device	serial number
Verification Code: Enter 6-2	0 characters
	Activate
How to get verification code	?
How to get device?	

2. Input the Product S/N and Verification Code (can be obtained from the included Password Envelope), then tap "Activate" to activate the X-431 HD module.



Bluetooth Settings

Before diagnosing a vehicle, you are suggested to make a Bluetooth pair between X-431 HD module and the diagnostic tool. Proceed as follows:

- 1. Enter Bluetooth setting screen ("Settings" --> "Bluetooth"), slide the Bluetooth switch to ON and will start searching all available Bluetooth devices.
- 2. Tap the desired one, then key in the PIN code (the default value is 0000) in the pop-up dialog box, and then tap "Pair".

By default, the Bluetooth name is 98454*****00 (where ***** stands for 5 digits.).

3. Once it is paired successfully, it will appear in the paired devices list.

Note: If no Bluetooth setting is done before diagnostic application is launched, you can also configure it while using the software.



文档大小:原始文档为A4纸张(宽297mm x 高210mm),按照1:1输出 材质要求:157G双铜

印刷要求:彩色印刷