

(I)	2400 16v
(I)	2400 16v
(II)	2000 16v
(II)	2000 16v DI-D
(II)	2200 16v DI-D
(II)	2200 16v DI-D
(II)	2200 16v DI-D
(III)	2200 16v DI-D
(III)	2500 TD
(III)	3000 V6
(III)	3200 TD
(III)	3500 V6
(IV)	3200 DI-D
(IV)	3200 DI-D
(IV)	3200 DI-D
(V93)	3000 V6 24V
(V93)	3800 V6 24V
	1800 16v GDI
	2000 16v GDI
(II)	3200 TD
(II)	2000 16v GDI
(II)	2400 16v
(II)	3200 TD
	2000 16v GDI
	2400 16v
	1800 16v GDI
	1900 8v DI-D
	1900 8v DI-D
(III)	3200 TD
(IV)	2500 16v DI-D
(IV)	3200 16v DI-D
	3000 DDI
	3000 DDI
	3000 DDI
	3000 DDI
	3000 DDI
FG 4x4	3000 DDI
	5000 TD
(Z33)	3500 V6
(Z33)	3500 V6
(Z33)	3500 V6
(Z34)	3700 V6
(G11)	1600 16V
(N16)	1500 dCi
(N16)	1800 16V
(N16)	2200 DCi
(N16)	2200 TD Di
(N16)	2200 TD Di
(N17)	1500
110	3000 Tdi