

CDGA	110	150	Petrol	2010	BOSCH
CAYC	77	105	Diesel	2010	SIEMENS
CDAA	118	160	Petrol	2010	BOSCH
CDAA	118	160	Petrol	2009	BOSCH
CDAB	112	152	Petrol	2010	BOSCH
CEAA	118	160	Petrol	2011	BOSCH
CBAB	103	140	Diesel	2009	BOSCH
CBAB	103	140	Diesel	2009	BOSCH
CFAA	100	136	Diesel	2010	BOSCH
CFAA	100	136	Diesel	2010	BOSCH
CFFA	100	136	Diesel	2008	BOSCH
CFFB	103	140	Diesel	2010	BOSCH
CFGB	125	170	Diesel	2010	BOSCH
CFGC	130	177	Diesel	2012	BOSCH
CKRA	103	140	Diesel	2013	BOSCH
CLLA	125	170	Diesel	2010	BOSCH
CCZA	147	200	Petrol	2009	BOSCH
CCZA	147	200	Petrol	2009	TEMIC
CCZB	155	211	Petrol	2010	BOSCH
CCZB	155	211	Petrol	2010	TEMIC
CBUA	125	170	Petrol	2011	BOSCH
CBUA	125	170	Petrol	2010	BOSCH
BWS	220	300	Petrol	2010	BOSCH
DCXA	88	120	Diesel	2014	BOSCH
CRLB	110	150	Diesel	2015	BOSCH
CRLB	110	150	Diesel	2015	BOSCH
CUAA	176	239	Diesel	2014	BOSCH
DFCA	140	190	Diesel	2015	BOSCH
BZB	118	160	Petrol	2008	BOSCH
BZB	118	160	Petrol	2008	BOSCH
CDAA	118	160	Petrol	2009	BOSCH
CDAB	112	152	Petrol	2009	BOSCH
CGYA	112	152	Petrol	2008	BOSCH
CBAA	100	136	Diesel	2008	BOSCH
CBAA	100	136	Diesel	2008	BOSCH
CBAB	103	140	Diesel	2008	BOSCH
CBAB	103	140	Diesel	2008	BOSCH
CBAC	105	143	Diesel	2009	BOSCH
CBAC	105	143	Diesel	2009	BOSCH
CBBB	125	170	Diesel	2008	BOSCH
CBBB	125	170	Diesel	2008	BOSCH
CFFA	100	136	Diesel	2008	BOSCH
CFFB	103	140	Diesel	2010	BOSCH
CFGB	125	170	Diesel	2010	BOSCH
CLLA	125	170	Diesel	2011	BOSCH
CCTA	147	200	Petrol	2012	BOSCH
CAWB	147	200	Petrol	2008	BOSCH
CBFA	147	200	Petrol	2009	BOSCH
CCTA	147	200	Petrol	2008	BOSCH
CCTA	147	200	Petrol	2008	BOSCH