

AEB	110	150	Petrol	1997	BOSCH
AJL	132	180	Petrol	1997	BOSCH
ANB	110	150	Petrol	1999	BOSCH
APU	110	150	Petrol	1998	BOSCH
AWT	110	150	Petrol	2000	BOSCH
AFN	81	110	Diesel	1997	BOSCH
AJM	85	115	Diesel	1998	BOSCH
AVF	96	131	Diesel	2001	BOSCH
AVG	81	110	Diesel	1999	BOSCH
AWX	96	131	Diesel	2001	BOSCH
ALT	96	131	Petrol	2001	BOSCH
ALW	100	136	Petrol	1997	BOSCH
AMM	120	163	Petrol	2000	BOSCH
APZ	120	163	Petrol	1998	BOSCH
ARN	100	136	Petrol	1999	BOSCH
ASM	100	136	Petrol	2000	BOSCH
AFB	110	150	Diesel	1997	BOSCH
AKE	132	179	Diesel	1999	BOSCH
AKN	110	150	Diesel	1998	BOSCH
AYM	114	155	Diesel	2001	BOSCH
BAU	132	179	Diesel	2003	BOSCH
BCZ	120	163	Diesel	2003	BOSCH
BDG	120	163	Diesel	2003	BOSCH
BDH	132	179	Diesel	2003	BOSCH
BFC	120	163	Diesel	2002	BOSCH
AJK	169	230	Petrol	1999	BOSCH
ARE	184	250	Petrol	2000	BOSCH
AZA	169	230	Petrol	2000	BOSCH
BES	184	250	Petrol	2002	BOSCH
ACK	142	193	Petrol	1997	BOSCH
ALG	142	193	Petrol	1997	BOSCH
AMX	142	193	Petrol	1998	BOSCH
APR	142	193	Petrol	1998	BOSCH
AQD	142	193	Petrol	1997	BOSCH
ARS	220	299	Petrol	1999	BOSCH
ASG	220	299	Petrol	2000	BOSCH
BAS	220	299	Petrol	2003	BOSCH
BLB	103	140	Diesel	2004	BOSCH
BRE	103	140	Diesel	2005	BOSCH
CAGB	100	136	Diesel	2008	BOSCH
CAGB	100	136	Diesel	2008	BOSCH
CAHA	125	170	Diesel	2008	BOSCH
CAHA	125	170	Diesel	2008	BOSCH
CAHB	120	163	Diesel	2009	BOSCH
BPJ	125	170	Petrol	2005	BOSCH
BPP	132	179	Diesel	2004	BOSCH
CANA	140	190	Diesel	2008	BOSCH
CANA	140	190	Diesel	2008	BOSCH
CANB	120	163	Diesel	2008	BOSCH
CANB	120	163	Diesel	2008	BOSCH