

Aero	2300 16v Turbo
Aero	2800 V6 24v Turbo
	7000 V8 16v Twinturbo
(B)	1000 12V
(B)	1200 16V
(F)	1400 16V
(F)	1800 8V
(F)	2000 16V
(G)	1200 16V
(G)	1200 16V
(G)	1400 16V
(G)	1600 8V
(G)	1600 16V
(G)	1700 8V TD
(G)	1700 16V DTI
(G)	2000 16V DI
(G)	2000 16V DTI
(G)	2000 16V Turbo
(H)	1300 CDTI
(H)	1600 16V
(H)	1700 16V CDTI
(H)	1900 CDTI
(H)	1900 CDTI
(H)	1900 CDTI
(H)	2000 16V Turbo
	3600 V6
(D)	1200 16V
(D)	1600 16V Turbo
(D)	1600 16V Turbo
(D)	1600 16V Turbo
	2800 V6
(B)	2000 16V Turbo
(B)	2000 16V Turbo
	2000 D4-S
I	1800 20v Turbo
I	1800 20v Turbo
I	1900 8v TDI
I	1900 8v TDI
I	1900 8v TDI
I	1900 8v TDI
I	1900 8v TDI
I	1900 8v TDI
I	1900 8v TDI
I	1900 8v TDI
I	2000 16v TDI
I	2000 16v TDI
I	2000 8v
I	2000 8v
I	2800 V6 24v
I	2800 V6 24v